

IDENTIFICATION
=====

PRODUCT CODE: AC-9045G-MC
PRODUCT NAME: CZAMCGO 0-124K MEM EXER 16K
PRODUCT DATE: 27-DECEMBER-1979
MAINTAINER: DIAGNOSTIC ENGINEERING

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

No responsibility is assumed for the use or reliability of software on equipment that is not supplied by Digital or its affiliated companies.

Copyright (c) 1975, 1980 by Digital Equipment Corporation

The following are trademarks of Digital Equipment Corporation:

DIGITAL PDP UNIBUS MASSBUS
DEC DECUS DECTAPE

REVISION HISTORY
=====

REVISION A: MAY 1975
REVISION B: OCTOBER 1975
REVISION C: OCTOBER 1976
REVISION D: JUNE 1977
REVISION E: DECEMBER 1977
REVISION F: FEBRUARY 1978
REVISION G: DECEMBER 1979
CHGG1 - INSERT DUMMY ARGUMENTS UNDER ERRTB ITEM 22
IN ORDER THAT ERROR REPORTING ROUTINES
WILL REPORT MESSAGES CORRECTLY.
CHGG2 - CHANGE BNE INSTRUCTION TO BEQ IN CKPME SUB-
ROUTINE TO REPORT CORRECT ERROR MESSAGE.

TABLE OF CONTENTS

1.0	GENERAL PROGRAM INFORMATION.
1.1	Program Purpose (Abstract)
1.2	System Requirements
1.3	Related Documents and Standards
1.4	Diagnostic Hierarchy Prerequisites
1.5	Assumptions
2.0	OPERATING INSTRUCTIONS
2.1	Loading and Starting Procedure
2.2	Special Environments
2.3	Program Options
2.4	Execution Times
3.0	ERROR INFORMATION
3.1	Error Reporting
3.2	Error Halts
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
5.1	CORE PARITY REGISTER
5.2	MOS PARITY REGISTER
5.3	MSII-K CSR
6.0	SUB-TEST SUMMARIES
6.1	Section 1: Address Tests
6.2	Section 2: Worst Case Noise Tests
6.3	Section 3: Instruction Execution Tests
6.4	Section 4: MOS Tests
6.5	Special Toggle in Tests
7.0	PROGRAM FUNCTIONAL FLOW CHARTS
8.0	PROGRAM LISTING

1.0 GENERAL PROGRAM INFORMATION.

1.1 Program Purpose (Abstract)

This program has the ability to test memory from address 000000 to address 757777. It does so using:

- A. Unique addressing techniques
- B. Worst case noise patterns, and
- C. Instruction execution thruout memory.

There is also a special routine to type out all unibus address ranges which do not timeout, as well as two(2) toggle in address tests provided in section 6.1 of this document.

The intent of this program is to test as comprehensively as possible all memory systems manufactured by DEC without concentrating on any one system. Although the tests relate to general designs they may be complete for certain systems. E.G. Any core memory from the 8K MM11-L on up need not have any other addressing or worst case patterns run but in order to completely test the MS11-K MOS memory another diagnostic is required. This test is also not intended to be a 100% test of the memory. Other tests that do I/O may find memory problems that this test is unable to.

1.2 System Requirements

A. Hardware Requirements

PDP11 family processor with a minimum of 16K of memory.
optional...
Any parity memory control module.
KT11 memory management.

B. Software Requirements

The smallest unit of memory this program will recognize is 4K. If any address in a 4K bank causes a time out trap, that entire bank of memory is ignored by the program.

The program is designed to exercise the vector portion of memory (locations 0-776) in exactly the same manner as the rest of memory. To make this possible, without requiring memory management, no software traps are used in the program. This means that if memory management is not available or is disabled (SW12=1), if the program is relocated out of bank 0, if location 0-776 are selected for test, and if an unexpected hardware trap occurs, the results will be unpredictable.

The program has the proper interface code to allow running under the automated manufacturing test line system - ACT11 and APT.

1.3 Related Documents and Standards

- A. Programming Practices - Document No. 175-003-009-01
- B. PDP-11 MAINDEC SYSMAC Package - MAINDEC-11-DZQAC-C2-D
- C. The applicable Memory System Maintenance Manual
- D. The applicable Circuit Schematics

1.4 Diagnostic Hierarchy Prerequisites

Before running this program, a CPU diagnostic should be run to verify the functionality of the processor and PDP-11 instruction set.

If memory management is to be used, then the KT11 diagnostic should also be run before this program.

PDP-11/20 - MAINDEC-11-DZQKC
PDP-11/34 - MAINDEC-11-DFKTH
PDP-11/40 - MAINDEC-11-DBQEAE
OR MAINDEC-11-DCQKC
PDP-11/45 - MAINDEC-11-DCQKC
PDP-11/60 - MAINDEC-11-DQKDA
KT11-C - MAINDEC-11-DCKTA THRU DCKTF
KT11-D - MAINDEC-11-DBKTA THRU DBKTF

1.5 Assumptions

This program assumes the correct operation of the CPU and, if used, the memory management option.

2.0 OPERATING INSTRUCTIONS

2.1 Loading and Starting Procedures

2.1.1 Load the program using any standard absolute loader.

2.1.2 Starting address 200:

Normal program execution.

2.1.3 Starting address 204:

Allows the operator to input, via teletype conversation, first and last addresses to be exercised, and a data pattern to be used in tests 6 and 7.

2.1.4 Starting Address 210:

Restart program using previously selected parameters.

2.1.5 Starting Address 214:

Restore loaders and halt. This routine is capable of relocating the program back to banks 0 and 1 if the program was halted while running the top two banks of memory. There are special procedures required for this situation.

- A. If memory addresses 0-1000 have not been exercised, either through parameter selection (SA=204) or by running with SW05=1, then:

Load Address ?¹,
Press START.

- B. If running without memory management, then:

Load Address <214+relocation factor>
(Relocation factor is typed when the program is
relocated),
Press START.

- C. If running with memory management and the unibus has not been initialized (via reset instruction, start switch, etc.), then:

Load Address 777707 (PC)
Deposit 214
Press CONTINUE

- D. If running with memory management and the unibus has been initialized:

Load Address 772340 (KIPAR0)
Deposit <(relocation factor)/100>
(Example: Relocation factor=540000, then
deposit 005400)
Load Address 777572 (SR0)
Deposit 000001
Load Address 777707 (PC)
Deposit 214
Press Continue

2.1.6 Starting address 220:

Byte address memory map typeout routine. This routine performs DATI, DATIP, DATO, and DATOB on all possible addresses, and types the ranges of addresses which do not cause a timeout trap.

2.2 Special Environments

If the program is run in quick verify mode under ACT11 or APT11 the program is done after the first pass. Also, the

CZOMCGO 0-124K MEM EXER 16K

SEQ 000

program does not relocate to test the lower 8K of memory.

2.3 Program Options

SW15 = 1 OR UP....	HALT ON ERROR
SW14 = 1 OR UP....	LOOP ON TEST
SW13 = 1 OR UP....	INHIBIT ERROR TYPEOUT
SW12 = 1 OR UP....	INHIBIT MEMORY MANAGEMENT (INITIAL START ONLY)
SW11 = 1 OR UP....	INHIBIT SUBTEST ITERATION
SW10 = 1 OR UP....	RING BELL ON ERROR
SW9 = 1 OR UP....	LOOP ON ERROR
SW8 = 1 OR UP....	LOOP ON TEST IN SWR<4:0>
SW7 = 1 OR UP....	INHIBIT PROGRAM RELOCATION
SW6 = 1 OR UP....	INHIBIT PARITY ERROR DETECTION

NOTE: With parity error detection enabled, a memory failure while running the worse case noise tests (non-parity) can cause a parity error. The error printout on a parity error does not type the good data. Thus a bit drop or pickup will not be typed as such. It is best to run the program for 1 pass with parity disabled, then, restart the program with parity enabled.

SW5 = 1 OR UP.... INHIBIT EXERCISING VECTOR AREA
(LOCATIONS 0-1000).

2.4 EXECUTION TIMES

Execution time is dependent on type of memory, and amount of memory. Worse case run times with 900ns memorys are:

a. For Non-Parity Memory

First Pass: 65 seconds for first 16k + 15 seconds for each additional 16k.

Full Pass: 3 minutes 40 seconds for first 16k + 3 minutes for each additional 16k.

Iteration Inhibited: same as first pass

b. For Parity Memory

First Pass: 1 minute 40 seconds per 16k.

Full Pass: 8 minutes per 16K

Iteration Inhibited: same as first pass

3.0 ERROR INFORMATION

3.1 Error Reporting

There are a total of 31(8) types of error reports generated by the program. Some of the key column heading mnemonics are described below for clarity:

PC = Program Counter of error detection code.
(V/PC=P/PC)

V/PC = Virtual Program Counter. This is where the error detection code can be found in the program listing.

P/PC = Physical Program Counter. This is where the error detection code is actually located in memory.

TRP/PC = Physical Program Counter of the code which caused a trap.

MA = Memory Address

REG = Parity REGister address.

PS = Processor Status word.

IUT = Instruction Under Test.

S/B = What contents Should Be.

WAS = What contents WAS.

3.2 Error Halts

With the 'HALT ON ERROR' switch (SW15) not set there are several programmed 'HALTS' in the program:

- A. In the error trap service routine for unexpected traps to vector 4. This one will occur if a 2nd trap to 4 occurs before the error report for the first has had a chance to be printed out.
- B. In the relocation routine if the program is being relocated back to the first 8K of memory and the program code was not able to be transferred properly.
- C. In the case of error reporting and there is no terminal to allow the information transfer.

- D. In the power fail routine if the power up sequence was started before the power down sequence had a chance to complete itself.
- E. In the Memory mapping routine or any of the address control routines, failures to find a meaningful map.


4.0 PERFORMANCE AND PROGRESS REPORTS

Not applicable

5.0 DEVICE INFORMATION TABLES

The following is a picture view of a parity control status registers, which will show bit assignments and definitions, to provide a handy reference:

5.1 CORE PARITY REGISTER



Bit assignments are defined as follows:

BIT15 PARITY ERROR

BITS 11-5 ERROR
ADDRESS HIGH ORDER
ADDRESS BITS OF
ADDRESS OF PARITY
ERROR (BITS 17-11 OF
ADDRESS)

BIT02 WRITE WRONG
PARITY NORMAL PARITY
(ODD) WHEN CLEAR;
OTHER PARITY (EVEN)
WHEN SET

BIT00 ACTION ENABLE NO
ACTION WHEN CLEAR TRAP
TO VECTOR 114 WHEN SET

5.2 MOS PARITY REGISTER

PE	I	I	I	I	I	I	I	I	I	I	I	WP	I	AE	I
	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01 00

BIT ASSIGNMENTS ARE DEFINED AS FOLLOWS:

BIT15 PARITY ERROR

BIT02 WRITE WRONG
 PARITY NORMAL PARITY
 (ODD) WHEN CLEAR;
 OTHER PARITY (EVEN)
 WHEN SET

BIT00 ACTION ENABLE NO
 ACTION WHEN CLEAR TRAP
 TO VECTOR 114 WHEN SET

5.3 MS11-K CSR

DE	I	I	I	I	I	I	I	I	I	I	I	SE	IP	DC	EC	EE
	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00

BIT ASSIGNMENTS ARE DEFINED AS FOLLOWS:

BIT15 DOUBLE ERROR

BIT 13 SET INHIBIT
 MODE WHEN THIS BIT IS
 SET TO A 1. IT ENABLES
 THE INH MODE POINTER
 TO INHIBIT EITHER THE
 FIRST OR SECOND 16K
 FROM EVER GOING INTO
 THE DIAG. CHECK OR
 ECC DISABLE MODE.

BITS 11-5 ERROR
 ADDRESS WHEN BIT02
 CLEARED CONTAINS HIGH
 ORDER BITS OF ADDRESS
 OF PARITY ERROR(BITS
 17-11); WHEN BIT02
 SET CONTAINS CHECK
 BITS FOR ECC.

BIT04 SINGLE ERROR SET
 WHENEVER SINGLE ERROR
 OCCURS

BIT03 INHIBIT MODE
POINTER THE INHIBIT
MODE POINTER WORKS IN
CONJUNCTION WITH THE
SET INHIBIT MODE BIT.
WHEN BIT 13 IS SET TO
A 1, A 16K PORTION OF
MEMORY IS INHIBITED
FROM OPERATING IN THE
ECC DISABLE MODE OR
DIAGNOSTIC CHECK MODE.
THE INHIBIT MODE
POINTER INDICATES
WHICH 16K IS BEING
INHIBITED,,,BIT 3 =1

THE SECOND 16K OF
MEMORY IS INHIBITED.
WHEN BIT 13 IS SET TO
A 0, BIT 3 BECOMES
INOPERATIVE.

BIT02 DIAGNOSTIC CHECK
A WHEN SET ENABLES
READ-WRITE OF CHECK
BITS(SEE BITS 11-5)

BIT01 DISABLE ERROR
CORRECTION WHEN SET NO
ERROR CORRECTION TAKES
PLACE

BIT00 DOUBLE ERROR
ENABLE WHEN SET
ENABLES TRAP TO VECTOR
114 ON DOUBLE ERROR.

6.0 SUB-TEST SUMMARIES

6.1 Section 1: Address Tests.

These tests verify the uniqueness of every memory address.

TEST 1 Writes and reads the value of each memory Word
Address into that Memory location. After all memory has been
written, all locations are checked again.

TEST 2 Writes the byte value of each address into that byte
location and checks it.

TEST 3 Writes the complement of each word address into that
location and checks it.

TEST 4 Writes the 4K bank number into each byte of that bank and checks it.

TEST 5 Writes the complement of the bank number into each byte of that bank and checks it.

6.2 Section 2: Worst Case Noise Tests.

These are intended to apply maximum stress to the various types of PDP-11 core memories.

TEST 6 and TEST 7 Are supplied to allow the operator to select a single word data pattern (SA=204) and SCOPE on either the writing (DAT0) in TEST 6 or the reading (DAT1) in TEST 7 of that data.

TEST 10 Writes and then checks a series of single word patterns which are designed to stress parity memory.

TEST 11 Writes all memory with 1's in every bit and then 'Ripples' a '0' through it.

TEST 12 Writes all memory with 0's in every bit and then 'Ripples' a '1' through it.

TEST 13,14,15, AND 16 Write a pattern which complements when address BIT 3 XOR BIT 9 complements.

TEST 17 Writes wrong parity in each byte of memory and checks that the parity detection logic works. This test is skipped for non-parity memory.

TEST 20 Write "random" program code through memory and checks it.

6.3 Section 3: Instruction Execution Tests.

This group of tests place instructions in the memory under test, then executes the instructions, and finally, checks that they executed correctly.

TEST 21 Executes an instruction which does a DATI and a DAT0 on the memory under test.

TEST 22 Executes an instruction which does a DATI and a DATOB on the low byte of memory under test.

TEST 23 Executes an instruction which does a DATI and a DATOB on the high byte.

TEST 24 Executes an instruction which does a DATIP and a DATO.

TEST 25 Executes an instruction which does a DATIP and a DATOB on the low byte.

TEST 26 EXECUTES AN INSTRUCTION WHICH DOES A DATIP and a DATOB on the high byte.

6.4 Section 4: Mos Tests

TEST 27 -Writes a pattern of 000377 through memory, then compliments it addressing downward, compliments the new pattern addressing upward, compliments the third pattern addressing upward and finally compliments this new AB patterns addressing downward.

TEST 30-31 Write a checkerboard through memory then stalls for 2 seconds and then verifies no data has changed.

6.5 Special Toggle In Tests

6.5.1 Toggle-in-program #1

The following is a toggle in memory address test. This test is useful when an address selection failure is suspected involving the first 8K of memory. This program writes the value of each address into itself starting with the lower limit and continuing to the upper limit. After all addresses have been written each address is checked for the correct contents starting with the upper limit and continuing to the lower limit.

LOCATION	CONTENTS	MNEMONIC	COMMENT
10	012700	MOV #50,R0	:GET FIRST ADDRESS
* 12	000050		:TO TEST
			:(EXAMPLE START ADDRESS)
14	010001	MOV R0,R1	:SAVE IN R1
16	020037	1\$: CMP R0,ANSWR	:CHECK UPPER LIMIT
20	177570		:(IN SWITCH REGISTER)
22	001403	B EQ 2\$:BRANCH IF AT UPPER LIMIT
24	010010	MOV R0,(R0)	:LOAD VALUE INTO ADDRESS
26	005720	TST (R0)+	:STEP TO NEXT ADDRESS
30	000772	BR 1\$:LOOP UNTIL DONE
32	010004	2\$: MOV R0,R4	:SAVE UPPER LIMIT
34	020001	3\$: CMP R0,R1	:CHECK IF AT LOWER LIMIT
* 36	001767	B EQ 1\$:BRANCH IF DONE
40	024000	CMP -(R0),R0	:CHECK DATA WRITTEN
42	001774	B EQ 3\$:BRANCH IF OK
44	000000	HALT	:ERROR
46	000772	BR 3\$:LOOP BACK

After toggling the program LA=10**set upper limit**, start

NOTES: The upper limit address obtained from the switch

register may be changed during program operation. However occasionally the program may halt because of 'SWITCH BOUNCE'. (The best procedure when changing limits is to stop the program make the change and continue.) The lower limit address (12) may be patched to any desired address.

6.5.2 Toggle-in-Program #2

The following is also a toggle in program to be used with toggle-in-program #1 for more complete address testing. This program writes the complement value of each address into itself starting with the upper limit and continuing to the lower limit. After all addresses have been written each address is checked for the correct contents starting with the lower limit address and continuing to the upper limit. Toggle in the following patches to the program above.

These are the patches to toggle-in-prcgram #1:

LOCATION	CONTENTS	MNEMONIC	COMMENT
12	100		:CHANGE LOWER LIMIT
36	001404	BEO 4\$;BRANCH TO PROGRAM #2

These are the additions to toggle-in-program #1:

LOCATION	CONTENTS	MNEMONIC	COMMENT
50	010402	4\$: MOV R4,R2	:GET UPPER LIMIT
52	005142	5\$: COM -(R2)	:COMPLEMENT ADDRESS
54	020201	CMP R2,R1	:CHECK IF AT LOWER LIMIT
56	001375	BNE 5\$:LOOP UNTIL DONE
60	020204	6\$: CMP R2,R4	:CHECK IF AT UPPER LIMIT
62	001755	BEO 1\$:GO TO PROGRAM 1 IF DONE
64	010203	MOV R2,R3	:GET VALUE OF ADDRESS
66	005103	COM R3	:COMPLEMENT VALUE
70	020322	CMP R3,(R2)+	:CHECK ADDRESS
72	001772	BEO 6\$:BRANCH IF OK
74	000000	HALT	:ERROR
76	000770	BR 6\$:GO CHECK NEXT ADDRESS

7.0 PROGRAM FUNCTIONAL FLOW CHARTS

Attached

8.0 PROGRAM LISTING

Attached

6184 OPERATIONAL SWITCH SETTINGS
6186 BASIC DEFINITIONS
6189 MEMORY MANAGEMENT DEFINITIONS
6204 TRAP CATCHER
(1) STARTING ADDRESS(ES)
6215 ACT11 HOOKS
6290 POWER DOWN AND UP ROUTINES
6485 COMMON TAGS
(2) APT MAILBOX-E-TABLE
(4) APT PARAMETER BLOCK
(4) APT STATISTICS TABLE
(3) MEMORY PARITY PATTERNS TABLE
(3) MEMORY PARITY REGISTER ADDRESS TABLE
(1) ERROR POINTER TABLE
6616 START: SETUP AND MAP MEMORY
6624 INITIALIZE THE COMMON TAGS
6627 TYPE PROGRAM NAME
(2) GET VALUE FOR SOFTWARE SWITCH REGISTER
6789 MAP PARITY REGISTERS
6824 MAP PARITY MEMORY
6962 TEST PARITY REGISTERS
7039 USER PARAMETER SELECTION SECTION
7148 SECTION 1: MEMORY ADDRESS TESTS
7157 T1 WRITE VALUE OF MEMORY ADDRESS INTO MEMORY
7175 T2 WRITE VALUE OF MEMORY ADDRESS INTO MEMORY
7193 T3 WRITE 1'S COMPLEMENT VALUE OF ADDRESS INTO ADDRESS.
7211 T4 WRITE BANK # INTO ALL ADDRESSES IN A 4K BANK
7226 T5 WRITE 1'S COMPLEMENT OF BANK #.
7243 SECTION 2: WORST CASE NOISE TESTS
7248 T6 WRITE A CONSTANT INTO MEMORY.
7257 T7 READ MEMORY AND COMPARE TO CONSTANT.
7277 T10 WORSE CASE NOISE (PARITY) WORD TESTING
7288 T11 ROTATE A '0' BIT THROUGH A FIELD OF ONES.
7299 T12 ROTATE A '1' BIT THROUGH A FIELD OF ZEROS
7310 T13 3 XOR 9 TEST PATTERN.
7355 T14 COMPLEMENT 3 XOR 9 TEST PATTERN
7401 T15 MODIFIED 3 XOR 9 PATTERN FOR PARITY MEMORY
7466 T16 COMPLEMENT PARITY 3 XOR 9 TEST PATTERN.
7538 T17 WORSE CASE NOISE PARITY BYTE TESTING
7660 T20 RANDOM DATA TESTING THRU PROGRAM CODE RELOCATION.
7681 SECTION 3: INSTRUCTION EXECUTION TESTS.
7706 T21 EXECUTE DATI, DATO THRU MEMORY.
7743 T22 EXECUTE DATI, DATOB (LOW BYTE) THRU MEMORY.
7780 T23 EXECUTE DATI, DATOB (HIGH BYTE) THRU MEMORY.
7820 T24 EXECUTE DATI, DATIP, DATO THRU MEMORY.
7857 T25 EXECUTE DATI, DATI, DATIP, DATOB (LOW BYTE) THRU MEMORY.
7894 T26 EXECUTE DATI, DATI, DATIP, DATOB (HIGH BYTE) THRU MEMORY.
7908 SECTION 4: MOS TESTS
7932 T27 MARCHING 1'S AND 0'S.
7985 T30 WRITE CHECKERBOARD STARTING WITH '125252' DATA.
8002 T31 WRITE CHECKERBOARD STARTING WITH 052525 DATA
8020 DONE: RELOCATE PROGRAM AND REPEAT ALL TESTS.
8046 END OF PASS ROUTINE
8047 SUBROUTINE AND TRAP ROUTINE SECTION.
8048 MEMORY MANAGEMENT AND ADDRESSING SUBROUTINES.
8303 SUBROUTINES FOR ADDRESS AND WORSE CASE NOISE TESTS.

CZOMCGO O-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 12-MAR-80 13:10
CZOMCG.P11 12-MAR-80 13:07 TABLE OF CONTENTS

D 2

SEQ 0016

8403 RELOCATION SUBROUTINES.
8607 PARITY MEMORY TRAP SERVICE AND SUBROUTINES.
8761 SUBROUTINES TO SET UP DATA FOR ERROR PRINTOUT ROUTINE.
8919 SCOPE HANDLER ROUTINE
8921 ERROR HANDLER ROUTINE
8922 ERROR MESSAGE TYPEOUT ROUTINE
8923 TTY INPUT ROUTINE
8924 READ AN OCTAL NUMBER FROM THE TTY
8937 TYPE ROUTINE
8938 APT COMMUNICATIONS ROUTINE
8939 CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
8940 BINARY TO OCTAL (ASCII) AND TYPE
8954 PHYSICAL ADDRESS TYPE ROUTINE
9001 STANDARD PROGRAM MESSAGES
9039 ERROR REPORTING MESSAGES AND TABLES.

.TITLE CZOMCGO 0-124K MEMORY EXERCISER, 16K VER
.COPYRIGHT (C) 1975, 1979
.DIGITAL EQUIPMENT CORP.
.MAYNARD, MASS. 01754
.PROGRAM BY BRUCE BURGESS/KEN CHAPMAN
.THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
.PACKAGE (MAINDEC-11-DZQAC-(3), JAN 19, 1977.

6184 SBTTL OPERATIONAL SWITCH SETTINGS

	SWITCH	USE
(1)	15	HALT ON ERROR
(1)	14	LOOP ON TEST
(1)	13	INHIBIT ERROR TYPEOUTS
(1)	12	INHIBIT KT11 (AT START TIME ONLY)
(1)	11	INHIBIT ITERATIONS
(1)	10	BELL ON ERROR
(1)	9	LOOP ON ERROR
(1)	8	LOOP ON TEST IN SWR<4:0>
6185	7	INHIBIT PROGRAM RELOCATION
(1)	6	INHIBIT PARITY ERROR DETECTION
(1)	5	INHIBIT EXERCISING VECTOR AREA.

6186 SBTTL BASIC DEFINITIONS

(1) 001100 :*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***

(1) STACK 1100

(1) .EQUIV EMT,ERROR ;:BASIC DEFINITION OF ERROR CALL

(1) .EQUIV IOT,SCOPE ;:BASIC DEFINITION OF SCOPE CALL

(1) :*MISCELLANEOUS DEFINITIONS

(1) 000011 HT= 11 ;:CODE FOR HORIZONTAL TAB

(1) 000012 LF= 12 ;:CODE FOR LINE FEED

(1) 000015 CR= 15 ;:CODE FOR CARRIAGE RETURN

(1) 000200 CRLF= 200 ;:CODE FOR CARRIAGE RETURN-LINE FEED

(1) 177776 PS= 177776 ;:PROCESSOR STATUS WORD

(1) .EQUIV PS,PSW

(1) 177774 STKLMT= 177774 ;:STACK LIMIT REGISTER

(1) 177772 PIRO= 177772 ;:PROGRAM INTERRUPT REQUEST REGISTER

(1) 177570 DSWR= 177570 ;:HARDWARE SWITCH REGISTER

(1) 177570 DDISP= 177570 ;:HARDWARE DISPLAY REGISTER

(1) :*GENERAL PURPOSE REGISTER DEFINITIONS

(1) 000000 R0= %0 ;:GENERAL REGISTER

(1) 000001 R1= %1 ;:GENERAL REGISTER

(1) 000002 R2= %2 ;:GENERAL REGISTER

(1) 000003 R3= %3 ;:GENERAL REGISTER

(1) 000004 R4= %4 ;:GENERAL REGISTER

(1) 000005 R5= %5 ;:GENERAL REGISTER

(1) 000006 R6= %6 ;:GENERAL REGISTER

(1) 000007 R7= %7 ;:GENERAL REGISTER

(1) 000006 SP= %6 ;:STACK POINTER

(1) 000007 PC= #7 ;;PROGRAM COUNTER
(1)
(1) ;*PRIORITY LEVEL DEFINITIONS
(1) 000000 PR0= 0 ;:PRIORITY LEVEL 0
(1) 000040 PR1= 40 ;:PRIORITY LEVEL 1
(1) 000100 PR2= 100 ;:PRIORITY LEVEL 2
(1) 000140 PR3= 140 ;:PRIORITY LEVEL 3
(1) 000200 PR4= 200 ;:PRIORITY LEVEL 4
(1) 000240 PR5= 240 ;:PRIORITY LEVEL 5
(1) 000300 PR6= 300 ;:PRIORITY LEVEL 6
(1) 000340 PR7= 340 ;:PRIORITY LEVEL 7
(1)
(1) ;*''SWITCH REGISTER'' SWITCH DEFINITIONS
(1) 100000 SW15= 100000
(1) 040000 SW14= 40000
(1) 020000 SW13= 20000
(1) 010000 SW12= 10000
(1) 004000 SW11= 4000
(1) 002000 SW10= 2000
(1) 001000 SW09= 1000
(1) 000400 SW08= 400
(1) 000200 SW07= 200
(1) 000100 SW06= 100
(1) 000040 SW05= 40
(1) 000020 SW04= 20
(1) 000010 SW03= 10
(1) 000004 SW02= 4
(1) 000002 SW01= 2
(1) 000001 SW00= 1
(1) .EQUIV SW09,SW9
(1) .EQUIV SW08,SW8
(1) .EQUIV SW07,SW7
(1) .EQUIV SW06,SW6
(1) .EQUIV SW05,SW5
(1) .EQUIV SW04,SW4
(1) .EQUIV SW03,SW3
(1) .EQUIV SW02,SW2
(1) .EQUIV SW01,SW1
(1) .EQUIV SW00,SW0
(1)
(1) ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
(1) 100000 BIT15= 100000
(1) 040000 BIT14= 40000
(1) 020000 BIT13= 20000
(1) 010000 BIT12= 10000
(1) 004000 BIT11= 4000
(1) 002000 BIT10= 2000
(1) 001000 BIT09= 1000
(1) 000400 BIT08= 400
(1) 000200 BIT07= 200
(1) 000100 BIT06= 100
(1) 000040 BIT05= 40
(1) 000020 BIT04= 20
(1) 000010 BIT03= 10
(1) 000004 BIT02= 4
(1) 000002 BIT01= 2

(1) 000001 BIT00= 1
(1) .EQUIV BIT09,BIT9
(1) .EQUIV BIT08,BIT8
(1) .EQUIV BIT07,BIT7
(1) .EQUIV BIT06,BIT6
(1) .EQUIV BIT05,BIT5
(*) .EQUIV BIT04,BIT4
(1) .EQUIV BIT03,BIT3
(1) .EQUIV BIT02,BIT2
(1) .EQUIV BIT01,BIT1
(1) .EQUIV BIT00,BIT0

(1) ;*BASIC "CPU" TRAP VECTOR ADDRESSES
(1) 000004 ERRVEC= 4 ; TIME OUT AND OTHER ERRORS
(1) 000010 RESVEC= 10 ; RESERVED AND ILLEGAL INSTRUCTIONS
(1) 000014 TBITVEC=14 ; 'T' BIT
(1) 000014 TRTVEC= 14 ; TRACE TRAP
(1) 000014 BPTVEC= 14 ; BREAKPOINT TRAP (BPT)
(1) 000020 IOTVEC= 20 ; INPUT/OUTPUT TRAP (IOT) **SCOPE**
(1) 000024 PWRVEC= 24 ; POWER FAIL
(1) 000030 EMTVEC= 30 ; EMULATOR TRAP (EMT) **ERROR**
(1) 000034 TRAPVEC=34 ; "TRAP" TRAP
(1) 000060 TKVEC= 60 ; TTY KEYBOARD VECTOR
(1) 000064 TPVEC= 64 ; TTY PRINTER VECTOR
(1) 000240 PIRQVEC=240 ; PROGRAM INTERRUPT REQUEST VECTOR

6187
6188
6189 .SBttl MEMORY MANAGEMENT DEFINITIONS
(1)
(1) ;*KT11 VEC > ADDRESS
(1) 000250 MMVEC= 250
(1) ;*KT11 STATUS REGISTER ADDRESSES
(1)
(1) 177572 SR0= 177572
(1) 177574 SR1= 177574
(1) 177576 SR2= 177576
(1) 172516 SR3= 172516
(1) ;*KERNEL "I" PAGE DESCRIPTOR REGISTERS
(1)
(1) 172300 KIPDR0= 172300
(1) 172302 KIPDR1= 172302
(1) 172304 KIPDR2= 172304
(1) 172306 KIPDR3= 172306
(1) 172310 KIPDR4= 172310
(1) 172312 KIPDR5= 172312
(1) 172314 KIPDR6= 172314
(1) 172316 KIPDR7= 172316
(1) ;*KERNEL "I" PAGE ADDRESS REGISTERS
(1)
(1) 172340 KIPAR0= 172340
(1) 172342 KIPAR1= 172342
(1) 172344 KIPAR2 172344

(1) 172346 KIPAR3= 172346
(1) 172350 KIPAR4= 172350
(1) 172352 KIPAR5= 172352
(1) 172354 KIPAR6= 172354
(*) 172356 KIPAR7= 172356

6190 000000 UP = 0 :CODE FOR UPWARDS MAP IN MEM MGMT PDR'S
6191 000006 RW = 6 :CODE FOR READ/WRITE IN MEM MGMT PDR'S
6192
6193 :* PARITY MEMORY DEFINITIONS.
6194 000001 AE=1 :PARITY ACTION ENABLE
6195 000114 PARVEC=114 :PARITY TRAP VECTOR
6196
6197 :* MISCELLANEOUS ASSIGNMENTS
6198 017777 MASK4K= 17777 :MASK FOR 4K ADDRESS BANK BOUNDARY.
6199
6200 :* CACHE REGISTER DEFINITIONS.
6201 177746 IMPCHF= 177746
6202
6204 .SBTTL TRAP CATCHER
(1)
(1) 000000 =0 :*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
(1)
(1)
(1)
(1) 000174 000000 :SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
(1) 000176 000000 :LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
.=174
DISPREG: .WORD 0 ;SOFTWARE DISPLAY REGISTER
SWREG: .WORD 0 ;SOFTWARE SWITCH REGISTER
.SBTTL STARTING ADDRESS(ES)
(1) 000200 000137 002650 JMP @START ;JUMP TO STARTING ADDRESS OF PROGRAM
6205 000204 000167 002446 JMP SELECT ;STARTING ADDRESS TO ALLOW THE OPERATOR TO
6206
6207 000210 000167 000064 JMP RESTAR ;SELECT VARIOUS PARAMETERS.
6208 000214 000167 000064 JMP RESTOR ;RESTART ADDRESS, USING PREVIOUS PARAMETERS.
6209 000220 000167 003406 JMP TIMEOUT ;RESTORE LOADERS TO END OF MEMORY AND HALT.
6210
6211 000004 025124 .=ERRVEC
6212 000004 025124 .WORD ERRTRP
6213 000006 000000 .WORD 0
6214
6215 .SBTTL ACT11 HOOKS
(1)
(2)
(1) :*****
;HOOKS REQUIRED BY ACT11
(1) 000010 \$SVP= .SAVE PC
(1) 000046 .=46
(1) 000046 014232 SENDAD ;1)SET LOC.46 TO ADDRESS OF SENDAD IN .SEOP
(1) 000052 000052 .=52
(1) 000052 040000 .WORD BIT14 ;2)SET LOC.52 TO BIT14
(1) 000010 -\$SVP= ;RESTORE PC

6217 000300 .=300
 6218
 6219 :* THE FOLLOWING ROUTINES ARE LOCATED IN THE VECTOR AREA (0-1000) SO THAT
 6220 :* THEY CAN BE PROTECTED BY SELECTING SW05 (SEE DOCUMENT FOR USE OF SW05).
 6221 :* THE CODE CAN ALSO BE RUN FROM ANY BANK OF MEMORY, ASSUMING MEMORY
 6222 :* MANAGEMENT IS DISABLED BY 'CONSOLE START'.
 6223
 6224 000300 005005 RESTAR: CLR R5 ;CLEAR FLAG TO INDICATE RESTART.
 6225 000302 000401 BR REST1 ;GO RESTORE PROGRAM BEFORE RESTARTING.
 6226 000304 010705 RESTOR: MOV PC, R5 ;PUT DATA INTO FLAG FOR RESTORE.
 6227 000306 012706 001100 REST1: MOV #STACK, SP ;SET UP THE STACK POINTER.
 6228 000312 005767 001206 TST MEMMAP ;CHECK IF THE MEMORY HAS BEEN MAPPED.
 6229 000316 001002 BNE REST2 ;BR IF MEMORY MAPPED.
 6230 000320 000167 002340 JMP STARTA ;GO START
 6231 000324 005767 000256 REST2: TST MMAVA ;CHECK IF MEM MGMT AVAILABLE.
 6232 000330 001470 BEQ 10\$;BR IF NO MEM MGMT.
 6233 000332 032737 000001 177572 BIT #BIT0, @#SRO ;CHECK IF MEM MGMT ACTIVE.
 6234 000340 001034 BNE 2\$;BR IF MEM MGMT ALREADY SET UP.
 6235 000342 012700 172300 MOV #KIPDRO, R0 ;POINT TO FIRST MEM MGMT DDATA REG.
 6236 000346 012701 000010 MOV #8, R1 ;SET UP COUNTER.
 6237 000352 012720 077406 1\$: MOV #077406, (R0)+ ;MAP FIRST 28K 1-FOR-1.
 6238 000356 005301 DEC R1 ;COUNT REGESTERS.
 6239 000360 001374 BNE 1\$;BR IF MORE REG.
 6240 000362 012700 172340 MOV #KIPAR0, R0 ;POINT TO FIRST MEM MGMT ADDRESS REG.
 6241 000366 005020 CLR (R0)+ ;PAR0 MAPPED INTO BANK0.
 6242 000370 012720 000200 MOV #200, (R0)+ ;PAR1 MAPPED INTO BANK1.
 6243 000374 012720 000400 MOV #400, (R0)+ ;PAR2 MAPPED INTO BANK2.
 6244 000400 012720 000600 MOV #600, (R0)+ ;PAR3 MAPPED INTO BANK3.
 6245 000404 012720 001000 MOV #1000, (R0)+ ;PAR4 MAPPED INTO BANK4.
 6246 000410 012720 001200 MOV #1200, (R0)+ ;PAR5 MAPPED INTO BANK5.
 6247 000414 012720 001400 MOV #1400, (R0)+ ;PAR6 MAPPED INTO BANK6.
 6248 000420 012720 007600 MOV #7600, (R0)+ ;PAR7 MAPPED INTO BANK37.
 6249 000424 012737 000001 177572 MOV #BIT0, @#SRO ;ENABLE MEM MGMT.
 6250 000432 005000 2\$: CLR R0 ;INIT TEMP PAR REG.
 6251 000434 016701 000142 MOV PRGMAP, R1 ;GET THE PROGRAM MAP...LO 64K.
 6252 000440 016702 000140 MOV PRGMAP+2, R2 ;...HI 64K.
 6253 000444 006202 3\$: ASR R2 ;SHIFT THE MAP POINTER...HI
 6254 000446 006001 ROR R1 ;...LO.
 6255 000450 103404 BCS 4\$;BR WHEN FIRST BANK FOUND.
 6256 000452 062700 000200 ADD #200, R0 ;UPDATE TMP PAR TO NEXT BANK.
 6257 000456 100372 BPL 3\$;BR IF MORE.
 6258 000460 000000 HALT ;FATAL ERROR!!! MAP EMPTY?
 6259 000462 010037 172340 4\$: MOV R0, @#KIPAR0 ;PUT TEMP PAR INTO FIRST PAR.
 6260 000466 000137 000472 JMP @#5\$;JUMP INTO PROGRAM IF NOT THERE ALREADY.
 6261 000472 062700 000200 5\$: ADD #200, R0 ;KEEP UPDATING TEMP PAR REG.
 6262 000476 006202 ASR R2 ;SHIFT POINTER...HI
 6263 000500 006001 ROR R1 ;...LO
 6264 000502 103373 BCC 5\$;BR IF TOP BANK NOT YET FOUND.
 6265 000504 010037 172342 MOV R0, @#KIPAR1 ;SET UP SECOND PROGRAM ANK POINTER.
 6266 000510 000410 BR 20\$;BR TO RELOCATE SECTION.
 6267 000512 016700 000062 10\$: MOV RELOCF, R0 ;GET RELOCATION FACTOR.
 6268 000516 062700 001100 ADD #STACK, R0 ;SET UP STACK POINTER.
 6269 000522 010006 MOV R0, SP ;SET STACK TO RELOCATE PROGRAM.
 6270 000524 062700 177432 ADD #20\$-STACK, R0 ;ADJUST R0 TO RELOCATED '20\$' ADDRESS.
 6271 000530 000110 JMP (R0) ;GO TO '20\$' (RELOCATED).
 6272 000532 022767 000003 000042 20\$: CMP #3, PRGMAP ;CHECK IF PROGRAM IS IN BANKS 0 AND 1.

CZOMCG0 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) J 2
CZOMCG.P11 12-MAR-80 13:07 ACT11 HOOKS 12-MAR-80 13:10 PAGE 59-5

SEQ 0022

6273 000540 001402
6274 000542 004767 016324
6275 000546 005705
6276 000550 001006
6277 000552 005067 000412
6278 000556 105067 000320
6279 000562 000167 005326
6280 000566 004767 016506
6281 000572 000000
6282 000574 000167 002064
6283
6284
6285
6286 000600 000000
6287 000602 000000 000000
6288 000606 000000

21\$: BEQ 21\$;BR IF IN BANKS 0 AND 1.
JSR PC, RELO ;RELOCATE THE PROGRAM BACK TO BANKS 0 AND 1.
TST R5 ;CHECK RESTART/RESTORE FLAG.
BNE 22\$;BR IF RESTORE.
CLR \$TIMES ;CLEAN UP BEFORE STARTING.
CLRB \$STSTNM
JMP START1 ;RESTART WITH PREVIOUSLY SELECTED PARAMETERS.
22\$: JSR PC, RESLDR ;RESTORE THE LOADERS TO THE 'TOP' OF MEMORY.
HALT ;HALT AFTER RESTORING THE LOADERS.
JMP STARTA ;CONTINUE WILL RESTART THE PROGRAM.
/* THE FOLLOWING LOCATIONS ARE USED BY THE ABOVE ROUTINE AND MUST BE LOCATED
/* BELOW 1000 TO INSURE CORRECT OPERATION UNDER THE WIDEST VARIETY OF
/* CIRCUMSTANCES.
RELOCF: .WORD 0 ;CONTAINS RELOCATION FACTOR (NO MEM MGMT)
PRGMAP: .WORD 0,0 ;PROGRAM MAP - WHERE THE PROGRAM IS LOCATED
MMAVA: .WORD 0 ;MEMORY MANAGEMENT AVAILABLE FLAG.

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) K 2
CZOMCG.P11 12-MAR-80 13:07 POWER DOWN AND UP ROUTINES 12-MAR-80 13:10 PAGE 59-6

SEQ 0023

6290

.SBTTL POWER DOWN AND UP ROUTINES

(1)
(2)
(1) :*****
(1) :POWER DOWN ROUTINE
(1) 000610 012737 000756 000024 \$PWRDN: MOV #\$ILLUP,&PWRVEC ;SET FOR FAST UP
(1) 000616 012737 000340 000026 MOV #340,&PWRVEC+2 ;PRIO:7
(3) 000624 010046 MOV R0,-(SP) ;PUSH R0 ON STACK
(3) 000626 010146 MOV R1,-(SP) ;PUSH R1 ON STACK
(3) 000630 010246 MOV R2,-(SP) ;PUSH R2 ON STACK
(3) 000632 010346 MOV R3,-(SP) ;PUSH R3 ON STACK
(3) 000634 010446 MOV R4,-(SP) ;PUSH R4 ON STACK
(3) 000636 010546 MOV R5,-(SP) ;PUSH R5 ON STACK
(3) 000640 017746 000274 MOV @SWR,-(SP) ;PUSH @SWR ON STACK
(1) 000644 010667 000112 MOV SP,\$SAVR6 ;SAVE SP
(1) 000650 012737 000662 000024 MOV #SPWRUP,&PWRVEC ;SET UP VECTOR
(1) 000656 000000 HALT
(1) 000660 000776 BR .-2 ;HANG UP
(1)
(2) :*****
(1) :POWER UP ROUTINE
(1) 000662 012737 000756 000024 \$PWRUP: MOV #\$ILLUP,&PWRVEC ;SET FOR FAST DOWN
(1) 000670 016706 000066 MOV \$SAVR6,SP ;GET SP
(1) 000674 005067 000062 CLR \$SAVR6 ;WAIT LOOP FOR THE TTY
(1) 000700 005267 000056 1\$: INC \$SAVR6 ;WAIT FOR THE INC
(1) 000704 001375 BNE 1\$ OF WORD
(3) 000706 012677 000226 MOV (SP)+,@SWR ;POP STACK INTO @SWR
(3) 000712 012605 MOV (SP)+,R5 ;POP STACK INTO R5
(3) 000714 012604 MOV (SP)+,R4 ;POP STACK INTO R4
(3) 000716 012603 MOV (SP)+,R3 ;POP STACK INTO R3
(3) 000720 012602 MOV (SP)+,R2 ;POP STACK INTO R2
(3) 000722 012601 MOV (SP)+,R1 ;POP STACK INTO R1
(3) 000724 012600 MOV (SP)+,R0 ;POP STACK INTO R0
(1) 000726 012737 000610 000024 MOV #SPWRDN,&PWRVEC ;SET UP THE POWER DOWN VECTOR
(1) 000734 012737 000340 000026 MOV #340,&PWRVEC+2 ;PRIO:7
(2) 000742 004567 022554 JSR R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
(1) 000746 025651 SPWRMG: WORD PWRMSG ;POWER FAIL MESSAGE POINTER
(1) 000750 012716 MOV (PC)+,(SP) ;RESTART AT RESTART
(1) 000752 000300 SPWRAD: WORD RESTART ;RESTART ADDRESS
(1) 000754 000002 RTI
(1) 000756 000000 \$ILLUP: HALT ;THE POWER UP SEQUENCE WAS STARTED
(1) 000760 000776 BR .-2 ;BEFORE THE POWER DOWN WAS COMPLETE
(1) 000762 000000 \$SAVR6: 0 ;PUT THE SP HERE

(2) 001212 000000 \$PASS: .WORD APASS :: PASS COUNT
 (2) 001214 000000 \$DEVCT: .WORD ADEVCT :: DEVICE COUNT
 (2) 001216 000000 \$UNIT: .WORD AUNIT :: I/O UNIT NUMBER
 (2) 001220 000000 \$MSGAD: .WORD AMSGAD :: MESSAGE ADDRESS
 (2) 001222 000000 \$MSGLG: .WORD AMSGLG :: MESSAGE LENGTH
 (2) 001224 SETABLE: .WORD :: APT ENVIRONMENT TABLE
 (2) 001224 000 SENV: .BYTE AENV :: ENVIRONMENT BYTE
 (2) 001225 000 SENVM: .BYTE AENVM :: ENVIRONMENT MODE BITS
 (2) 001226 000000 \$SWREG: .WORD ASWREG :: APT SWITCH REGISTER
 (2) 001230 000000 \$USR: .WORD AUSR :: USER SWITCHES
 (2) 001232 000000 \$CPUOP: .WORD ACPUOP :: CPU TYPE,OPTIONS
 (2) * BITS 15-11=CPU TYPE
 (2) * 11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
 (2) * 11/70=06,PDQ=07,Q=10
 (2) * BIT 10=REAL TIME CLOCK
 (2) * BIT 9=FLOATING POINT PROCESSOR
 (2) * BIT 8=MEMORY MANAGEMENT
 (2) 001234 000 SMAMS1: .BYTE AMAMS1 :: HIGH ADDRESS,M.S. BYTE
 (2) 001235 000 SMTYP1: .BYTE AMTYP1 :: MEM. TYPE,BLK#1
 (2) * MEM. TYPE BYTE -- (HIGH BYTE)
 (2) * 900 NSEC CORE=001
 (2) * 300 NSEC BIPOLAR=002
 (2) * 500 NSEC MOS=003
 (2) 001236 000000 SMADR1: .WORD AMADR1 :: HIGH ADDRESS,BLK#1
 (2) * MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABOVE
 (2) 001240 000 SMAMS2: .BYTE AMAMS2 :: HIGH ADDRESS,M.S. BYTE
 (2) 001241 000 SMTYP2: .BYTE AMTYP2 :: MEM. TYPE,BLK#2
 (2) 001242 000000 SMADR2: .WORD AMADR2 :: MEM.LAST ADDRESS,BLK#2
 (2) 001244 000 SMAMS3: .BYTE AMAMS3 :: HIGH ADDRESS,M.S.BYTE
 (2) 001245 000 SMTYP3: .BYTE AMTYP3 :: MEM. TYPE,BLK#3
 (2) 001246 000000 SMADR3: .WORD AMADR3 :: MEM.LAST ADDRESS,BLK#3
 (2) 001250 000 SMAMS4: .BYTE AMAMS4 :: HIGH ADDRESS,M.S.BYTE
 (2) 001251 000 SMTYP4: .BYTE AMTYP4 :: MEM. TYPE,BLK#4
 (2) 001252 000000 SMADR4: .WORD AMADR4 :: MEM.LAST ADDRESS,BLK#4
 (2) 001254 000000 SVECT1: .WORD AVECT1 :: INTERRUPT VECTOR#1,BUS PRIORITY#1
 (2) 001256 000000 SVECT2: .WORD AVECT2 :: INTERRUPT VECTOR#2,BUS PRIORITY#2
 (2) 001260 000000 SBASE: .WORD ABASE :: BASE ADDRESS OF EQUIPMENT UNDER TEST
 (2) 001262 000000 SDEVM: .WORD ADEVM :: DEVICE MAP
 (2) 001264 000000 SCDW1: .WORD ACDW1 :: CONTROLLER DESCRIPTION WORD#1
 (2) 001266 000000 SCDW2: .WORD ACDW2 :: CONTROLLER DESCRIPTION WORD#2
 (2) 001270 000000 SDDW0: .WORD ADDW0 :: DEVICE DESCRIPTOR WORD#0
 (2) 001272 000000 SDDW1: .WORD ADDW1 :: DEVICE DESCRIPTOR WORD#1
 (2) 001274 000000 SDDW2: .WORD ADDW2 :: DEVICE DESCRIPTOR WORD#2
 (2) 001276 000000 SDDW3: .WORD ADDW3 :: DEVICE DESCRIPTOR WORD#3
 (2) 001300 000000 SDDW4: .WORD ADDW4 :: DEVICE DESCRIPTOR WORD#4
 (2) 001302 000000 SDDW5: .WORD ADDW5 :: DEVICE DESCRIPTOR WORD#5
 (2) 001304 000000 SDDW6: .WORD ADDW6 :: DEVICE DESCRIPTOR WORD#6
 (2) 001306 000000 SDDW7: .WORD ADDW7 :: DEVICE DESCRIPTOR WORD#7
 (2) 001310 000000 SDDW8: .WORD ADDW8 :: DEVICE DESCRIPTOR WORD#8
 (2) 001312 000000 SDDW9: .WORD ADDW9 :: DEVICE DESCRIPTOR WORD#9
 (2) 001314 000000 SDDW10: .WORD ADDW10 :: DEVICE DESCRIPTOR WORD#10
 (2) 001316 000000 SDDW11: .WORD ADDW11 :: DEVICE DESCRIPTOR WORD#11
 (2) 001320 000000 SDDW12: .WORD ADDW12 :: DEVICE DESCRIPTOR WORD#12
 (2) 001322 000000 SDDW13: .WORD ADDW13 :: DEVICE DESCRIPTOR WORD#13
 (2) 001324 000000 SDDW14: .WORD ADDW14 :: DEVICE DESCRIPTOR WORD#14
 (2) 001326 000000 SDDW15: .WORD ADDW15 :: DEVICE DESCRIPTOR WORD#15

(4) ;*****
 (3) ;* THE FOLLOWING TAGS ARE USER DEFINED
 (4) ;*****

(3) 001514 000000 \$VERPC: .WORD 0 ;VIRTUAL PC LOCATION FOR ERROR TIMEOUT ROUTINE (\$ERTYP).
 (3) 001516 070032 RESRVD: .WORD 070032 ;CORE PARITY REG BITS RESERVED FOR FUTURE USE.
 (3) ;NOTE: FOR MS11 MEMORY WITH PARITY, CHANGE TO 077772.

(3) 001520 000000 LMAD: .WORD 0 ;LAST CONTIGUOUS MEMORY ADDRESS (+2)
 (3) 001522 000000 LDDISP: .WORD 0 ;CONTAINS DISPLAY REGISTER IMAGE
 (3) 001524 MEMMAP: .WORD 0 ;MEMORY MAP - EACH BIT CORRESPONDS TO 4K
 (3) 001524 000000 .WORD 0 ;FIRST WORD CONTAINS LOW (0-64K) MAP
 (3) 001526 000000 .WORD 0 ;SECOND WORD CONTAINS HIGH (64-128K) MAP
 (3) 001530 TSTMAP: .WORD 0 ;TEST MAP - WHICH BANKS ARE SELECTED FOR TEST.
 (3) 001530 000000 .WORD 0 ;FIRST WORD CONTAINS LOW (0-64K) MAP
 (3) 001532 000000 .WORD 0 ;SECOND WORD CONTAINS HIGH (64-128K) MAP
 (3) 001534 SAVTST: .WORD 0 ;SAVED TEST MAP - USED DURING FIRST PASS TO ONLY
 (3) ; TEST EACH BANK ONCE.
 (3) 001534 000000 .WORD 0 ;FIRST WORD CONTAINS LOW (0-64K) MAP
 (3) 001536 000000 .WORD 0 ;SECOND WORD CONTAINS HIGH (64-128K) MAP
 (3) 001540 PMEMAP: .WORD 0 ;PARITY MAP - WHICH BANKS HAVE MEMORY PARITY
 (3) 001540 000000 .WORD 0 ;FIRST WORD CONTAINS LOW (0-64K) MAP
 (3) 001542 000000 .WORD 0 ;SECOND WORD CONTAINS HIGH (64-128K) MAP
 (3) 001544 BITPT: .WORD 0 ;pointer to current 4K bank of memory
 (3) 001544 000000 .WORD 0 ;FIRST WORD CONTAINS LOW (0-64K) MAP
 (3) 001546 000000 .WORD 0 ;SECOND WORD CONTAINS HIGH (64-128K) MAP
 (3) 001550 TMPPT: .WORD 0 ;TEMPORARY POINTER FOR 2ND 4K BANK OF MEMORY
 (3) 001550 000000 .WORD 0 ;FIRST WORD CONTAINS LOW (0-64K) MAP
 (3) 001552 000000 .WORD 0 ;SECOND WORD CONTAINS HIGH (64-128K) MAP
 (3) 001554 MMORE: .WORD 0 ;LOOP ADDRESS FOR MULTIPLE BLOCK TESTING.
 (3) ;SET UP BY 'INITMM' AND 'INITDN' ROUTINES.
 (3) ;USED BY 'MMUP' AND 'MMDOWN' ROUTINES.
 (3) 001556 000 SELFLG: .BYTE 0 ;OPERATOR SELECTED PARAMETERS FLAG. (SA=204)
 (3) 001557 000 FLAG8K: .BYTE 0 ;8K BLOCK INDICATOR. USED IN 'INITMM' AND 'MMUP'.
 (3) 001560 000 OEFLG: .BYTE 0 ;ODD/EVEN FLAG USED IN PARITY MEMORY BYTE TEST.
 (3) 001562 001562 FSTADR: .WORD 0 ;FIRST VIRTUAL ADDRESS TO BE TESTED.
 (3) ;FIRST ADDRESS IS USER SELECTABLE.
 (3) 001564 000000 TMPFAD: .WORD 0 ;ADJUSTED FIRST ADDRESS.
 (3) 001566 000000 FADMSK: .WORD 0 ;BIT MASK TO ALLOW DOWNWARD ADDRESSING TESTS
 (3) ;TO BREAK TO 'MMDOWN' TO FIND FIRST ADDRESS.
 (3) 001570 000000 000000 FADMAP: .WORD 0,0 ;MAP OF BANK IN WHICH FIRST ADDRESS IS LOCATED.
 (3) 001574 000000 LSTADR: .WORD 0 ;LAST VIRTUAL ADDRESS (+2) TO BE TESTED.
 (3) ;LAST ADDRESS IS USER SELECTABLE.
 (3) 001576 000000 TMPLAD: .WORD 0 ;ADJUSTED LAST ADDRESS.
 (3) 001600 000000 LADMSK: .WORD 0 ;BIT MASK TO ALLOW UPWARD ADDRESSING TESTS
 (3) ;TO BREAK TO 'MMUP' TO FIND LAST ADDRESS.
 (3) 001602 000000 000000 LADMAP: .WORD 0,0 ;MAP OF BANK IN WHICH LAST ADDRESS IS LOCATED.
 (3) 001606 000000 BLKMSK: .WORD 0 ;BLOCK MASK, DETERMINES THE BLOCK SIZE.
 (3) 001610 000000 .CONST: .WORD 0 ;USER SELECTABLE CONSTANT DATA.
 (3) 001612 000004 WWP: .WORD 4 ;WRITE WRONG PARITY COMMAND
 (3) 001614 000000 TEMP: .WORD 0 ;TEMPORARY STORAGE
 (3) 001616 000000 CASFLG: .WORD 0 ;CACHE PRESENT FLAG
 (3) 001620 177746 CASREG: .WORD 177746 ;CACHE CONTROL REGISTER
 (3) ;*****
 (4) ;* RELATIVE ADDRESSING TABLE.
 (3) ;* THE FOLLOWING LOCATIONS ARE MODIFIED AT RELOCATION TIME TO ALLOW

(3) ;* RELATIVE ADDRESSING TO GET THE RELOCATED VALUE OF THE ARGUMENT TAGS.
(4)
(3) 001622 001100
RADTAB:
(3) 001622 001100 .STACK: STACK ;STACK POINTER INITIAL ADDRESS.
(3) 001624 001516 .RESRV: RESRVD ;PARITY REGISTER RESERVED BIT MASK ADDRESS.
(3) 001626 002076 .MPRO: MPRO ;MEMORY PARITY REGISTER TABLE ADDRESS.
(3) 001630 002276 .MPRX: MPRX ;MEMORY PARITY REGISTER EXIST TABLE ADDRESS.
(3) 001632 012062 .PBTRP: PBTRP ;PARITY BYTE TEST TRAP ROUTINE ADDRESS.
(3) 001634 002050 .MPPAT: MPPATS ;MEMORY PARITY PATTERN TABLE ADDRESS.
(3) 001636 017440 .PESRV: PESRV ;MEMORY PARITY ERROR TRAP ROUTINE ADDRESS.
(3) 001640 002340 .ERRTB: SERRTB ;ERROR TIMEOUT TABLE PONTER.
(3) 001642 000010 .EIGHT: 8 ;DECIMAL TYPE ROUTINE COUNT DESIGNATOR.
(3) 001644 014014 .TST32: TST32 ;SCOPE ABORT ADR FOR WHEN NO MEM AVA FOR TEST.
(4)
(3) ;* DATA CONTAINERS FOR ERROR PRINTOUT.
(4)
(3) 001646 001116 001120 001124 DT1: \$ERRPC,\$GDADR,\$GDDAT,\$BDDAT,0
(3) 001654 001126 000000
(3) 001660 001514 001116 001120 DT2: \$VERPC,\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT,0
(3) 001666 001124 001126 000000
(3) 001674 001514 001116 001120 DT12: \$VERPC,\$ERRPC,\$GDADR,\$GDDAT,0
(3) 001702 001124 000000
(3) 001706 001514 001116 001160 DT14: \$VERPC,\$ERRPC,\$TMP0,\$GDADR,0
(3) 001714 001120 000000
(3) 001720 001514 001116 001120 DT15: \$VERPC,\$ERRPC,\$GDADR,\$TMP0,\$GDDAT,\$BDDAT,0
(3) 001726 001160 001124 001126
(3) 001734 000000
(3) 001736 001514 001116 001160 DT21: \$VERPC,\$ERRPC,\$TMP0,\$GDADR,\$GDDAT,\$BDDAT,0
(3) 001744 001120 001124 001126
(3) 001752 000000
(3) 001754 001514 001116 001120 DT23: \$VERPC,\$ERRPC,\$GDADR,\$BDADR,\$GDDAT,\$BDDAT,0
(3) 001762 001122 001124 001126
(3) 001770 000000
(3) 001772 001514 001116 001122 DT24: \$VERPC,\$ERRPC,\$BDADR,0
(3) 002000 000000
(3) 002002 001514 001116 001122 DT25: \$VERPC,\$ERRPC,\$BDADR,\$TMP0,\$TMP1,0
(3) 002010 001160 001162 000000
(3) 002016 001514 001116 001160 DT26: \$VERPC,\$ERRPC,\$TMP0,\$TMP1,0
(3) 002024 001162 000000
(3) 002030 001160 001162 001120 DT30: \$TMP0,\$TMP1,\$GDADR,\$BDDAT,0
(3) 002036 001126 000000
(3) 002042 001166 000000 DT31: \$TMP3,0
(3) 002046 177777 .WORD -1 ;TABLE TERMINATOR.
(3)
(3) ;SBTTL MEMORY PARITY PATTERNS TABLE
(4)
(3) ;THE FOLLOWING ARE THE PARITY PATTERNS EXERCISED THRUOUT MEMORY
(4)
(3)
(3) 002050 125325 MPPATS: 125325 ;EVEN,ODD
(3) 002052 152652 152652 ;ODD,EVEN
(3) 002054 052452 052452 ;EVEN,ODD
(3) 002056 025125 025125 ;ODD,EVEN
(3) 002060 102070 102070 ;EVEN,EVEN
(3) 002062 072527 072527 ;ODD,ODD
(3) 002064 177777 177777 ;EVEN,EVEN

(3) 002066	107030	107030	:ODD,ODD
(3) 002070	152525	152525	:ODD,EVEN
(3) 002072	000000	0	:EXTRA PATTERN HOLDER FOR
(3)			:FUTURE USE
(3) 002074	000000	MPEND: 0	:TABLE TERMINATOR
(3)			

SBTTL MEMORY PARITY REGISTER ADDRESS TABLE

|||||
 (3) * THE FOLLOWING REPRESENTS THE MEMORY PARITY REGISTER ADDRESS TABLE
 (3) * FROM WHICH PARITY MEMORY IS ADDRESSED & CONTROLLED:
 (3) *
 (3) * THE LEAST SIGNIFICANT BIT IN THE DEVICE ADDRESS IS SET TO A ONE (1)
 (3) * IF THE CONTROL IS FOUND NOT TO BE PRESENT. THE MEMORY PRESENT UNDER
 (3) * THE CONTROL OF EACH CONTROLLER IS REPRESENTED BY TWO (2) WORDS FOLLOWING
 (3) * THE DEVICE ADDRESS. EACH BIT REPRESENTING A 4K BLOCK. I.E.
 (3) * FIRST WORD BIT0 = 0 - 4K, BIT1 = 4 - 8K, ... BIT15 = 60 - 64K
 (3) * SECOND WORD BIT0 = 64 - 68K, ..., BIT14 = 120 - 124K.
 (4) |||||

(3) 002076	172101	MPRO: 172100 +1	;PARITY STATUS REGISTER
(3) 002100	000000	0	;CONTROL MAP (LOW 64K)
(3) 002102	000000	0	;CONTROL MAP (HIGH 64K)
(3) 002104	000000	0	;MASK FOR MOS,CORE,MS11-K
(3) 002106	172103	MPR1: 172102 +1	;PARITY STATUS REGISTER
(3) 002110	000000	0	;CONTROL MAP (LOW 64K)
(3) 002112	000000	0	;CONTROL MAP (HIGH 64K)
(3) 002114	000000	0	;MASK FOR MOS,CORE,MS11-K
(3) 002116	172105	MPR2: 172104 +1	;PARITY STATUS REGISTER
(3) 002120	000000	0	;CONTROL MAP (LOW 64K)
(3) 002122	000000	0	;CONTROL MAP (HIGH 64K)
(3) 002124	000000	0	;MASK FOR MOS,CORE,MS11-K
(3) 002126	172107	MPR3: 172106 +1	;PARITY STATUS REGISTER
(3) 002130	000000	0	;CONTROL MAP (LOW 64K)
(3) 002132	000000	0	;CONTROL MAP (HIGH 64K)
(3) 002134	000000	0	;MASK FOR MOS,CORE,MS11-K
(3) 002136	172111	MPR4: 172110 +1	;PARITY STATUS REGISTER
(3) 002140	000000	0	;CONTROL MAP (LOW 64K)
(3) 002142	000000	0	;CONTROL MAP (HIGH 64K)
(3) 002144	000000	0	;MASK FOR MOS,CORE,MS11-K
(3) 002146	172113	MPR5: 172112 +1	;PARITY STATUS REGISTER
(3) 002150	000000	0	;CONTROL MAP (LOW 64K)
(3) 002152	000000	0	;CONTROL MAP (HIGH 64K)
(3) 002154	000000	0	;MASK FOR MOS,CORE,MS11-K
(3) 002156	172115	MPR6: 172114 +1	;PARITY STATUS REGISTER
(3) 002160	000000	0	;CONTROL MAP (LOW 64K)
(3) 002162	000000	0	;CONTROL MAP (HIGH 64K)
(3) 002164	000000	0	;MASK FOR MOS,CORE,MS11-K
(3) 002166	172117	MPR7: 172116 +1	;PARITY STATUS REGISTER
(3) 002170	000000	0	;CONTROL MAP (LOW 64K)
(3) 002172	000000	0	;CONTROL MAP (HIGH 64K)
(3) 002174	000000	0	;MASK FOR MOS,CORE,MS11-K
(3) 002176	172121	MPR8: 172120 +1	;PARITY STATUS REGISTER
(3) 002200	000000	0	;CONTROL MAP (LOW 64K)
(3) 002202	000000	0	;CONTROL MAP (HIGH 64K)
(3) 002204	000000	0	;MASK FOR MOS,CORE,MS11-K
(3) 002206	172123	MPR9: 172122 +1	;PARITY STATUS REGISTER

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) E 3
CZOMCG.P11 12-MAR-80 13:07 MEMORY PARITY REGISTER ADDRESS TABLE

SEQ 0030

(3) 002210	000000	0	:CONTROL MAP (LOW 64K)
(3) 002212	000000	0	:CONTROL MAP (HIGH 64K)
(3) 002214	000000	0	:MASK FOR MOS,CORE,MS11-K
(3) 002216	172125	MPR10: 172124 +1	:PARITY STATUS REGISTER
(3) 002220	000000	0	:CONTROL MAP (LOW 64K)
(3) 002222	000000	0	:CONTROL MAP (HIGH 64K)
(3) 002224	000000	0	:MASK FOR MOS,CORE,MS11-K
(3) 002226	172127	MPR11: 172126 +1	:PARITY STATUS REGISTER
(3) 002230	000000	0	:CONTROL MAP (LOW 64K)
(3) 002232	000000	0	:CONTROL MAP (HIGH 64K)
(3) 002234	000000	0	:MASK FOR MOS,CORE,MS11-K
(3) 002236	172131	MPR12: 172130 +1	:PARITY STATUS REGISTER
(3) 002240	000000	0	:CONTROL MAP (LOW 64K)
(3) 002242	000000	0	:CONTROL MAP (HIGH 64K)
(3) 002244	000000	0	:MASK FOR MOS,CORE,MS11-K
(3) 002246	172133	MPR13: 172132 +1	:PARITY STATUS REGISTER
(3) 002250	000000	0	:CONTROL MAP (LOW 64K)
(3) 002252	000000	0	:CONTROL MAP (HIGH 64K)
(3) 002254	000000	0	:MASK FOR MOS,CORE,MS11-K
(3) 002256	172135	MPR14: 172134 +1	:PARITY STATUS REGISTER
(3) 002260	000000	0	:CONTROL MAP (LOW 64K)
(3) 002262	000000	0	:CONTROL MAP (HIGH 64K)
(3) 002264	000000	0	:MASK FOR MOS,CORE,MS11-K
(3) 002266	172137	MPR15: 172136 +1	:PARITY STATUS REGISTER
(3) 002270	000000	0	:CONTROL MAP (LOW 64K)
(3) 002272	000000	0	:CONTROL MAP (HIGH 64K)
(3) 002274	000000	0	:MASK FOR MOS,CORE,MS11-K
(3) 002276	000021	MPRX: .BLKW 17.	:THIS IS THE END OF THE TABLE ! :TABLE TO HOLD JUST PARITY STATUS REGISTERS THAT EXIST. :(THE EXTRA WORD IS FOR A TERMINATOR.)

ERROR POINTER TABLE

(1)

.SBTTL ERROR POINTER TABLE

(1)
 (1)
 (1) :* THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
 (1) :* THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
 (1) :* LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
 (1) :* NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
 (1) :* NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS

(1)	:* EM	::POINTS TO THE ERROR MESSAGE
(1)	:* DH	::POINTS TO THE DATA HEADER
(1)	:* DT	::POINTS TO THE DATA
(1)	:* DF	::POINTS TO THE DATA FORMAT

(1) 002340	\$ERRTB:		
6486 002340	CHGG1:		
6487	;* ITEM 1		
6488 002340 027020	DM1	:PARITY REGISTER DATA ERROR.	
6489 002342 030377	DH1	:PC,REG,S/B,WAS	
6490 002344 001646	DT1	:\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT	
6491 002346 030744	DF1	:16,18,16,16	
6492	;* ITEM 2		
6493 002350 027054	DM2	:ADDRESS TEST ERROR(TST1-5).	
6494 002352 030416	DH2	:V/PC,P/PC,MA,S/B,WAS	
6495	;* ITEM 3		
6496 002354 001660	DT2	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT	
6497 002356 030750	DF2	:16,18,18,16,16	
6498	;* ITEM 4		
6499 002360 027054	DM2	:ADDRESS TEST ERROR(TST1-5).	
6500 002362 030416	DH2	:V/PC,P/PC,MA,S/B,WAS	
6501 002364 001660	DT2	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT	
6502 002366 030755	DF3	:16,18,18,8,8	
6503	;* ITEM 5		
6504 002370 027110	DM4	:CONSTANT DATA ERROR(TST6-10).	
6505 002372 030416	DH2	:V/PC,P/PC,MA,S/B,WAS	
6506 002374 001660	DT2	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT	
6507 002376 030750	DF2	:16,18,18,16,16	
6508	;* ITEM 6		
6509 002400 027146	DM5	:ROTATING BIT ERROR(TST11-12).	
6510 002402 030416	DH2	:V/PC,P/PC,MA,S/B,WAS	
6511 002404 001660	DT2	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT	
6512 002406 030750	DF2	:16,18,18,16,16	
6513	;* ITEM 7		
6514 002410 027204	DM6	:MOS REFRESH TEST ERROR (TST30-31).	
6515 002412 030416	DH2	:V/PC,P/PC,MA,S/B,WAS	
6516 002414 001660	DT2	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT	
6517 002416 030750	DF2	:16,18,18,16,16	
6518	;* ITEM 8		
6519 002420 027250	DM7	:3 XOR 9 PATTERN ERROR(TST13-16).	
6520 002422 030416	DH2	:V/PC,P/PC,MA,S/B,WAS	
6521 002424 001660	DT2	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT	
6522 002426 030750	DF2	:16,18,18,16,16	
6523	;* ITEM 10		
6524 002430 027311	DM10	:MARCHING 1'S AND 0'S ERROR(TST27).	
6525 002432 030416	DH2	:V/PC,P/PC,MA,S/B,WAS	
6526 002434 001660	DT2	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT	

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER
CZOMCG.P11 12-MAR-80 13:07

MACY11 30A(1052)
ERROR POINTER TABLE

G 3
12-MAR-80 13:10 PAGE 59-15

SEQ 0032

6527	002436	030750	DF2	:16,18,18,16,16
6528			ITEM 11	
6529	002440	027355	DM11	:PARITY MEMORY ADDRESS ERROR(TST17).
6530	002442	030416	DH2	:V/PC,P/PC,MA,S/B,WAS
6531	002444	001660	DT2	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT
6532	002446	030755	DF3	:16,18,18,8,8
6533			ITEM 12	
6534	002450	027421	DM12	:DATIP WITH WRONG PARITY DIDN'T TRAP(TST17).
6535	002452	030443	DH12	:V/PC,P/PC,MA,S/B
6536	002454	001674	DT12	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT
6537	002456	030755	DF3	:16,18,18,8
6538			ITEM 13	
6539	002460	027475	DM13	:WRONG PARITY TRAPED, BUT NO REGISTER SHOWS ERROR FLAG.
6540	002462	030443	DH12	:V/PC,P/PC,MA,S/B
6541	002464	001674	DT12	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT
6542	002466	030755	DF3	:16,18,18,8
6543			ITEM 14	
6544	002470	027565	DM14	:PARITY REGISTER NOT MAPPED AS CONTROLLING THIS ADDRESS(TST17).
6545	002472	030464	DH14	:V/PC,P/PC,REG,MA
6546	002474	001706	DT14	:\$VERPC,\$ERRPC,\$TMPO,\$GDADR
6547				
6548	002476	030762	DF14	:16,18,18,18
6549			ITEM 15	
6550	002500	027020	DM1	:PARITY REGISTER DATA ERROR.
6551	002502	030505	DH15	:V/PC,P/PC,MAUT,REG,S/B,WAS
6552	002504	001720	DT15	:\$VERPC,\$ERRPC,\$GDADR,\$TMPO,\$GDDAT,\$BDDAT
6553	002506	030762	DF14	:16,18,18,18,16,16
6554			ITEM 16	
6555	002510	027664	DM16	:MORE THAN ONE REGISTER INDICATED PARITY ERROR.
6556	002512	030464	DH14	:V/PC,P/PC,REG,MA
6557	002514	001706	DT14	:\$VERPC,\$ERRPC,\$TMPO,\$GDADR
6558	002516	030762	DF14	:16,18,18,
6559			ITEM 17	
6560	002520	027743	DM17	:DATA SHOULDN'T HAVE CHANGED WHEN PARITY ERROR
6561				:TRAPPED(TST21).
6562	002522	030416	DH2	:V/PC,P/PC,MA,S/B,WAS
6563	002524	001660	DT2	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT
6564	002526	030755	DF3	:16,18,18,8,8
6565			ITEM 20	
6566	002530	030041	DM20	:RANDOM DATA ERROR(TST20).
6567	002532	030416	DH2	:V/PC,P/PC,MA,S/B,WAS
6568	002534	001660	DT2	:\$VERPC,\$ERRPC,\$GDADR,\$GDDAT,\$BDDAT
6569	002536	030750	DF2	:16,18,18,16,16
6570			ITEM 21	
6571	002540	030073	DM21	:INSTRUCTION EXECUTION ERROR(TST21-26).
6572	002542	030540	DH21	:V/PC,P/PC,IUT,MA,S/B,WAS
6573	002544	001736	DT21	:\$VERPC,\$ERRPC,\$TMPO,\$GDADR,\$GDDAT,\$BDDAT
6574	002546	030770	DF21	:16,18,16,18,16,16
6575			ITEM 22	
6576	002550	000000	O	:NOT USED
6577	002552	000000	O	:CHGG1
6578	002554	000000	O	
6579	002556	000000	O	
6580			ITEM 23	
6581	002560	030142	DM23	:PROGRAM CODE CHANGED WHEN RELOCATED.
6582	002562	030571	DH23	:V/PC,P/PC,SRC MA,DST MA,S/B,WAS

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER
CZOMCG.P11 12-MAR-80 13:07

H 3
MAC(Y11 30A(1052)) 12-MAR-80 13:10 PAGE 59-16
ERROR POINTER TABLE

EQ 0033

6583 002564 001754 DT23 :\$VERPC,\$ERRPC,\$GDADR,\$BDADR,\$GDDAT,\$BDDAT
6584 002566 030762 DF14 ;16,18,18,18,16,16
6585 :* ITEM 24
6586 002570 030207 DM24 ;TRAPPED, BUT NO REGISTER HAD ERROR BIT SET.
6587 002572 030631 DH24 ;V/PC,P/PC,TRP/PC
6588 002574 001772 DT24 ;\$VERPC,\$ERRPC,\$BDADR
6589 002576 030762 DF14 ;16,18,18
6590 :* ITEM 25
6591 002600 030263 DM25 ;TRAPPED TO 114.
6592 002602 030652 DH25 ;V/PC,P/PC,TRP/PC,REG,WAS
6593 002604 002002 DT25 ;\$VERPC,\$ERRPC,\$BDADR,\$TMO,\$TMI
6594 002606 030762 DF14 ;16,18,18,16
6595 :* ITEM 26
6596 002610 030303 DM26 ;FAILED TO TRAP.
6597 002612 030703 DH26 ;V/PC,P/PC,REG,WAS
6598 002614 002016 DT26 ;\$VERPC,\$ERRPC,\$TMO,\$TMI
6599 002616 030750 DF2 ;16,18,18,16
6600 :* ITEM 27
6601 002620 030323 DM27 ;(ACTION ENABLE WASN'T SET).
6602 002622 030703 DH26 ;V/PC,P/PC,REG,WAS
6603 002624 002016 DT26 ;\$VERPC,\$ERRPC,\$TMO,\$BDDAT
6604 002626 030750 DF2 ;16,18,18,16
6605 :* ITEM 30
6606 002630 000000 0 ;NO MESSAGE.
6607 002632 030725 DH30 ;REG,WAS,MA,WAS
6608 002634 002030 DT30 ;\$TMO,\$TMI,\$GDADR,\$BDDAT
6609 002636 030776 DF30 ;18,16,18,8
6610 :* ITEM 31
6611 002640 030357 DM31 ;TRAPPED TO 4
6612 002642 000000 0 ;NO HEADER
6613 002644 002042 DT31 ;\$TMI
6614 002646 030776 DF30 ;18
6615
6616 .SBTTL START: SETUP AND MAP MEMORY

;*/\:/*\:/*\:/*\:/*\:/*\:/*\:/*\:/*\:/*\:/*\:/*\:/*\:
;* THIS IS THE NORMAL (SA = 200) BEGINNING OF THE PROGRAM.
;* NOTE: THIS CODE IS NOT POSITION INDEPENDENT.
;*/*/:*/:*/:*/:*/:*/:*/:*/:*/:*/:*/:*/:*/:

6621 002650 105067 176702 START: CLR8 SELFLG ;CLEAR SELECT PARAMETER FLAG.
6622 002654 000403 BR STARTA ;GO DO SETUP AND MEMORY MAP.
6623 002656 112767 177777 176672 SELECT: MOVB #-1, SELFLG ;SET THE SELECT PARAMETERS FLAG.
6624 002664
(1) .SBTTL INITIALIZE THE COMMON TAGS
(1) ;:CLEAR THE COMMON TAGS (\$CMTAG) AREA
(1) 002664 012706 001100 MOV #SCMTAG,R6 ;FIRST LOCATION TO BE CLEARED
(1) 002670 005026 CLR (R6)+ ;CLEAR MEMORY LOCATION
(1) 002672 022706 001140 CMP #SWR,R6 ;DONE?
(1) 002676 001374 BNE -.6 ;LOOP BACK IF NO
(1) 002700 012706 001100 MOV #STACK,SP ;SETUP THE STACK POINTER
(1) ;:INITIALIZE A FEW VECTORS
(1) 002704 012737 000610 000024 MOV #PWRDN,B/PWRVEC ;POWER FAILURE VECTOR
(1) 002712 012737 000340 000026 MOV #340,B/PWRVEC+2 ;LEVEL 7
(1) 002720 016767 011242 011232 MOV SENDCT,SEOPCT ;SETUP END-OF-PROGRAM COUNTER
(2) ;:SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS

```

(2) 002726 013746 000004      ::EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
(2) 002732 012737 002766 000004 MOV #ERRVEC,-(SP)   ::SAVE ERROR VECTOR
(2) 002740 012767 177570 176172 MOV #64S,#ERRVEC  ::SET UP ERROR VECTOR
(2) 002746 012767 177570 176166 MOV #DSWR,SWR    ::SETUP FOR A HARDWARE SWICH REGISTER
(2) 002754 022777 177777 176156 MOV #DDISP,DISPLAY::AND A HARDWARE DISPLAY REGISTER
(2) 002762 001012              CMP #-1,DSWR       ::TRY TO REFERENCE HARDWARE SWR
(2)                      BNE 66$          ::BRANCH IF NO TIMEOUT TRAP OCCURRED
(2)                      BNE 66$          ::AND THE HARDWARE SWR IS NOT -1
(2) 002764 000403              BR 65$           ::BRANCH IF NO TIMEOUT
(2) 002766 012716 002774      64$: MOV #65$, (SP)  ::SET UP FOR TRAP RETURN
(2) 002772 000002              RTI               ::POINT TO SOFTWARE SWR
(2) 002774 012767 000176 176136 65$: MOV #SWREG,SWR  ::NO,USE APT SWITCH REGISTER
(2) 003002 012767 000174 176132 66$: MOV #DISPREG,DISPLAY
(2) 003010 012637 000004      66$: MOV (SP)+,#ERRVEC ::RESTORE ERROR VECTOR
(1)
(2) 003014 005067 176172      CLR SPASS        ::CLEAR PASS COUNT
(2) 003020 132767 000200 176177  BITB #APTSIZE,SENV  ::TEST USER SIZE UNDER APT
(2) 003026 001403              BEQ 67$          ::YES,USE NON-APT SWITCH
(2) 003030 012767 001226 176102  MOV #SSWREG,SWR  ::NO,USE APT SWITCH REGISTER
(2) 003036 005067 176460      67$: CLR LDDISP      ::CLEAR DISPLAY REGISTER STORAGE LOCN
6625 003036 005067 176074      CLR #DISPLAY     ::CLEAR DISPLAY REGISTER
6626 003042 005077
6627 .SBTTL TYPE PROGRAM NAME
(1) 003046 005227 177777      ::TYPE THE NAME OF THE PROGRAM IF FIRST PASS
(1) 003052 001040              INC #-1          ::FIRST TIME?
(1) 003054 022737 014232 000042 BNE 68$          ::BRANCH IF NO
(1) 003062 001434              CMP #SENDAD,#42  ::ACT-11?
(1) 003064 004567 020432      BEQ 68$          ::BRANCH IF YES
(2) 003070 003142              JSR R5, SPRINT   ::GO PRINT OUT THE FOLLOWING MESSAGE.
(2)                      .WORD 69$          ::ADDRESS OF MESSAGE TO BE TYPED
(2) 003072 005737 000042      .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
(2) 003076 001015              TST #42          ::ARE WE RUNNING UNDER XXDP/ACT?
(2) 003100 126727 176120 000001 BNE 70$          ::BRANCH IF YES
(2) 003106 001411              CMPB SENV,#1    ::ARE WE RUNNING UNDER APT?
(2) 003110 026727 176024 000176 BEQ 70$          ::BRANCH IF YES
(2) 003116 001010              CMP SWR,#SWREG  ::SOFTWARE SWITCH REG SELECTED?
(2)                      BNE 71$          ::BRANCH IF NO
(4) 003120 013746 177776      ::* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $GTWR ROUTINE
(4) 003124 004767 017316      ::* WITHOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
(4)                      MOV #WPSW, -(SP)  ::PUT THE PROCESSOR STATUS ON THE STACK
(4)                      JSR PC, $GTWR    ::GO TO THE SUBROUTINE
(2) 003130 000403              BR 71$          ::SET AUTO-MODE INDICATOR
(2) 003132 112767 000001 175774 70$: MOV B #1,SAUTOB
(2) 003140 000405              71$: BR 68$          ::GET OVER THE ASCIZ
(1) 003140 000405              ::69$: .ASCIZ <CRLF>'CZOMCGO'<CRLF>
(1) 003154 010700              68$: MOV PC, R0      ::GET CURRENT PROGRAM COUNTER.
6628 003154 022700 003156      CMP #.            RO      ::CHECK IF THE PROGRAM IS RELOCATED.
6629 003156 022700 003156      BEQ 10$          ::BR IF PROGRAM NOT RELOCATED.
6630 003162 001402              JMP RESTAR      ::GO TRY TO RELOCATED BEFORE CONTINUING.
6631 003164 000167 175110      MOV #3, PRGMAP  ::INITIALIZE PROGRAM MAP....LO 64K.
6632 003170 012767 000003 175404 10$: CLR PRGMAP+2 ::HI 64K.
6633 003176 005067 175402      CLR RELOCF     ::INIT THE RELOCATION FACTOR.
6634 003202 005067 175372      TSTB #WSENV    ::CHECK FOR APT11
6635 003206 105737 001224      BNE 13$          ::BR IF APT11
6636 003212 001011

```

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) J 3
 CZOMCG.P11 12-MAR-80 13:07 GET VALUE FOR SOFTWARE SWITCH REGISTER 12-MAR-80 13:10 PAGE 59-18

SEQ 0035

6637	003214	005737	000042	TST	#42	;CHECK FOR STANDALONE
6638	003220	001406		BEQ	13\$;BR IF STANDALONE
6639	003222	023737	000042 000046	CMP	#42,#46	;CHECK FOR ACT11
6640	003230	001402		BEQ	13\$;BR IF ACT11
6641						MUST BE XXDP
6642	003232	004767	014122	JSR	PC,SAVLD	;GO SAVE LOADERS
6643						
6644						;* CHECK IF MEMORY MANAGEMENT IS AVAILABLE, AND SET IT UP IF IT IS.
6645	003236	005067	175344	13\$:	CLR MMAVA	;CLEAR MEM MGMT AVAILABLE FLAG
6646	003242	032777	010000 175670	BIT #SW12, ASWR	;CHECK FOR INHIBIT KT11 SWITCH	
6647	003250	001014		BNE IMPCK	;BRANCH IF SET	
6648	003252	012737	003302 000004	MOV #IMPCK, #ERRVEC	;SET UP TIMEOUT TRAP VECTOR	
6649	003260	005037	177572	CLR #SRO	;CLEAR MEM MGMT STATUS REG	
6650	003264	004767	011020	JSR PC, MMINIT	;MEM MGMT INITIALIZATION ROUTINE.	
6651	003270	005267	175312	INC MMAVA	;SET MEM MGMT AVAILABLE FLAG	
6652	003274	004567	020222	JSR RS, SPRINT	;GO PRINT OUT THE FOLLOWING MESSAGE.	
(2)	003300	025364		.WORD MMAMES	;ADDRESS OF MESSAGE TO BE TYPED	
(1)						;'KT11 AVAILABLE'
6653						
6654						;* CHECK IF CACHE PRESENT, IF SO TURN IT OFF!!!
6655	003302	012706	001100	IMPCK:	MOV #STACK, SP	
6656	003306	005067	176304	CLR CASFLG	;CLEAR CACHE PRESENT FLAG	
6657	003312	012737	003334 000004	MOV #MAPMEM, #ERRVEC		
6658	003320	052767	000014 174420	BIS #1, IMPCHE		
6659	003326	012767	000001 176262	MOV #1, CASFLG	;SET CACHE PRESENT FLAG	
6660						
6661						;*****
6662						;* ROUTINE TO MAP ALL OF MEMORY.
6663						;* ONLY FULL 4K BANKS WILL BE RECOGNIZED.
6664						;* R0 = MEMMAP POINTER...LO 64K.
6665						;* R1 = MEMMAP POINTER...HI 64K.
6666						;* R2 = ADDRESS POINTER
6667						;* R3 = BANK POINTER...LO 64K.
6668						;* R4 = BANK POINTER...HI 64K.
6669						;* R5 = SCRATCH REGISTER.
6670						;*****
6671	003334	012706	001100	MAPMEM:	MOV #STACK, SP	;RESET THE STACK
6672	003340	012700	001524	MOV #MEMMAP,R0	;SET UP MEMORY MAP POINTER...LO 64K.	
6673	003344	012701	001526	MOV #MEMMAP+2,R1	;HI 64K.	
6674	003350	005010		CLR (R0)	;CLR MEMORY MAP...LO 64K.	
6675	003352	005011		CLR (R1)	;HI 64K.	
6676	003354	005002		CLR R2	;SET ADDRESS POINTER TO 0	
6677	003356	012703	000001	MOV #1, R3	;SETUP 4K BANK POINTER...LO 64K.	
6678	003362	005004		CLR R4	;HI 64K.	
6679	003364	005067	175576	CLR STMP3	;INIT TEMPORARY HIGH ADDRESS BITS.	
6680	003370	004567	020126	JSR R5, SPRINT	;GO PRINT OUT THE FOLLOWING MESSAGE.	
(2)	003374	025431		.WORD MMAMES	;ADDRESS OF MESSAGE TO BE TYPED	
(1)						'MEMORY MAP':
6681	003376	012737	003512 000004	1\$: MOV #2\$, #ERRVEC	;SET UP TIMEOUT VECTOR	
6682	003404	011222		MOV (R2), (R2)+	;READ+WRITE ALL MEMORY	
6683	003406	032702	017777	BIT #MASK4K,R2	;CHECK FOR 4K BOUNDARY	
6684	003412	001374		BNE 1\$;BRANCH IF MORE IN BANK	
6685	003414	050310		BIS R3, (R0)	;SET FLAG FOR BANK...LO 64K.	
6686	003416	050411		BIS R4, (R1)	;...HI 64K.	
6687	003420	010267	175540	MOV R2, STMP2	;SAVE ADDRESS POINTER.	
6688	003424	005367	175534	DEC STMP2	;ADJUST TO LAST ADR, LAST BANK.	

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER
CZOMCG.P11 12-MAR-80 13:07

K 3
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-19
GET VALUE FOR SOFTWARE SWITCH REGISTER

SEQ 0036

6689 003430 005767 175152 TST MMAVA ;CHECK FOR MEM MGMT.
6690 003434 001432 BEQ 3\$;BR IF NO MEM MGMT.
6691 003436 042767 160000 175520 BIC #160000, \$TMP2 ;CLEAR BANK BITS ON RELATIVE ADDRESS.
6692 003444 013705 172344 MOV @KIPAR2,R5 ;SAVE KIPAR2.
6693 003450 005067 175512 CLR \$TMP3 ;MAKE SURE HI BITS ARE INIT.
6694 003454 006305 ASL R5 ;SHIFT IT 6 PLACES.
6695 003456 006305 ASL R5
6696 003460 006305 ASL R5
6697 003462 006305 ASL R5
6698 003464 006305 ASL R5
6699 003466 006167 175474 ROL \$TMP3
6700 003472 006305 ASL R5
6701 003474 006167 175466 ROL \$TMP3
6702 003500 060567 175460 ADD R5, \$TMP2 ;MAKE LAST ADR PHYSICAL.
6703 003504 005567 175456 ADC \$TMP3
6704 003510 000404 BR 3\$;GO TO UPDATE POINTERS.
6705
6706 :* TIMEOUT TRAPS TO HERE
6707 003512 022626 017777 2\$: CMP (SP)+, (SP)+ ;RESTORE THE STACK POINTER
6708 003514 052702 017777 BIS #MASK4K,R2 ;LAST ADDRESS OF 4K BANK
6709 003520 005202 INC R2 ;FIRST ADDRESS OF NEXT BANK.
6710 003522 005767 175060 3\$: TST MMAVA ;CHECK FOR MEM MGMT
6711 003526 001411 BEQ 4\$;BRANCH IF NO MEM MGMT
6712 003530 062737 000200 172344 ADD #200, @KIPAR2 ;UPDATE THIRD PAR
6713 003536 012702 040000 MOV #40000, R2 ;POINT TO START OF THIRD PAR
6714 003542 006303 ASL R3 ;UPDATE LO BANK POINTER.
6715 003544 006104 ROL R4 ;UPDATE HI BANK POINTER.
6716 003546 100316 BPL 1\$;BRANCH IF MORE MEMORY TO MAP.
6717 003550 000402 BR 5\$;EXIT WHEN DONE.
6718
6719 003552 106303 4\$: ASLB R3 ;UPDATE MAP POINTER
6720 003554 100313 BPL 1\$;BRANCH IF NOT YET DONE
6721 003556 012737 025124 000004 5\$: MOV #ERRTRP, @ERRVEC ;RESET TIMEOUT VECTOR
6722 003564 004767 014632 JSR PC, TYPMAP ;GO TYPE THE MAP.
6723 003570 004567 017726 JSR R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
.WORD SCRLF ;ADDRESS OF MESSAGE TO BE TYPED
6724 003576 011067 175732 MOV (R0), SAVTST ;SET UP TEST MAP...LO 64K.
6725 003602 011167 175730 MOV (R1), SAVTST+2 ;...HI 64K.
6726 003606 011000 MOV (R0), R0 ;GET LOW MEM MAP
6727 003610 042700 177760 BIC #177760, R0 ;MASK ALL BUT BOTTOM 4 BANKS
6728 003614 020027 000017 CMP R0, #17 ;CHECK THAT BOTTOM 16K IS ALL THERE.
6729 003620 001530 BEQ GMPR ;BRANCH IF BOTTOM 16K EXISTS
6730 003622 004567 017674 JSR R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
.WORD IN\$UFF ;ADDRESS OF MESSAGE TO BE TYPED
(1) 6731 003630 000000 HALT ;'FIRST 16K OF MEMORY NOT ALL THERE!'
;FATAL ERROR HALT...
6732 ;MEMORY IS NOT CONFIGURED TO RUN THIS PROGRAM.
6733 ;*****
6734 ;* SPECIAL ROUTINE TO TYPE OUT ALL UNIBUS ADDRESSES WHICH RESPOND TO
6735 ;* DATI, DATIP, DATO, AND DATOB.
6736 ;*****
6737 003632 012706 001100 TIMEOUT: MOV #STACK, SP ;SET UP THE STACK POINTER.
6738 003636 005067 174744 CLR MMAVA ;CLEAR MEM MGMT AVAILABLE FLAG.
6739 003642 032777 010000 175270 BIT #SW12, @SWR ;CHECK IF MEM MGMT TO BE INHIBITED.
6740 003650 001011 BNE 1\$;BR IF NO MEM MGMT.
6741 003652 012737 003674 000004 MOV #1\$, @ERRVEC ;SET TIMEOUT FOR MEM MGMT CHECK.

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER
CZOMCG.P11 12-MAR-80 13:07

MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-20
L 3
GET VALUE FOR SOFTWARE SWITCH REGISTER

SEQ 0037

6742	003660	005037	177572		CLR	R5,	ANSRO	:CHECK FOR MEM MGMT... TIMES OUT IF NONE.
6743	003664	004767	010420		JSR	PC.	MMINIT	:INIT ALL MEM MGMT REGISTERS.
6744	003670	005267	174712		INC	MMAVA		:SET MEM MGMT AVAILABLE FLAG.
6745	003674			1\$:				
(2)	003674	004567	017622		JSR	RS,	SPRINT	:GO PRINT OUT THE FOLLOWING MESSAGE.
(2)	003700	025447			.WORD	BYTIMES		:ADDRESS OF MESSAGE TO BE TYPED
(1)								:BYTE MEMORY MAP:
6746	003702	005000			CLR	R0		:SET UP TYPE OUT FLAG.
6747	003704	005002			CLR	R2		:SET ADDRESS POINTER TO ZERO.
6748	003706	012737	003752 000004	10\$:	MOV	#20\$,	ANERRVEC	:SET TIME OUT VEC TO SERVICE NON-EX MEM.
6749	003714	105712			TSTB	(R2)		:DO DATI ONLY.
6750	003716	032702	000001		BIT	#BIT0,	R2	:CHECK FOR WORD ADDRESS.
6751	003722	001001			BNE	11\$:BR IF ODD BYTE ADDRESS.
6752	003724	011212			MOV	(R2),	(R2)	:DO DATI, DATO... NOP FOR READ ONLY MAP.
6753	003726	151212			BISB	(R2),	(R2)	:DO DATI, DATIP, DATOB... NOP FOR READ ONLY MAP.
6754	003730	005700			TST	R0		:CHECK FOR PREVIOUS TYPOUT.
6755	003732	001023			BNE	30\$:BR IF ALREADY TYPED 'FROM'.
6756	003734	004567	017562	11\$:	JSR	R5,	SPRINT	:GO PRINT OUT THE FOLLOWING MESSAGE.
(2)	003740	025517			.WORD	FROM		:ADDRESS OF MESSAGE TO BE TYPED
(1)								:FROM'
6757	003742	010246			MOV	R2,	-(SP)	:PUT THE DATA ON THE STACK.
(1)	003744	004767	021212		JSR	PC,	STYPAD	:DETERMINE THE PHYSICAL ADDRESS AND TYPE IT.
6758	003750	000413			BR	29\$:GO TO ADDRESS POINTER UPDATE.
6759				20\$:	TIME OUTS COME HERE.			
6760	003752	022626			CMP	(SP)+,	(SP)+	:POP TWO OFF STACK.
6761	003754	005700			TST	R0		:CHECK FOR PREVIOUS TYPOUT.
6762	003756	001411			BEQ	30\$:BR IF ALREADY TYPED 'TO'.
6763	003760	004567	017536		JSR	R5,	SPRINT	:GO PRINT OUT THE FOLLOWING MESSAGE.
(2)	003764	025527			.WORD	TO		:ADDRESS OF MESSAGE TO BE TYPED
(1)								:TO'
6764	003766	005302			DEC	R2		:BACK UP ONE BYTE.
6765	003770	010246			MOV	R2,	-(SP)	:PUT THE DATA ON THE STACK.
(1)	003772	004767	021164		JSR	PC,	STYPAD	:DETERMINE THE PHYSICAL ADDRESS AND TYPE IT.
6766	003776	005202			INC	R2		:RESET ADDRESS POINTER.
6767	004000	005100			COM	R0		:RESET PREVIOUS TYPOUT FLAG.
6768	004002	005202		29\$:	INC	R2		:UPDATE ADDRESS POINTER TO NEXT BYTE.
6769	004004	001423			BEO	31\$:EXIT IF ZERO REACHED.
6770	004006	032702	017777		BIT	#MASK4K,R2		:CHECK FOR 4K BANK BOUNDARY.
6771	004012	001340			BNE	10\$:BR IF MORE THIS 4K BANK.
6772	004014	005767	174566		TST	MMAVA		:CHECK IF MEM MGMT IS AVAILABLE.
6773	004020	001735			BEO	10\$:BR IF NO MEM MGMT.
6774	004022	022737	007600 172346		CMP	#7600,	ANKIPAR3	:CHECK FOR END OF LAST 4K BANK.
6775	004030	001411			BEO	31\$:EXIT WHEN ALL DONE.
6776	004032	012702	060000		MOV	#60000, R2		:RESET VIRTUAL ADDRESS POINTER.
6777	004036	013737	172346 172344		MOV	ANKIPAR3, ANKIPAR2		:SAVE MEM MGMT REG FOR TYPOUT.
6778	004044	062737	000200 172346	31\$:	ADD	#200,	ANKIPAR3	:UPDATE MEM MGMT REG 2 TO NEXT 4K BANK.
6779	004052	000720			BR	10\$:BR BACK TO DO NEXT BANK.
6780	004054	005700			TST	R0		:CHECK PREVIOUS TYPE FLAG BEFORE EXIT.
6781	004056	001407			BEO	32\$:BR TO EXIT IF TYPING ALL DONE.
6782	004060	004567	017436		JSR	R5,	SPRINT	:GO PRINT OUT THE FOLLOWING MESSAGE.
(2)	004064	025527			.WORD	TO		:ADDRESS OF MESSAGE TO BE TYPED
(1)								:TO'
6783	004066	005302			DEC	R2		:BACK ADDRESS POINTER UP ONE BYTE.
6784	004070	010246			MOV	R2,	-(SP)	:PUT THE DATA ON THE STACK.
(1)	004072	004767	021064		JSR	PC,	STYPAD	:DETERMINE THE PHYSICAL ADDRESS AND TYPE IT.
6785	004076	000000		32\$:	HALT			:* THIS ROUTINE IS FOR DEBUG USE ONLY.

6786 004100 000654 BR TIMEOUT ;* TO RUN THE MAIN PROGRAM RESTART AT 200 OR 204.
 6787
 6788
 6789 .SBTTL MAP PARITY REGISTERS
 6790 ;* SEARCH FOR PARITY REGISTERS PRESENT AND TYPE ADDRESSES OF THOSE FOUND
 6791 ;* THAT ARE FUNCTIONAL AND HAVE CORRESPONDING PARITY MEMORY
 6792 ;*
 6793 ;*
 6794 ;*
 6795 004102 012704 002276 GMPR: MOV #MPRX, R4 ;SET UP POINTER TO PARITY REG EXIST TABLE.
 6796 004106 032777 000100 BIT #SW06, @SWR ;CHECK FOR INHIBIT PARITY SWITCH.
 6797 004114 001036 BNE GMPRD ;BR IF INHIBIT PARITY.
 6798 004116 012703 002076 MOV #MPRO, R3 ;SET UP TABLE POINTER
 6799 004122 012737 004144 000004 MOV #GMPRB, @#ERRVEC ;SET UP TIMEOUT TRAP SERVICE
 6800 004130 042713 000001 GMPRA: BIC #1, (R3) ;CLEAR FLAG BIT IN TABLE
 6801 004134 005773 000000 TST @((R3)) ;DOES THIS MEMORY PARITY REGISTER EXIST.
 6802 ;* IF IT DOESN'T EXIST, A TIMEOUT TRAP WILL GO TO 'GMPRB'.
 6803 004140 012324 MOV (R3)+, (R4)+ ;SAVE IT IN THE PARITY REG EXIST TABLE.
 6804 004142 000403 BR GMPRC ;SKIP TIMEOUT SERVICE CODE
 6805 ;* TIMEOUT COMES HERE
 6806 004144 022626 GMPRB: CMP (SP)+, (SP)+ ;RESTORE STACK POINTER
 6807 004146 052723 000001 BIS #1, (R3)+ ;SET FLAG TO INDICATE REGISTER NOT PRESENT
 6808 004152 005023 GMPRC: CLR (R3)+ ;CLEAR THE MAP...LO 64K.
 6809 004154 005023 CLR (R3)+ ;...HI 64K.
 6810
 6811 004156 005023 CLR (R3)+ ;...AND THE MASK.
 6812 004160 020327 002276 CMP R3, #MPRX ;HAVE WE CHECKED ALL REGISTERS?
 6813
 6814 004164 103761 BLO GMPRA ;NO - GO BACK TO CHECK NEXT ONE
 6815 004166 005014 CLR (R4) ;SET TERMINATOR IN PARITY REG EXIST TABLE.
 6816 004170 012737 025124 000004 MOV #ERRTRP, @#ERRVEC ; RESTORE TRAPCATCHER
 6817 004176 005767 176074 TST MPRX ;ANY PARITY REGISTERS PRESENT?
 6818 004202 001006 BNE MPAMEM ;YES - GO TEST CONTROLS PRESENT
 6819 004204 004567 017312 JSR RS, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
 (2) 004210 025615 .WORD MTR ;ADDRESS OF MESSAGE TO BE TYPED
 (1) ;'NO MEMORY PARITY REGISTERS FOUND'
 6820 004212 005014 GMPRD: CLR (R4) ;MAKE SURE TABLE IS CLEAR.
 6821 004214 000167 001156 JMP MANUAL ;AND SKIP ALL CONTROLS TESTING
 6822

6824 .SBTTL MAP PARITY MEMORY
 6825 ;*****
 6826 ;MAP CORRESPONDENCE BETWEEN PARITY REGISTERS AND MEMORY, AND TYPE RESULTS
 6827 ;NOTE THAT IF PARITY MEMORY IS NOT LOCATED CORRECTLY THAT IT IS IN ALL
 6828 ;PROBABILITY DUE TO ONE OF THE FOLLOWING FAILURES:
 6829 ; - SETTING WRITE WRONG PARITY DIDN'T CAUSE BAD PARITY TO BE WRITTEN
 6830 ; - PARITY GENERATE OR DETECT LOGIC FAILED
 6831 ; - PARITY ERROR BIT FAILED TO SET
 6832 ; - PARITY BITS IN MEMORY LOCATION FAILED
 6833 ; - I.E. BIT STUCK AT GOOD PARITY VALUE
 6834 ;*****
 6835
 6836 004220 004767 014054 175312 MPAMEM: JSR PC, CLRPAR :INITIALIZE ALL PARITY REGISTERS
 6837 004224 012767 000001 175312 MOV #1, BITPT :INITIALIZE 4K POINTER
 6838 004232 005067 175310 CLR BITPT+2 :CLEAR HI 64K POINTER
 6839 004236 012702 014000 MOV #14000, R2 :SET ADR POINTER TO 14000.
 6840 004242 005767 174340 TST MMAVA :CHECK FOR MEM MGMT
 6841 004246 001404 BEQ MAPRB :BRANCH IF NO MEM MGMT
 6842 004250 012702 054000 MOV #54000, R2 :SET ADR POINTER TO PAR2
 6843 004254 004767 010030 JSR PC, MMINIT :SET UP ALL MEMORY MGMT REGISTERS.
 6844
 6845 ;*****
 6846 ;SET WRITE WRONG PARITY IN ALL REGISTERS PRESENT
 6847 ;* THEN WRITE TEST LOCATION VIA DATO & READ TEST LOCATION VIA DATI
 6848 ;* THEN CLEAR WRITE WRONG PARITY IN ALL REGISTERS.
 6849 ;*****
 6850
 6851 004260 005067 175254 MAPRB: CLR PMEMAP :CLEAR THE PARITY MEMORY MAP
 6852 004264 005067 175252 CLR PMEMAP+2
 6853 004270 012703 002076 1\$: MOV #MPRO, R3 :INITIALIZE TABLE ADDRESS
 6854 004274 032713 000001 2\$: BIT #1, (R3) :IS THIS REGISTER PRESENT?
 6855 004300 001052 BNE 3\$:NO - GET THE NEXT ONE
 6856 004302 013773 001612 000000 MOV @#WWP, @R3 :YES - SET WRITE WRONG PARITY
 ;AND CLEAR REST OF REGISTER
 6857 004310 011212 MOV (R2), (R2) :WRITE WRONG PARITY
 6858 004312 005712 TST (R2) :READ WRONG PARITY
 6859 004314 043773 001612 000000 BIC @#WWP, @R3 :CLEAR WRITE WRONG PARITY
 6860 004322 005773 000000 TST @R3 :OTHERWISE, CHECK TO SEE IF THIS
 ;CONTROL REGISTER GOT A PARITY
 ;ERROR
 6863
 6864 004326 100014 BPL 6\$:BRANCH IF IT DIDN'T AND CHECK
 6865 004330 032773 007740 000000 BIT #7740, @R3 :IS IT A CORE PAR. REG.
 6866 004336 001404 BEQ 5\$:BRANCH IF NOT.
 6867 004340 012763 070032 000006 MOV #70032, 6(R3) :IF IT IS SET UP MASK
 6868 004346 000413 BR 7\$:AND BRANCH TO SET BITS.
 6869 004350 012763 077772 000006 5\$: MOV #77772, 6(R3) :IF MOS SET UP MASK
 6870 004356 000407 BR 7\$:AND BRANCH TO SET BIT.
 6871 004360 032773 007740 000000 6\$: BIT #7740, @R3 :IF ANY BITS ARE SET
 6872 004366 001417 BEQ 3\$:THEN CSR IS MS11-K.
 6873 004370 012763 070000 000006 MOV #70000, 6(R3) :IF MS11-K SET MASK.
 6874 004376 056763 175142 000002 7\$: BIS BITPT, 2(R3) :SET FLAG IN MAP FOR THIS PARITY REGISTER
 6875 004404 056763 175136 000004 BIS BITPT+2,4(R3)
 6876 004412 056767 175126 175120 BIS BITPT, PMEMAP :SET FLAG IN PARITY MAP
 6877 004420 056767 175122 175114 BIS BITPT+2,PMEMAP+2
 6878 004426 062703 000010 3\$: ADD #10, R3 :STEP UP TO NEXT REGISTER
 6879 004432 020327 002276 CMP #MPRX :ARE WE DONE WITH TABLE?

6880	004436	103716		BLO	2\$: GO BACK TO CHECK FOR ANY MORE	
6881	004440	011212		MOV	(R2), (R2)	: CLEAR BAD PARITY	
6882	004442	005767	174140	TST	MMAVA	: CHECK FOR MEM MGMT	
6883	004446	001444		BEQ	10\$: BR IF NO MEM MGMT	
6884	004450	062737	000200	172344	4\$:	ADD #200, WKIPAR2 : UPDATE PAR TO NEXT 4K BANK.	
6885	004456	006367	175062	ASL	BITPT	: UPDATE BANK POINTER...LO 64K.	
6886	0C .462	006167	175060	ROL	BITPT+2	: HI 64K.	
6887	004466	100441		BMI	TMAP	: BR IF ALL DONE.	
6888	004470	023727	172344	001000	CMP WKIPAR2 , #1000	: THIS CODE TESTS IF MS11-K IS	
6889	004476	001013		BNE	12\$: PRESENT AND IF IT IS I SET	
6890	004500	032737	000003	002260	BIT #3, AMMPR14+2	: THE BIT TO DISABLE ECC IN	
6891	004506	001004		BNE	13\$: THE LOCATION WWP THAT IS	
6892	004510	032737	000003	002270	BIT #3, AMMPR15+2	: USED AS THE COMMAND TO	
6893	004516	001400		BEQ	13\$: WRITE WRONG PARITY.	
6894	004520	012737	020004	001612	13\$:	MOV #20004, AMWP	
6895	004526	036767	175012	174770	12\$:	BIT BITPT, MEMMAP : CHECK IF BANK EXISTS...LO 64K.	
6896	004534	001255		BNE	1\$: BR IF BANK EXISTS.	
6897	004536	036767	175004	174762	BIT	BITPT+2, MEMMAP+2 : HI 64K.	
6898	004544	001251		BNE	1\$: BR IF BANK EXISTS.	
6899	004546	000740		BR	4\$: BR IF BANK DOESN'T EXIST.	
6900	004550	036767	174770	174746	11\$:	BIT BITPT, MEMMAP : CHECK IF BANK EXISTS.	
6901	004556	001244		BNE	1\$: BR IF BANK EXISTS.	
6902	004560	062702	020000		10\$:	ADD #20000, R2 : UPDATE ADDRESS POINTER TO NEXT BANK.	
6903	004564	106367	174754		ASLB	BITPT : MOVE POINTER TO NEXT BANK.	
6904	004570	100367		BPL	11\$: BR IF MORE TO LOOK FOR.	
6905							
6906							
6907						*****	
6908						* ROUTINE TO TYPE MAP OF WHERE PARITY MEMORY IS PRESENT	
6909						* AND WHICH CONTROL REGISTERS CONTROL WHICH MEMORY	
6910						*****	
6911	004572	004767	013502	TMAP:	JSR PC,	CLPPAR : INITIALIZE ALL PARITY REGISTERS PRESENT	
6912	004576	004567	016720		JSR R5,	SPRINT : GO PRINT OUT THE FOLLOWING MESSAGE.	
(2)	004602	025472		.WORD	MTMAP	: ADDRESS OF MESSAGE TO BE TYPED	
(1)						: 'PARITY MEMORY MAP'	
6913	004604	012703	002076		MOV #MPRO, R3	: INITIALIZE TABLE POINTER	
6914	004610	032713	000001	1\$:	BIT #BIT0, (R3)	: CHECK IF THIS REGISTER IS PRESENT.	
6915	004614	001046		BNE	2\$: BR IF NOT PRESENT.	
6916	004616	022763	070032	000006	CMP #70032, 6(R3)		
6917	004624	001004		BNE	3\$		
6918	004626	004567	016670		JSR R5,	SPRINT : GO PRINT OUT THE FOLLOWING MESSAGE.	
(2)	004632	026133		.WORD	MX3	: ADDRESS OF MESSAGE TO BE TYPED	
(1)						: 'CORE PARITY'	
6919	004634	000417		BR	5\$		
6920	004636	022763	077772	000006	3\$:	CMP #777772, 6(R3)	
6921	004644	001004		BNE	4\$		
6922	004646	004567	016650		JSR R5,	SPRINT : GO PRINT OUT THE FOLLOWING MESSAGE.	
(2)	004652	026152		.WORD	MX4	: ADDRESS OF MESSAGE TO BE TYPED	
(1)						: 'MOS PARITY'	
6923	004654	000407		BR	5\$		
6924	004656	022763	070000	000006	4\$:	CMP #70000, 6(R3)	
6925	004664	001003		BNE	5\$		
6926	004666	004567	016630		JSR R5,	SPRINT : GO PRINT OUT THE FOLLOWING MESSAGE.	
(2)	004672	026170		.WORD	MX5	: ADDRESS OF MESSAGE TO BE TYPED	
(1)						: 'MS11-K CSR'	
6927	004674			5\$:			

(2) 004674 004567 016622 JSR R5, SPRINT ; GO PRINT OUT THE FOLLOWING MESSAGE.
 (2) 004700 026101 016622 .WORD MX1 ; ADDRESS OF MESSAGE TO BE TYPED
 (1) 6928 004702 011346 MOV (R3), -(SP) ; REGISTER AT
 (3) :* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE STYPOC ROUTINE
 (3) :* WITHOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
 (3) 004704 013746 177776 MOV @#PSW, -(SP) ; PUT THE PROCESSOR STATUS ON THE STACK
 (3) 004710 004767 020004 JSR PC, STYPOC ; GO TO THE SUBROUTINE
 6929 004714 004567 016602 JSR R5, SPRINT ; GO PRINT OUT THE FOLLOWING MESSAGE.
 (2) 004720 026120 .WORD MX2 ; ADDRESS OF MESSAGE TO BE TYPED
 (1) 6930 004722 C10300 MOV R3, R0 ; SET UP R0 FOR TYPMAP ROUTINE.
 6931 004724 005720 TST (R0)+ ; UPDATE POINTER TO MAP.
 6932 004726 004767 013470 JSR PC, TYPMAP ; GO TYPE THE MEMORY COVERED BY THIS REGISTER.
 6933 004732 062703 000010 ADD #10, R3 ; UPDATE TO NEXT REGISTER IN TABLE.
 6934 004736 020327 002276 CMP R3, #MPRX ; ARE WE ALL DONE WITH TABLE?
 6935 004742 103722 BLO 1\$; BRANCH IF MORE REGISTERS
 6936 004744 004567 016552 JSR R5, SPRINT ; THE REASON I'M OUTPUTTING THIS CRLF
 6937 004750 001201 \$CRLF ; IS TO GIVE THE PRINTER ENOUGH TIME TO
 6938 ; FINISH PRINTING THE MEMORY MAP BEFORE THE RESET OCCURS.
 6939 004752 022737 070000 002264 CMP #70000, #MPR14+6 ; DO WE HAVE MS11-K AT THIS ADDRESS
 6940 004760 001006 BNE 7\$; IF NO BRANCH
 6941 004762 043727 002260 001540 BIC #MPR14+2, #PMEMAP ; IF YES THEN CLEAR THE BITS IN
 6942 004770 043737 002262 001540 BIC #MPR14+4, #PMEMAP ; THE PARITY MEMORY MAP
 6943 004776 022737 070000 002274 7\$: CMP #70000, #MPR15+6 ; DO WE HAVE A MS11-K
 6944 005004 001031 BNE 9\$; IF NO GO TO TESTS NOW.
 6945 005006 043737 002270 001540 BIC #MPR15+2, #PMEMAP ; IF YES I AM GOING TO
 6946 005014 043737 002272 001542 BIC #MPR15+4, #PMEMAP+2 ; CLEAR THE PARITY INDICATORS
 6947 005022 012705 002276 MOV #MPRX, R5 ; FOR THAT PORTION OF MEMORY.
 6948 005026 021537 002256 6\$: CMP (R5), #MPR14 ; SEARCH FOR THIS MS11-K CSR IN
 6949 005032 001004 BNE 8\$; AND IF ITS THERE DELETE IT
 6950 005034 005015 CLR (R5)
 6951 005036 052737 000001 002256 BIS #1, #MPR14
 6952 005044 022537 002266 8\$: CMP (R5)+, #MPR15 ; SEARCH FOR MS11-K CSR IN
 6953 005050 001366 BNE 6\$; THE AVAILABILITY TABLE.
 6954 005052 005045 CLR -(R5) ; AND CLEAR ITS ADDRESS FROM THE TABLE
 6955 005054 052737 000001 002266 BIS #1, #MPR15 ; SET BIT0 IN ADDRESS IN CSR TABLE
 6956 005062 004567 016434 JSR R5, SPRINT ; OUTPUT MESSAGE TO RUN MS11-K TEST.
 6957 005066 026206 .WORD MX6
 6958 005070 005737 002276 9\$: TST #MPRX ; ARE THERE ANY PARITY REGISTERS TO TEST?
 6959 005074 001002 BNE CTRLs ; IF SO TEST THE BITS IN THE REGISTERS.
 6960 005076 000167 000274 JMP MANUAL ; IF NO JUMP OVER REGISTER TESTS.
 6961
 6962 .SBTTL TEST PARITY REGISTERS
 6963 ;*****
 6964 ;* SHOW THAT BITS 0, 2, 5 - 11, AND 15 OF EACH PARITY REGISTER PRESENT
 6965 ;* CAN BE SET AND CLEARED.
 6966 ;* THIS IS A ONCE ONLY TEST.
 6967 ;*****
 6968
 6969 005102 012703 002076 CTRLs: MOV #MPRO, R3 ; LOAD INITIAL TABLE ADDRESS FOR A POINTER
 6970 005106 011302 1\$: MOV (R3), R2 ; LOAD R2 WITH ADDRESS OF THIS PARITY REGISTER
 6971 005110 062703 000010 ADD #10, R3 ; UPDATE POINTER TO NEXT PAR. REG. ADD.
 6972 005114 032702 000001 BIT #1, R2 ; IS THIS REGISTER BEING USED?
 6973 005120 001372 BNE 1\$; GO TO NEXT IF NOT
 6974 005122 020327 002276 CMP R3, #MPRX ; ARE WE AT END OF TABLE

6975 005126 003055 BGT RESCHK : GO TO NEXT TEST IF YES
 6976 005130 005763 177776 TST -2(R3) : TEST MASK FOR PARITY REGISTER
 6977 005134 001764 BEQ 1\$: IF = 0, THEN DO NOT TEST
 6978 005136 016367 177776 174352 MOV -2(R3), RESRVD : GET MASK FOR REGISTER WE ARE WORKING ON
 6979 005144 012700 000001 MOV #1, R0 : LOAD R0 WITH VALUE OF 1ST BIT TESTED
 6980 005150 005012 CLR (R2) : INITIALIZE THE PARITY REGISTER
 6981 005152 011201 MOV (R2), R1 : READ THE CONTENTS OF THE PARITY REGISTER
 6982 005154 046701 174336 BIC RESRVD, R1 : CLEAR BITS WHICH ARE RESERVED
 6983 005160 001405 BEQ 2\$: CHECK OTHER BITS - BRANCH IF OK
 6984 005162 004767 013134 64\$: JSR PC, SPRNT : SET UP VALUES FOR ERROR PRINTING.
 (2) 005166 004767 014456 JSR PC, \$ERROR : *** ERROR *** (GO TYPE A MESSAGE)
 (2) 005172 000001 .WORD 1 : ERROR TYPE CODE.
 6985 005174 030067 174316 2\$: BIT R0, RESRVD : IS THIS BIT RESERVED?
 6986 005200 001025 BNE 3\$: YES - DON'T TEST IT
 6987 005202 010012 MOV R0, (R2) : NO - SET THIS BIT IN THE PARITY REGISTER
 6988 005204 011201 MOV (R2), R1 : READ & SAVE CONTENTS OF THE PARITY REGISTER
 6989 005206 005012 CLR (R2) : CLEAR THE PARITY REGISTER
 6990 005210 046701 174302 BIC RESRVD, R1 : CLEAR BIT LOCATIONS THAT ARE RESERVED
 6991 005214 020001 CMP R0, R1 : COMPARE THE CHECK WORD WITH THE DATA READ.
 (2) 005216 001405 BEQ 66\$: BRANCH OVER ERROR CALL IF GOOD DATA.
 (3) 005220 004767 013126 65\$: JSR PC, SPRNTO : SET UP VALUES FOR ERROR PRINTING.
 (4) 005224 004767 014420 JSR PC, \$ERROR : *** ERROR *** (GO TYPE A MESSAGE)
 (4) 005230 000001 .WORD 1 : ERROR TYPE CODE.
 (2) 005232 66\$: .
 6992 005232 011201 MOV (R2), R1 : READ THE CONTENTS OF THE PARITY REGISTER
 6993 005234 046701 174256 BIC RESRVD, R1 : CLEAR BITS WHICH ARE RESERVED
 6994 005240 001405 BEQ 3\$: CHECK OTHER BITS - BRANCH IF OK
 6995 005242 004767 013054 67\$: JSR PC, SPRNT : SET UP VALUES FOR ERROR PRINTING.
 (2) 005246 004767 014376 JSR PC, \$ERROR : *** ERROR *** (GO TYPE A MESSAGE)
 (2) 005252 000001 .WORD 1 : ERROR TYPE CODE.
 6996 005254 006300 3\$: ASL R0 : ROTATE TO GET NEXT BIT TO BE TESTED
 6997 005256 103346 BCC 2\$: BRANCH IF NOT DONE WITH ALL BITS
 6998 005260 000712 BR 1\$: AFTER TESTING FOR BIT 15 GO GET NEXT REGISTER.
 6999 .
 7000 .
 7001 ;* SHOW THAT RESET CLEARS BITS 0,2, AND 15 OF EACH PARITY REGISTER PRESENT.
 7002 ;* THIS IS A ONCE ONLY TEST.
 7003 .
 7004 .
 7005 005262 012704 002076 RESCHK: MOV #MPRO, R4 : LOAD INITIAL TABLE ADDRESS FOR A POINTER
 7006 005266 010403 1\$: MOV R4, R3
 7007 005270 062704 000010 ADD #10, R4
 7008 005274 032713 000001 BIT #1, (R3) : IS THIS REGISTER BEING USED
 7009 005300 001372 BNE 1\$: BRANCH IF NO
 7010 005302 012773 177777 000000 MOV #-1, @R3 : SET ALL BITS TO A 1
 7011 005310 022704 002276 CMP #MPRX, R4 : ARE WE AT THE END OF THE TABLE
 7012 005314 002764 BLT 1\$: IF YES THEN WE ARE READY TO TEST
 7013 005316 000005 RESET : RESET THE WORD
 7014 005320 012703 002076 MOV #MPRO, R3 : LOAD INITIAL ADDRESS FOR POINTER
 7015 005324 011302 2\$: MOV (R3), R2 : STORE PARITY REGISTER ADDRESS
 7016 005326 062703 000010 ADD #10, R3
 7017 005332 032702 000001 BIT #1, R2
 7018 005336 001372 BNE 2\$
 7019 005340 022703 002276 CMP #MPRX, R3
 7020 005344 002014 BGE MANUAL
 7021 005346 011201 MOV (R2), R1 : GET CONTENTS OF REGISTER

CZOMCG GO 0-124K MEMORY EXERCISER. 16K VFR MACY11 30A(1052) E 4
CZOMCG.P11 12-MAR-80 13:07 TEST PARITY REGISTERS 12-MAR-80 13:10 PAGE 59-26

SEQ 0043

7022	005350	005012		CLR	(R2)		
7023	005352	042701	077772	BIC	#77772, R1	:CLEAR BITS NOT EFFECTED BY RESET	
7024	005356	005701		TST	R1	:CHECK IF REST WERE CLEARED BY RESET	
7025	005360	001405		BEQ	65\$:BRANCH OVER ERROR CALL IF GOOD DATA.	
(2)	005362	004767	012734	64\$:	JSR PC.	SPRNT	:SET UP VALUES FOR ERROR PRINTING.
(3)	005366	004767	014256	JSR PC.	\$ERROR	:*** ERROR *** (GO TYPE A MESSAGE)	
(3)	005372	000001		.WORD	1	:ERROR TYPE CODE.	
(1)	005374			65\$:	BR	2\$:BRANCH BACK TO CHECK NEXT REGISTER
7026	005374	000753					
7027							
7028							
7029	005376	012700	000014	MANUAL:	MOV #12 R0	:SET COUNTER TO CLEAR 12 WORDS.	
7030	005402	012701	001562		MOV #FSTADR,R1	:STARTING AT FSTADR.	
7031	005406	005021		1\$:	CLR (R1)+	:CLEAR THE LOCATIONS.	
7032	005410	005300			DEC R0	:COUNT.	
7033	005412	001375			BNE 1\$:BR IF MORE.	
7034	005414	105767	174136		TSTB SELFLG	:CHECK FOR SELECT PARAMETERS STARTUP.	
7035	005420	001005			BNE MANUL1	:BR IF PARAMETERS TO BE SELECTED.	
7036	005422	016767	173536 174144		MOV STMP2 LSTADR	:SET UP VIRTUAL LAST ADDRESS.	
7037	005430	000167	000402	JMP	MANUL2	:SKIP PARAMETER SELECTION SECTION.	

7039
 7040
 7041
 7042
 7043 005434 012700 000001
 7044 005440 005001
 7045 005442 005002
 7046 005444 005003
 7047 005446 004567 016050
 (2) 005452 026321
 (1)
 7048
 (2)
 (2) 005454 013746 177776
 (2) 005460 004767 015664
 7049 005464 042716 000001
 7050 005470 005067 174040
 7051 005474 005067 174036
 7052 005500 062702 020000
 7053 005504 005503
 7054 005506 020367 016006
 7055 005512 103403
 7056 005514 101006
 7057 005516 020216
 7058 005520 101004
 7059 005522 006300
 7060 005524 006101
 7061 005526 100364
 7062 005530 000507
 7063 005532 030067 173766
 7064 005536 001003
 7065 005540 030167 173762
 7066 005544 001501
 7067 005546 016704 015746
 7068 005552
 (2) 005552 004567 015744
 (2) 005556 026406
 (1)
 7069
 (2)
 (2) 005560 013746 177776
 (2) 005564 004767 015560
 7070 005570 005716
 7071 005572 001010
 7072 005574 005767 015720
 7073 005600 001005
 7074 005602 016716 173356
 7075 005606 016767 173354
 7076 005614 012667 173754
 7077 005620 020467 015674
 7078 005624 101352
 7079 005626 103403
 7080 005630 021667 173740
 7081 005634 101345
 7082 005636 032716 017777
 7083 005642 001404

.SBTTL USER PARAMETER SELECTION SECTION
 ;* USER PARAMETER SELECTION SECTION IS ENTERED BY STARTING AT 204.
 ;*
 MANUL: MOV #BIT0, R0 ;SET UP BANK POINTER.
 CLR R1 ;HI 64K.
 CLR R2 ;CLEAR ADDRESS POINTER.
 CLR R3 ;HI ADDRESS BITS.
 JSR R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
 .WORD FADMES ;ADDRESS OF MESSAGE TO BE TYPED
 ;FIRST ADDRESS:
 ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE \$RDOCT ROUTINE
 ;* WIHTOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
 MOV #PSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
 JSR PC, \$RDOCT ;GO TO THE SUBROUTINE
 BIC #BIT0, (SP) ;MAKE SURE ADDRESS IS ON A WORD BOUNDARY.
 CLR SAVTST ;INIT TEST MAP...LO 64K.
 CLR SAVTST+2 ;HI 64K.
 1\$: ADD #20000, R2 ;UPDATE ADDRESS POINTER TO NEXT BANK.
 ADC R3
 CMP R3, \$HIOCT ;CHECK HI ADDRESS BITS.
 BLO 2\$;BR IF NOT HI ENOUGH YET.
 BH1 3\$;BR IF PAST SELECTED ADDRESS.
 CMP R2, (SP) ;CHECK THE LO ADDRESS BITS.
 BH1 3\$;BR IF PAST SELECTED ADDRESS.
 ASL R0 ;UPDATE POINTER...LO 64K.
 ROL R1
 BPL 1\$;BR BACK TO CHECK NEXT BANK.
 BR 17\$;BR IF OVERFLOW.
 2\$: BIT R0, MEMMAP ;CHECK IF BANK EXISTS.
 BNE 4\$;BR IF BANK EXISTS.
 BIT R1, MEMMAP+2 ;CHECK HI 64K.
 BEQ 17\$;BR IF ADDRESS IN UN-MAPPED BANK.
 4\$: MOV \$HIOCT, R4 ;SAVE FIRST ADR HI BITS.
 10\$: JSR R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
 .WORD LADMES ;ADDRESS OF MESSAGE TO BE TYPED
 ;LAST ADDRESS:
 ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE \$RDOCT ROUTINE
 ;* WIHTOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
 MOV #PSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
 JSR PC, \$RDOCT ;GO TO THE SUBROUTINE
 TST (SP) ;CHECK IF ADR 0 SELECTED (DEFAULT).
 BNE 11\$;BR IF NOT 0 (DEFAULT).
 TST \$HIOCT ;CHECK HI BITS.
 BNE 11\$;BR IF NOT 0 (DEFAULT).
 MOV STMP2, (SP) ;SET UP DEFAULT LAST ADR.
 MOV STMP3, \$HIOCT
 015704 11\$: MOV (SP)+, LSTADR ;GET THE DATA.
 CMP R4, \$HIOCT ;CHECK FOR LAST ADR BELOW FIRST ADR.
 BH1 10\$;BB IF LAST BELOW FIRST.
 BLO 12\$;BR IF LAST ABOVE FIRST.
 CMP (SP), LSTADR ;CHECK FOR LAST BELOW FIRST.
 BH1 10\$;BR IF LAST BELOW FIRST.
 BEQ 13\$;CHECK IF FIRST ADR ON BANK BOUNDARY.
 BH1 13\$;BR IF ON BOUNDARY.

/* THE REST OF THE PROGRAM IS POSITION INDEPENDENT CODE, SO THAT IT CAN EXECUTE PROPERLY WHEN THE PROGRAM HAS BEEN RELOCATED. THIS IS DONE SO THAT THE FIRST TWO BANKS OF MEMORY CAN BE EXERCISED IN EXACTLY THE SAME MANNER AS THE REST OF MEMORY */

7135	006114	016706	173502		START1: MOV .STACK, SP	:SET STACK POINTER
7136	006120	005767	173472		TST CASFLG	:CHECK CACHE PRESENT FLAG
7137	006124	001403			BEQ 1\$:BRANCH IF NO CACHE
7138	006126	052777	000014	173464	BIS #14, ACASREG	:TURN OFF CACHE
7139	006134	012767	006114	172744	1\$: MOV #START1, SLPADR	:INIT LOOP ADDRESS.
7140	006142	066767	172432	172736	ADD RELOCF, SLPADR	
7141	006150	004767	011372		JSR PC, MAMF	:SET UP MEMORY PARITY ERROR VECTOR
7142	006154	005767	172426		TST MMAVA	:CHECK FOR MEMORY MANAGEMENT AVAILABLE.
7143	006160	001406			BEQ TST1	:BRANCH IF NO MEM MGMT.
7144	006162	032737	000001	177572	BIT #BIT0, ASR0	:CHECK IF MEM MGMT ENABLED.
7145	006170	001002			BNE TST1	:BR IF MEM MGMT ENABLED.
7146	006172	004767	006112		JSR PC, MMINIT	:SET UP MEM MGMT REGISTERS.
7147						
7148					.SBT L SECTION 1: MEMORY ADDRESS TESTS	
7157					*****	
(3)					;* TEST 1 WRITE VALUE OF MEMORY ADDRESS INTO MEMORY	
(4)					;* R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)	
(4)					;* R1 = DATA READ FROM MEMORY (WAS)	
(4)					;* R2 = VIRTUAL ADDRESS	
(4)					;* R3 = NOT USED	
(4)					;* R4 = NOT USED	
(4)					;* R5 = BLOCK BOUNDARY BIT MASK.	
7157					*****	
(2)	006176				TST1: JSR R5, \$SCOPE	:GO TO SCOPE ROUTINE.
(3)	006176	004567	012436		.WORD 1	:MINIMUM BLOCK SIZE OF 1 WORDS
(3)	006202	000001				:REQUIRED FOR THIS TEST.
(3)	006204	000167	005604		JMP TST32	:SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
(3)						:AVAILABLE FOR TEST.
7158						
7159	006210	004467	006222		;* UPWARDS WORD ADDRESSING.	
7160	006214	004767	007644		1\$: JSR R4, INITMM	:INITIALIZE THE MEMORY ADDRESS POINTERS.
7161	006220	010012			1\$: JSR PC, PHYADR	:GET PHYSICAL ADDRESS INTO R0
7162	006222	012201			2\$: MOV R0, (R2)	:WRITE VALUE OF ADDRESS INTO ADDRESS
(2)	006224	020001			MOV (R2)+, R1	:GET THE DATA FROM MEMORY UNDER TEST.
(3)	006226	001405			CMP R0, R1	:COMPARE THE CHECK WORD WITH THE DATA READ.
(4)	006230	004767	012142		BEQ 65\$:BRANCH OVER ERROR CALL IF GOOD DATA.
(5)	006234	004767	013410		64\$: JSR PC, SPRNT2	:SET UP VALUES FOR ERROR PRINTING.
(5)	006240	000002			JSR PC, \$ERROR	:*** ERROR *** (GO TYPE A MESSAGE)
(3)	006242				.WORD 2	:ERROR TYPE CODE.
7163	006242	062700	000002		65\$: ADD #2, R0	:ADD #2 TO PHYSICAL ADDRESS
7164	006246	030502			BIT R5, R2	:CHECK FOR END OF A BLOCK.
(1)	006250	001363			BNE 2\$:BRANCH IF MORE IN CURRENT BLOCK.
(1)	006252	004767	006736		JSR PC, MMUP	:FIND NEXT BLOCK AND LOOP TO 1\$.
7165						
7166					;* CHECK THAT VALUE OF MEMORY ADDRESS WAS WRITTEN CORRECTLY	
,167					;* DOWNWARDS WORD ADDRESSING.	
7168	006256	004467	006612		JSR R4, INITDN	:INITIALIZE THE MEMORY ADDRESS POINTERS.
7169	006262	004767	007576		3\$: JSR PC, PHYADR	:GET PHYSICAL ADDRESS INTO R0
7170	006266	162700	000002		4\$: SUB #2, R0	:DEC DATA BY 2
7171	006272	014201			MOV -(R2), R1	:GET THE DATA FROM MEMORY

(ZOMCGO 0-124K MEMORY EXERCISER, 16K VER
CZOMCG.P11 12-MAR-80 13:07 T1

MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-30
1 4
WRITE VALUE OF MEMORY ADDRESS INTO MEMORY

SEQ 0047

7172 006274 020001
(2) 006276 001405
(3) 006300 004767 012046
(4) 006304 004767 013340
(4) 006310 000002
(2) 006312 000002
7173 006312 030502
(1) 006314 001364
(1) 006316 004767 007362

66\$: CMP R0 R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 67\$;BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC. SPRNTO ;SET UP VALUES FOR ERROR PRINTING.
JSR PC. \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 2 ;ERROR TYPE CODE.
67\$: BIT RS. R2 ;CHECK FOR END OF A BLOCK.
BNE 4\$;BRANCH IF MORE IN CURRENT BLOCK.
JSR PL. MMDDWN ;FIND NEXT BLOCK AND LOOP TO \$TAG1.

7175 (3) :***** TEST 2 WRITE VALUE OF MEMORY ADDRESS INTO MEMORY
 (4) :* R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)
 (4) :* R1 = DATA READ FROM MEMORY (WAS)
 (4) :* R2 = VIRTUAL ADDRESS
 (4) :* R3 = NOT USED
 (4) :* R4 = NOT USED
 (4) :* R5 = BLOCK BOUNDARY BIT MASK.
 (3) :*****
 (2) 006322 TST2:
 (3) 006322 004567 012312 JSR R5, \$SCOPE ;GO TO SCOPE ROUTINE.
 (3) 006326 000000 000000 .WORD 0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
 7176 :* UPWARDS BYTE ADDRESSING.
 7177 006330 004467 006102 JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
 7178 006334 004767 007524 1\$: JSR PC, PHYADR ;GET PHYSICAL ADDRESS INTO R0
 7179 006340 110022 2\$: MOVBL R0, (R2)+ ;WRITE VALUE OF ADDRESS INTO ADDRESS
 7180 006342 005200 INC R0 ;ADD ONE TO PHYSICAL ADDRESS
 7181 006344 030502 BIT R5, R2 ;CHECK FOR END OF A BLOCK.
 (1) 006346 001374 BNE 2\$;BRANCH IF MORE IN CURRENT BLOCK.
 (1) 006350 004767 006640 JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1\$.

7182 :* CHECK THAT VALUE OF MEMORY ADDRESS WAS WRITTEN CORRECTLY
 7183 :* DOWNTOWARDS BYTE ADDRESSING.
 7184 7185 006354 004467 006514 JSR R4, INITDN ;INITIALIZE THE MEMORY ADDRESS POINTERS.
 7186 006360 004767 007500 3\$: JSR PC, PHYADR ;GET PHYSICAL ADDRESS INTO R0
 7187 006364 005300 4\$: DEC R0 ;DEC DATA BY 1
 7188 006366 114201 MOVBL -(R2), R1 ;GET THE DATA FROM MEMORY
 7189 006370 120001 CMPBL R0, R1 ;CHECK THE DATA...LO BYTE ONLY VALID.
 7190 006372 001405 BEQ 65\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 (2) 006374 004767 011752 64\$: JSR PC, SPRNTO ;SET UP VALUES FOR ERROR PRINTING.
 (3) 006400 004767 013244 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 (3) 006404 000003 .WORD 3 ;ERROR TYPE CODE.
 (1) 006406 65\$: BIT R5, R2 ;CHECK FOR END OF A BLOCK.
 7191 006406 030502 BNE 4\$;BRANCH IF MORE IN CURRENT BLOCK.
 (1) 006410 001365 JSR PC, MMDOWN ;FIND NEXT BLOCK AND LOOP TO STAG1.
 (1) 006412 004767 007266
 7192 :*****
 7193 (3) :TEST 3 WRITE 1'S COMPLEMENT VALUE OF ADDRESS INTO ADDRESS.
 (4) :* R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)
 (4) :* R1 = DATA READ FROM MEMORY (WAS)
 (4) :* R2 = VIRTUAL ADDRESS
 (4) :* R3 = NOT USED
 (4) :* R4 = NOT USED
 (4) :* R5 = BLOCK BOUNDARY BIT MASK.
 (3) :*****
 (2) 006416 TST3:
 (3) 006416 004567 012216 JSR R5, \$SCOPE ;GO TO SCOPE ROUTINE.
 (3) 006422 000000 000000 .WORD 0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
 7194 :* DOWNTOWARDS WORD ADDRESSING.
 7195 006424 004467 006444 1\$: JSR R4, INITDN ;INITIALIZE THE MEMORY ADDRESS POINTERS.
 7196 006430 004767 007430 JSR PC, PHYADR ;GET PHYSICAL ADDRESS INTO R0
 7197 006434 005100 COM R0 ;COMPLEMENT THE ADR
 7198 006436 062700 000002 2\$: ADD #2, R0 ;+2 TO DATA--ADR GOES DOWN SO COM GOES UP
 7199 006442 010042 MOV R0, -(R2) ;PUT DATA INTO MEMORY
 7200 006444 030502 BIT R5, R2 ;CHECK FOR END OF A BLOCK.

CZOMCGO 0-124K MEMORY EXERCISER, 16X VER
CZOMCG.P11 12-MAR-80 13:07 T3

K 4
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-32
WRITE 1'S COMPLEMENT VALUE OF ADDRESS INTO ADDRESS.

SEQ 0049

(1) 006446 001373
(1) 006450 004767 007230
7201
7202
7203 :* CHECK COMPLEMENT DATA WRITTEN DOWN
7204 006454 004467 005756 :* UPWARDS WORD ADDRESSING.
7205 006460 004767 007400 3\$: JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
7206 006464 005100 JSR PC, PHYADR ;GET PHYSICAL ADDRESS INTO R0
7207 006466 COM R0 ;COMPLEMENT IT
(1) 006466 012201
(2) 006470 020001
(3) 006472 001405
(4) 006474 004767 011676 64\$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
(5) 006500 004767 013144 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
(5) 006504 000002 .WORD 2 ;ERROR TYPE CODE.
(3) 006506 65\$: SUB #2, R0 ;GET THE DATA FROM MEMORY UNDER TEST.
7208 006506 162700 000002 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
7209 006512 030502 BEQ 65\$;BRANCH OVER ERROR CALL IF GOOD DATA.
(1) 006514 001364 BNE 4\$;BRANCH IF MORE IN CURRENT BLOCK.
(1) 006516 004767 006472 JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 3\$.
7210
7211 :*****
(3) :* TEST 4 WRITE BANK # INTO ALL ADDRESSES IN A 4K BANK
(4) :* R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)
(4) :* R1 = DATA READ FROM MEMORY (WAS)
(4) :* R2 = VIRTUAL ADDRESS
(4) :* R3 = NOT USED
(4) :* R4 = NOT USED
(4) :* R5 = BLOCK BOUNDARY BIT MASK.
7212 TST4:
(2) 006522 JSR R5, \$SCOPE ;GO TO SCOPE ROUTINE.
(3) 006522 004567 012112 .WORD 0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
7213 006526 000000
7214 006530 004467 005702 :* UPWARDS BYTE ADDRESSING.
7215 006534 004767 007400 1\$: JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
7216 006540 110022 2\$: JSR PC, BANKNO ;GET THE BANK NUMBER INTO R0
7217 006542 030502 MOV8 R0, (R2)+ ;WRITE BANK # INTO ALL ADDRESSES
(1) 006544 001375 BIT R5, R2 ;CHECK FOR END OF A BLOCK.
(1) 006546 004767 006442 BNE 2\$;BRANCH IF MORE IN CURRENT BLOCK.
JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1\$.
7218
7219 :* CHECK THAT DATA WRITTEN ABOVE CAN BE READ
7220 :* UPWARDS BYTE ADDRESSING.
7221 006552 004467 005660 JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
7222 006556 004767 007356 3\$: JSR PC, BANKNO ;GET THE BANK NUMBER INTO R0
7223 006562 112201 4\$: MOV8 (R2)+, R1 ;READ THE DATA OUT OF MEMORY
(2) 006564 020001 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
(2) 006566 001405 BEQ 65\$;BRANCH OVER ERROR CALL IF GOOD DATA.
(3) 006570 004767 011564 64\$: JSR PC, SPRNT1 ;SET UP VALUES FOR ERROR PRINTING.
(4) 006574 004767 013050 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
(4) 006600 000003 .WORD 3 ;ERROR TYPE CODE.
(2) 006602 65\$: BIT R5, R2 ;GET THE DATA FROM MEMORY UNDER TEST.
7224 006602 030502 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
(1) 006604 001366 BEQ 65\$;BRANCH OVER ERROR CALL IF GOOD DATA.
(1) 006606 004767 006402 JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 3\$.
7225

CZQMC60 0-124K MEMORY EXERCISER. 16K VER
CZQMC6.P11 12-MAR-80 13:07 T5

L 6
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-33
WRITE 1'S COMPLEMENT OF BANK #.

SEQ 005C

7226
 (3)
 (4)
 (4)
 (4)
 (4)
 (4)
 (4)
 (4)
 (3)
 (2) 006612
 (3) 006612 004567 012022
 (3) 006616 000000
 7227 006620 004467 006250
 7229 006624 004767 007310
 7230 006630 005100
 7231 006632 110042
 7232 006634 030502
 (1) 006636 001375
 (1) 006640 004767 007040
 7233
 7234
 7235
 7236 006644 004467 006224
 7237 006650 004767 007264
 7238 006654 005100
 7239 006656 114201
 7240 006660 020001
 (2) 006662 001405
 (3) 006664 004767 011462
 (4) 006670 004767 012754
 (4) 006674 000003
 (2) 006676
 7241 006676 030502
 (1) 006700 001366
 (1) 006702 004767 006776
 7242
 7243
 7244
 7245
 7246
 7247
 7248
 (3)
 (3)
 (4)
 (4)
 (4)
 (4)
 (4)
 (4)
 (4)
 (3)
 (2) 006706
 (3) 006706 004567 011726
 (3) 006712 000000
 7249 006714 016700 172670

```

***** TEST 5 WRITE 1'S COMPLEMENT OF BANK #.
***** R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)
***** R1 = DATA READ FROM MEMORY (WAS)
***** R2 = VIRTUAL ADDRESS
***** R3 = NOT USED
***** R4 = NOT USED
***** R5 = BLOCK BOUNDARY BIT MASK.
***** TST5:
      JSR     R5.   $SCOPE ; GO TO SCOPE ROUTINE.
      WORD    0       ; NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
      ;* DOWNWARDS BYTE ADDRESSING.
      JSR     R4.   INITDN ; INITIALIZE THE MEMORY ADDRESS POINTERS.
      1$:   JSR     PC.   BANKNO ; GET THE BANK NUMBER INTO R0
            COM    R0       ; 1'S COMPLEMENT OF BANK #
            MOVB   R0.   -(R2) ; PUT 1'S COM OF BANK # INTO MEMORY
            BIT    R5.   R2       ; CHECK FOR END OF A BLOCK.
            BNE    2$           ; BRANCH IF MORE IN CURRENT BLOCK.
            JSR     PC.   MMDOWN ; FIND NEXT BLOCK AND LOOP TO 1$.

      ;* CHECK THAT DATA WRITTEN CAN BE READ.
      ;* DOWNWARDS BYTE ADDRESSING.
      JSR     R4.   INITDN ; INITIALIZE THE MEMORY ADDRESS POINTERS.
      3$:   JSR     PC.   BANKNO ; GET THE BANK # INTO R0
            COM    R0       ; SET 1'S COMPLEMENT OF BANK #
            MOVB   -(R2). R1   ; READ DATA OUT OF MEMORY
            CMP    R0.   R1       ; COMPARE THE CHECK WORD WITH THE DATA READ.
            BEQ    65$          ; BRANCH OVER ERROR CALL IF GOOD DATA.
            64$:  JSR     PC.   SPRNTO ; SET UP VALUES FOR ERROR PRINTING.
            JSR     PC.   $ERROR  ; *** ERROR *** (GO TYPE A MESSAGE)
            .WORD   3           ; ERROR TYPE CODE.

      65$:  BIT    R5.   R2       ; CHECK FOR END OF A BLOCK.
            BNE    4$           ; BRANCH IF MORE IN CURRENT BLOCK.
            JSR     PC.   MMDOWN ; FIND NEXT BLOCK AND LOOP TO STAG1.

      SBTTL SECTION 2: WORST CASE NOISE TESTS
***** THESE TESTS WRITE MEMORY WORST CASE NOISE TEST PATTERNS THROUGHOUT
***** MEMORY AND CHECK THAT THEY CAN BE WRITTEN AND READ.
***** TEST 6 WRITE A CONSTANT INTO MEMORY.
***** THE CONSTANT IS USER SELECTABLE (DEFAULT = 0).
***** R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)
***** R1 = DATA READ FROM MEMORY (WAS)
***** R2 = VIRTUAL ADDRESS
***** R3 = NOT USED
***** R4 = NOT USED
***** R5 = BLOCK BOUNDARY BIT MASK.
***** TST6:
      JSR     R5.   $SCOPE ; GO TO SCOPE ROUTINE.
      WORD    0       ; NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
      TST6A: MOV    CONST. R0   ; GET USER CONSTANT
  
```

CZQMCG0 0-124K MEMORY EXERCISER. 16K VER
CZQMCG.P11 12-MAR-80 13:07

M 4
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-34
WRITE A CONSTANT INTO MEMORY.

SEQ 0051

7250 006720 004467 005512 T6
7251 006724 010022 1\$:
7252 006726 030502 JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
(1) 006730 001375 MOV R0, (R2)+ ;WRITE CONSTANT INTO MEMORY.
(1) 006732 004767 006256 BIT R5, R2 ;CHECK FOR END OF A BLOCK.
7253 JSR PC, MMUP ;BRANCH IF MORE IN CURRENT BLOCK.
7254 JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1\$.
7255 ****
(3) :* TEST 7 READ MEMORY AND COMPARE TO CONSTANT.
(4) :* IMPORTANT: THIS TEST SHOULD NOT BE RUN WITHOUT FIRST RUNNING TEST STN.
(3) ****
(2) 006736 004567 011676 TST7:
(3) 006736 004567 011676 JSR RS, \$SCOPE ;GO TO SCOPE ROUTINE.
(3) 006742 000000 .WORD 0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
7258 006744 016700 172640 MOV CONST, R0 ;GET USER CONSTANT
7259 006750 004467 005462 JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
7260 006754 012201 1\$:
(1) 006754 012201 MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
(2) 006756 020001 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
(3) 006760 001405 BEQ 65\$;BRANCH OVER ERROR CALL IF GOOD DATA.
(4) 006762 004767 011410 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
(5) 006766 004767 012656 JSR PC, SERROR ;*** ERROR *** (GO TYPE A MESSAGE)
(5) 006772 000004 .WORD 4 ;ERROR TYPE CODE.
7261 006774 030502 65\$:
(1) 006776 001366 BIT R5, R2 ;CHECK FOR END OF A BLOCK.
(1) 007000 004767 006210 BNE 1\$;BRANCH IF MORE IN CURRENT BLOCK.
JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1\$.
7263 :* SPECIAL CHECK TO SEE IF TEST 6 IS SELECTED THRU THE SWR.
7264 :* ALLOWS THE OPERATOR TO SWITCH BACK AND FORTH BETWEEN TESTS 6 AND 7
7265 :* BY SIMPLY 'TOGGLING' SW00 WHEN SW01, SW02, AND SW08 ARE SET.
7266 007004 032777 000400 172126 BIT #SW08, @SWR ;CHECK THAT LOOP ON TEST BIT SET
7267 007012 001416 BEQ TST10 ;BRANCH IF NOT LOOP ON TEST
7268 007014 017746 172120 MOV @SWR, -(SP) ;GET SWITCH REGISTER DATA.
7269 007020 042716 177740 BIC #177740, (SP) ;CLEAR NON-TEST-NUMBER SWITCHES.
7270 007024 022726 000006 CMP #6, (SP)+ ;CHECK IF TEST 6 IN SWITCHES.
7271 007030 001007 BNE TST10 ;BRANCH IF NOT TEST 6
7272 007032 162767 000001 172042 SUB #1, \$TSTNM ;RESET TEST NUM
7273 007040 162767 000030 172040 SUB #TST7-TST6,\$LPADR ;RESET LOOP ADR
7274 007046 000722 BR TST6A ;GO TO TEST 6
7275 ****
(3) :* TEST 10 WORSE CASE NOISE (PARITY) WORD TESTING
(3) :* CHECK MEMORY WITH A SERIES OF PATTERNS
(3) ****
(2) 007050 004567 011564 TST10:
(3) 007050 004567 011564 JSR RS, \$SCOPE ;GO TO SCOPE ROUTINE.
(3) 007054 000000 .WORD 0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
7278 007056 016704 172552 MOV MPPAT, R4 ;INITIALIZE PATTERN TABLE POINTER
7279 007062 004767 010560 1\$:
JSR PC, CKPMER ;CHECK FOR NON-TRAP PARITY MEMORY ERRORS.
7280 007066 012400 MOV (R4)+, R0 ;GET THE DATA PATTERN.
7281 007070 001420 BEQ TST11 ;BR IF END OF TABLE.
7282 007072 004467 005340 JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
7283 007076 010012 MOV R0, (R2) ;PUT DATA PATTERN INTO MEMORY.
7284 007100 012201 MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
(2) 007102 020001 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
(3) 007104 001405 BEQ 65\$;BRANCH OVER ERROR CALL IF GOOD DATA.
(4) 007106 004767 011264 64\$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.

CZOMCG0 0-124K MEMORY EXERCISER, 16K VER
CZOMCG.P11 12-MAR-80 13:07 T10

N⁶
MACV11 30A(1052) 12-MAR-80 13:10 PAGE 59-35
WORSE CASE NOISE (PARITY) WORD TESTING

SEQ 0052

(5) 007112 004767 012532

JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 4 ;ERROR TYPE CODE.

(5) 007116 000004

65\$:

(3) 007120

BIT R5, R2 ;CHECK FOR END OF A BLOCK.
BNE 2\$;BRANCH IF MORE IN CURRENT BLOCK.
JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 2\$.
BR 1\$;BR BACK TO DO NEXT PATTERN

7285 007120 030502

(1) 007122 001365

(1) 007124 004767 006064

7286 007130 000754

7288

(3)

(3)

(2)

007132

004567 011502

7289

007140

012700 177777

7290

007144

004767 007030

7291

007150

004467 005262

7292

007154

000241

7293

007156

004767 007036

7294

007162

016201 177776

7295

007166

103402

7296

007170

020001

(2)

007172

001405

(3)

007174

004767 011176

(4)

007200

004767 012444

(4)

007204

000005

(2)

007206

030502

7297

(1)

007210

001361

(1)

007212

004767 005776

7298

7299

(3)

(3)

(2)

007216

004567 011416

(3)

007222

000000

7300

007224

005000

7301

007226

004767 006746

7302

007232

004467 005200

7303

007236

000261

7304

007240

004767 006754

7305

007244

016201 177776

7306

007250

103002

7307

007252

020001

(2)

007254

001405

(3)

007256

004767 011114

(4)

007262

004767 012362

(4)

007266

000005

(2)

007270

030502

(1)

007272

001361

(1)

007274

004767 005714

TEST 11 ROTATE A '0' BIT THROUGH A FIELD OF ONES.

TST11:

JSR R5, \$SCOPE : GO TO SCOPE ROUTINE.
 .WORD 0 : NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
 MOV #1, R0 : SET CHECK WORD
 JSR PC, SETCON : PUT THE CONTENTS OF R0 IN ALL MEMORY.
 JSR R4, INITMM : INITIALIZE THE MEMORY ADDRESS POINTERS.
 CLC : CLEAR CARRY BIT IN PSW

1\$: JSR PC, ROTATE : GET RESULT
 MOV -2(R2), R1 : BRANCH IF 'C' BIT WAS SET
 BCS 63\$: COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 64\$: BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 : SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR : *** ERROR *** (GO TYPE A MESSAGE)
 .WORD 5 : ERROR TYPE CODE.

63\$: BIT R5, R2 : CHECK FOR END OF A BLOCK.
 BNE 1\$: BRANCH IF MORE IN CURRENT BLOCK.
 JSR PC, MMUP : FIND NEXT BLOCK AND LOOP TO 1\$.

TEST 12 ROTATE A '1' BIT THROUGH A FIELD OF ZEROS

TST12:

JSR R5, \$SCOPE : GO TO SCOPE ROUTINE.
 .WORD 0 : NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
 CLR R0 : SET CHECK WORD
 JSR PC, SETCON : PUT THE CONTENTS OF R0 IN ALL MEMORY.
 JSR R4, INITMM : INITIALIZE THE MEMORY ADDRESS POINTERS.
 SEC : SET 'C' BIT IN PSW
 JSR PC, ROTATE : GO ROTATE '1' BIT

1\$: MOV -2(R2), R1 : GET RESULT
 BCC 63\$: BRANCH IF 'C' IS CLEAR
 BCS 64\$: COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 65\$: BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 : SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR : *** ERROR *** (GO TYPE A MESSAGE)
 .WORD 5 : ERROR TYPE CODE.

64\$: BIT R5, R2 : CHECK FOR END OF A BLOCK.
 BNE 1\$: BRANCH IF MORE IN CURRENT BLOCK.
 JSR PC, MMUP : FIND NEXT BLOCK AND LOOP TO 1\$.

7310
 (3)
 (3)
 (2) 007300 004567 011334
 (3) 007300 000777 000312
 (3) 007306 000167 000312
 (3) 007312 005000 005000
 7311 007312 005000 005000
 7312 007314 012703 177777
 7313 007320 004467 005112
 7314 007324 004767 006736
 7315 007330 030502 001374
 (1) 007332 001374 004767
 (1) 007334 004767 005654

7316
 7317
 7318
 7319
 7320 007340 005000 005070
 7321 007342 004467 005070
 7322 007346 012704 000100
 7323 007352 012201 020001
 (2) 007354 020001 001405
 (3) 007356 001405 004767
 (4) 007360 004767 011012
 (5) 007364 004767 012260
 (5) 007370 000007 007372
 (3) 007372 012201 020001
 (3) 007376 001405 004767
 (4) 007400 004767 010772
 (5) 007404 004767 012240
 (3) 007410 000007 007412
 (2) 007414 020001 012201
 (3) 007416 001405 004767
 (4) 007420 004767 010752
 (5) 007424 004767 012220
 (5) 007430 000007 007432
 (3) 007432 012201 020001
 (3) 007436 001405 004767
 (4) 007440 004767 010732
 (5) 007444 004767 012200
 (5) 007450 000007 007452
 (3) 007452 005100 005304
 7327 007452 005100 001335
 7328 007454 005304 007460 005100

713 :*****
 :*TEST 13 3 XOR 9 TEST PATTERN.
 :*****
 TST13:
 JSR .WORD 77\$ \$SCOPE ;GO TO SCOPE ROUTINE.
 JSR R5, TST14 ;MINIMUM BLOCK SIZE OF 256. WORDS
 ; REQUIRED FOR THIS TEST.
 ; SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
 ; AVAILABLE FOR TEST.
 .3X9: CLR R0 ;SET UP TEST DATA
 MOV #1, R3 ;SET COM DATA REG
 JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
 1\$: JSR PC, W3X9 ;WRITE 256. WORD BLOCK WITH 3 XOR 9 PAT.
 BIT R5, R2 ;CHECK FOR END OF A BLOCK.
 BNE 1\$, MMUP ;BRANCH IF MORE IN CURRENT BLOCK.
 JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1\$.

7317 :*****
 :* CHECK 3 XOR 9 TEST PATTERN WRITTEN ABOVE
 :*****
 CLR R0 ;SET CHECK WORD
 JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
 11\$: MOV #64, R4 ;SET 256. WORD COUNTER
 12\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 65\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 ;ERROR TYPE CODE.

64\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 65\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 ;ERROR TYPE CODE.

65\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 67\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 ;ERROR TYPE CODE.

66\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 67\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 ;ERROR TYPE CODE.

67\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 69\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 ;ERROR TYPE CODE.

68\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 69\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 ;ERROR TYPE CODE.

69\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 71\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 ;ERROR TYPE CODE.

70\$: COM R0 ;COMPLEMENT CHECK WORD
 DEC R4 ;DECREMENT 256. WORD COUNTER
 BNE 1\$, COM R0 ;COMPLEMENT CHECK WORD

CZOMCG0 0-124K MEMORY EXERCISER, 16K VER
CZOMCG,P11 12-MAR-80 13:07 T13

D 5
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-38
3 XOR 9 TEST PATTERN.

SEQ 005'

7331	007462	030502			BIT BNE JSR	R5 11\$ PC.	R2 MMJUP	:CHECK FOR END OF A BLOCK. :BRANCH IF MORE IN CURRENT BLOCK. :FIND NEXT BLOCK AND LOOP TO 11\$.
(1)	007466	001330						
(1)	007466	004767	005522					
7332								
7333								
7334								;;* CHECK, COM, CHECK, COM, CHECK 3 XOR 9 PATTERN WRITTEN ABOVE.
7335								;;*
7336	007472	005000			CLR JSR	R0 R4	INITMM	:INITIALIZE THE MEMORY ADDRESS POINTERS.
7337	007474	004467	004736		21\$: MOV	#64..	R4	:SET 256. WORD COUNTER
7338	007500	012704	000100		22\$: MOV	#4,	R3	:SET 4 WORD COUNTER
7339	007504	012703	000004		23\$: MOV	(R2)+,	R1	:GET THE DATA FROM MEMORY UNDER TEST.
7340	007510	012201			CMP	R0,	R1	:COMPARE THE CHECK WORD WITH THE DATA READ.
(1)	007512	020001			BEQ	73\$:BRANCH OVER ERROR CALL IF GOOD DATA.
(3)	007514	001405			72\$: JSR	PC,	SPRNT2	:SET UP VALUES FOR ERROR PRINTING.
(4)	007516	004767	010654		JSR	PC,	\$ERROR	:*** ERROR *** (GO TYPE A MESSAGE)
(5)	007522	004767	012122		.WORD	7		:ERROR TYPE CODE.
(3)	007526	000007			73\$: COM	R0		:COMPLEMENT CHECK WORD
7341	007530	005100			COM	-(R2)		:COMPLEMENT TEST DATA
7342	007532	005142			MOV	(R2)+,	R1	:GET THE DATA FROM MEMORY UNDER TEST.
7343	007534	012201			CMP	R0	R1	:COMPARE THE CHECK WORD WITH THE DATA READ.
(2)	007536	020001			BEQ	75\$:BRANCH OVER ERROR CALL IF GOOD DATA.
(3)	007540	001405			74\$: JSR	PC,	SPRNT2	:SET UP VALUES FOR ERROR PRINTING.
(4)	007542	004767	010630		JSR	PC,	\$ERROR	:*** ERROR *** (GO TYPE A MESSAGE)
(5)	007546	004767	012076		.WORD	7		:ERROR TYPE CODE.
(3)	007552	000007			75\$: COM	R0		:COMPLEMENT CHECK WORD
7344	007554	005100			COM	-(R2)		:COMPLEMENT TEST DATA
7345	007556	005142			MOV	(R2)+,	R1	:GET THE DATA FROM MEMORY UNDER TEST.
7346	007560	012201			CMP	R0	R1	:COMPARE THE CHECK WORD WITH THE DATA READ.
(2)	007562	020001			BEQ	77\$:BRANCH OVER ERROR CALL IF GOOD DATA.
(3)	007564	001405			76\$: JSR	PC,	SPRNT2	:SET UP VALUES FOR ERROR PRINTING.
(4)	007566	004767	010604		JSR	PC,	\$ERROR	:*** ERROR *** (GO TYPE A MESSAGE)
(5)	007572	004767	012052		.WORD	7		:ERROR TYPE CODE.
(3)	007576	000007			77\$: DEC	R3		:DECREMENT 4 WORD COUNTER
7347	007600	005303			BNE	23\$:BR IF NOT DONE.
7348	007602	001342			COM	R0		:COMPLEMENT CHECK WORD
7349	007604	005100			DEC	R4		:DECREMENT 256. WORD COUNTER
7350	007606	005304			BNE	22\$:BR IF NOT DONE.
7351	007610	001335			COM	R0		:COMPLEMENT CHECK WORD
7352	007612	005100			BIT	R5,	R2	:CHECK FOR END OF A BLOCK.
7353	007614	030502			BNE	21\$:BRANCH IF MORE IN CURRENT BLOCK.
(1)	007616	001330			JSR	PC,	MMJUP	:FIND NEXT BLOCK AND LOOP TO 21\$.
(1)	007620	004767	005370					

7355
 (3)
 (3)
 (2) 007624 004567 011010
 (3) 007624 000777 T14
 (3) 007630 000777
 (3) 007632 000167 000316
 (3) 007636 012700 177777
 (3) 007642 005003
 (3) 007644 004467 004566
 (3) 007650 004767 006412
 (1) 007654 030502
 (1) 007656 001374
 (1) 007660 004767 005330
 7361
 7362
 7363
 7364
 7365
 7366 007664 012700 177777
 7367 007670 004467 004542
 7368 007674 012704 000100
 7369 007700 012201
 (2) 007702 020001
 (3) 007704 001405
 (4) 007706 004767 010464
 (5) 007712 004767 011732
 (5) 007716 000007
 (3) 007720
 7370 007720 012201
 (2) 007722 020001
 (3) 007724 001405
 (4) 007726 004767 010444
 (5) 007732 004767 011712
 (5) 007736 000007
 (3) 007740
 7371 007740 012201
 (2) 007742 020001
 (3) 007744 001405
 (4) 007746 004767 010424
 (5) 007752 004767 011672
 (5) 007756 000007
 (3) 007760
 7372 007760 012201
 (2) 007762 020001
 (3) 007764 001405
 (4) 007766 004767 010404
 (5) 007772 004767 011652
 (5) 007776 000007
 (3) 010000
 7373 010000 005100
 7374 010002 005304
 7375 010004 001335

 TEST 14 COMPLEMENT 3 XOR 9 TEST PATTERN

TST14:
 JSR R5 77\$ \$SCOPE : GO TO SCOPE ROUTINE.
 .WORD : MINIMUM BLOCK SIZE OF 256. WORDS
 REQUIRED FOR THIS TEST.
 SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
 AVAILABLE FOR TEST.

1\$: MOV #1, R0 : SET UP TEST DATA
 CLR R3 : SET COM DATA REG
 JSR R4, INITMM : INITIALIZE THE MEMORY ADDRESS POINTERS.
 JSR PC, W3X9 : WRITE 256. WORD BLOCK WITH 3 XOR 9 PAT.
 BIT R5, R2 : CHECK FOR END OF A BLOCK.
 BNE 1\$: BRANCH IF MORE IN CURRENT BLOCK.
 JSR PC, MMUP : FIND NEXT BLOCK AND LOOP TO 1\$.

 CHECK COMPLEMENTED 3 XOR 9 TEST PATTERN WRITTEN ABOVE.

11\$: MOV #64, R4 : SET CHECK WORD
 JSR R6, INITMM : INITIALIZE THE MEMORY ADDRESS POINTERS.
 SET 256. WORD COUNTER

12\$: MOV (R2)+, R1 : GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 : COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 65\$: BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 : SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR : *** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 : ERROR TYPE CODE.

64\$: MOV (R2)+, R1 : GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 : COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 65\$: BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 : SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR : *** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 : ERROR TYPE CODE.

65\$: MOV (R2)+, R1 : GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 : COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 67\$: BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 : SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR : *** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 : ERROR TYPE CODE.

67\$: MOV (R2)+, R1 : GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 : COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 69\$: BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 : SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR : *** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 : ERROR TYPE CODE.

68\$: MOV (R2)+, R1 : GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 : COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 70\$: BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 : SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR : *** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 : ERROR TYPE CODE.

69\$: MOV (R2)+, R1 : GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 : COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 71\$: BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 : SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR : *** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 : ERROR TYPE CODE.

70\$: MOV (R2)+, R1 : GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 : COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 71\$: BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 : SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR : *** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 : ERROR TYPE CODE.

71\$: COM R0 : COMPLEMENT CHECK WORD
 DEC R4 : DECREMENT 256. WORD COUNTER
 BNE 12\$

CZQMCG0 0-124K MEMORY EXERCISER, 16K VER
CZQMCG.P11 12-MAR-80 13:07 T14

F 5
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-40
COMPLEMENT 3 XOR 9 TEST PATTERN

SEQ 005'

7376 010006 005100
7377 010010 030502
(1) 010012 001330
(1) 010014 004767 005174

7378
7379
7380 :* CHECK, COM, CHECK, COM, CHECK COMPLEMENTED 3 XOR 9 PATTERN.
7381
7382 010020 012700 177777
7383 010024 004467 004406
7384 010030 012704 000100
7385 010034 012703 000004
7386 010040
(1) 010040 012201
(2) 010042 020001
(3) 010044 001405
(4) 010046 004767 010324
(5) 010052 004767 011572
(5) 010056 000007
(3) 010060
7387 010060 005100
7388 010062 005142
7389 010064 012201
(2) 010066 020001
(3) 010070 001405
(4) 010072 004767 010300
(5) 010076 004767 011546
(5) 010102 000007
(3) 010104
7390 010104 005100
7391 010106 005142
7392 010110 012201
(2) 010112 020001
(3) 010114 001405
(4) 010116 004767 010254
(5) 010122 004767 011522
(5) 010126 000007
(3) 010130
7393 010130 005303
7394 010132 001342
7395 010134 005100
7396 010136 005304
7397 010140 001335
7398 010142 005100
7399 010144 030502
(1) 010146 001330
(1) 010150 004767 005040

COM R0 ;COMPLEMENT CHECK WORD
BIT R5 R2 ;CHECK FOR END OF A BLOCK.
BNE 11\$;BRANCH IF MORE IN CURRENT BLOCK.
JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 11\$.

***** CHECK, COM, CHECK, COM, CHECK COMPLEMENTED 3 XOR 9 PATTERN.

MOV #1, R0 ;SET UP CHECK WORD.
JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
21\$: MOV #64, R4 ;SET 256. WORD COUNTER
22\$: MOV #4, R3 ;SET 4 WORD COUNTER
23\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 73\$;BRANCH OVER ERROR CALL IF GOOD DATA.
72\$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.
73\$: COM R0 ;COMPLEMENT CHECK WORD
COM -(R2) ;COMPLEMENT TEST DATA
MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 75\$;BRANCH OVER ERROR CALL IF GOOD DATA.
74\$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.
75\$: COM R0 ;COMPLEMENT CHECK WORD
COM -(R2) ;COMPLEMENT TEST DATA
MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 77\$;BRANCH OVER ERROR CALL IF GOOD DATA.
76\$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.
77\$: DEC R3 ;DECREMENT 4 WORD COUNTER
BNE 23\$;BR IF NOT DONE.
COM R0 ;COMPLEMENT CHECK WORD
DEC R4 ;DECREMENT 256. WORD COUNTER
BNE 22\$;BR IF NOT DONE.
COM R0 ;COMPLEMENT CHECK WORD
BIT R5, R2 ;CHECK FOR END OF A BLOCK.
BNE 21\$;BRANCH IF MORE IN CURRENT BLOCK.
JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 21\$.

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER
CZOMCC.P11 12-MAR-80 13:07

G 5
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-41
MODIFIED 3 XOR 9 PATTERN FOR PARITY MEMORY

SEQ 0058

7401
(3)
(3)
(2) 010154 :*****
(3) 010154 004567 010460 ;TEST 15 MODIFIED 3 XOR 9 PATTERN FOR PARITY MEMORY
(3) 010160 000777 :*****
(3) 010162 000167 000610 TST15:
JSR .WORD R5, \$SCOPE :GO TO SCOPE ROUTINE.
MOV #401, R0 :MINIMUM BLOCK SIZE OF 256. WORDS
MOV #-1, R3 :REQUIRED FOR THIS TEST.
JSR R4, INITMM :SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
JSR PC, W3X9 :AVAILABLE FOR TEST.
BIT R5, R2 :SET UP PARITY 'ALL ZEROS' PATTERN
BNE 1\$:SET COM DATA REG
JSR PC, MMUP :INITIALIZE THE MEMORY ADDRESS POINTERS.
1\$: JSR PC, W3X9 :WRITE 256. WORD BLOCK WITH 3 XOR 9 PAT.
BIT R5, R2 :CHECK FOR END OF A BLOCK.
BNE 1\$:BRANCH IF MORE IN CURRENT BLOCK.
JSR PC, MMUP :FIND NEXT BLOCK AND LOOP TO 1\$.

7402 010166 012700 000401
7403 010172 012703 177777
7404 010176 004467 004234
7405 010202 004767 006060
7406 010206 030502
(1) 010210 001374
(1) 010212 004767 004776

7407
7408
7409 :*****
7410 :* CHECK PARITY 3 XOR 9 PATTERN WRITTEN ABOVE.
7411 010216 012700 000401
7412 010222 012703 177777
7413 010226 004467 004204
7414 010232 012704 000100
7415 010236
(1) 010236 012201
(2) 010240 020001
(3) 010242 001405
(4) 010244 004767 010126
(5) 010250 004767 011374
(5) 010254 000007
(3) 010256 012201
(2) 010260 020001
(3) 010262 001405
(4) 010264 004767 010106
(5) 010270 004767 011354
(5) 010274 000007
(3) 010276 012201
(2) 010300 020001
(3) 010302 001405
(4) 010304 004767 010066
(5) 010310 004767 011334
(5) 010314 000007
(3) 010316 012201
(2) 010320 020001
(3) 010322 001405
(4) 010324 004767 010046
(5) 010330 004767 011314
(5) 010334 000007
(3) 010336 010046
(1) 010340 010300
(1) 010342 012603

11\$: MOV #401, R0 :RESET PARITY 'ALL ZEROS' PATTERN.
MOV #-1, R3 :RESET PARITY ALL ONES PATTERN.
JSR R4, INITMM :INITIALIZE THE MEMORY ADDRESS POINTERS.
MOV #64., R4 :SET 256. WORD COUNTER

12\$: MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 65\$:BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR 7 :*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 :ERROR TYPE CODE.

64\$: MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 65\$:BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR 7 :*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 :ERROR TYPE CODE.

65\$: MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 67\$:BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR 7 :*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 :ERROR TYPE CODE.

66\$: MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 67\$:BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR 7 :*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 :ERROR TYPE CODE.

67\$: MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 69\$:BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR 7 :*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 :ERROR TYPE CODE.

68\$: MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 69\$:BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR 7 :*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 :ERROR TYPE CODE.

69\$: MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 71\$:BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR 7 :*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 :ERROR TYPE CODE.

70\$: MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 71\$:BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR 7 :*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 :ERROR TYPE CODE.

71\$: MOV R0, -(SP) :SAVE R0
MOV R3, R0 :PUT R3 INTO R0
MOV (SP)+, R3 :PUT SAVED R0 INTO R3

7420 010344 005304
 7421 010346 001333
 7422 010350 010046
 (1) 010352 010300
 (1) 010354 012603
 7423 010356 030502
 (1) 010360 001324
 (1) 010362 004767 004626

7424
 7425
 7426 ;* CHECK, COM, CHECK, COM, CHECK PARITY 3 XOR 9 PATTERN.
 7427 ;*
 7428 010366 012700 000401
 7429 010372 012703 177777
 7430 010376 004467 004034
 7431 010402 012704 000100

7432 010406 012201
 (2) 010410 020001
 (3) 010412 001405
 (4) 010414 004767 007756
 (5) 010420 004767 011224
 (5) 010424 000007
 (3) 010426

7433 010426 005100
 7434 010430 005142
 7435 010432 012201
 (2) 010434 020001
 (3) 010436 001405
 (4) 010440 004767 007732
 (5) 010444 004767 011200
 (5) 010450 000007
 (3) 010452

7436 010452 005100
 7437 010454 005142
 7438 010456 012201
 (2) 010460 020001
 (3) 010462 001405
 (4) 010464 004767 007706
 (5) 010470 004767 011154
 (5) 010474 000007
 (3) 010476

7439 010476 012201
 (2) 010500 020001
 (3) 010502 001405
 (4) 010504 004767 007666
 (5) 010510 004767 011134
 (5) 010514 000007
 (3) 010516

7440 010516 005100
 7441 010520 005142
 7442 010522 012201
 (2) 010524 020001
 (3) 010526 001405
 (4) 010530 004767 007642
 (5) 010534 004767 011110

715

DEC R4 :COUNT 256. WORDS
 BNE 12\$:BRANCH IF MORE
 MOV R0, -(SP) :SAVE R0
 MOV R3, R0 :PUT R3 INTO R0
 MOV (SP)+, R3 :PUT SAVED R0 INTO R3
 BIT RS, R2 :CHECK FOR END OF A BLOCK.
 BNE 11\$:BRANCH IF MORE IN CURRENT BLOCK.
 JSR PC, MMUP :FIND NEXT BLOCK AND LOOP TO 11\$.

21\$: MOV #401, R0 :SET UP PARITY 'ALL ZEROS' PATTERN.
 22\$: MOV #-1, R3 :SET UP ALL ONES PATTERN.
 JSR R4, INITMM :INITIALIZE THE MEMORY ADDRESS POINTERS.
 MOV #64, R4 :SET 256. WORD COUNTER

72\$: MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 73\$:BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR :*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 :ERROR TYPE CODE.

73\$: COM R0 :COMPLEMENT CHECK WORD
 COM -(R2) :COMPLEMENT TEST DATA
 MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 75\$:BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR :*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 :ERROR TYPE CODE.

74\$: COM R0 :COMPLEMENT CHECK WORD
 COM -(R2) :RESTORE DATA
 MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 77\$:BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR :*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 :ERROR TYPE CODE.

75\$: COM R0 :COMPLEMENT CHECK WORD
 COM -(R2) :RESTORE DATA
 MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 77\$:BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR :*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 :ERROR TYPE CODE.

76\$: COM R0 :COMPLEMENT CHECK WORD
 COM -(R2) :RESTORE DATA
 MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 79\$:BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR :*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 :ERROR TYPE CODE.

77\$: MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 79\$:BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR :*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 :ERROR TYPE CODE.

78\$: COM R0 :COMPLEMENT CHECK WORD
 COM -(R2) :COMPLEMENT TEST DATA
 MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 81\$:BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR :*** ERROR *** (GO TYPE A MESSAGE)

79\$: COM R0 :COMPLEMENT CHECK WORD
 COM -(R2) :COMPLEMENT TEST DATA
 MOV (R2)+, R1 :GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 81\$:BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 :SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR :*** ERROR *** (GO TYPE A MESSAGE)

CZQMCGU 0-124K MEMORY EXERCISER, 16K VER
CZQMCG.P11 12-MAR-80 13:07

15
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-43
MODIFIED 3 XOR 9 PATTERN FOR PARITY MEMORY

SEQ 0061

(5) 010540 000007 .WORD 7 ;ERROR TYPE CODE.
(3) 010542 005100 81\$: COM R0 ;COMPLEMENT CHECK WORD
7443 010542 005100 COM -(R2) ;RESTORE DATA
7444 010544 005142 MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
7445 010546 012201 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
(2) 010550 020001 BEQ 83\$;BRANCH OVER ERROR CALL IF GOOD DATA.
(3) 010552 001405 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
(4) 010554 004767 007616 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
(5) 010560 004767 011064 .WORD 7 ;ERROR TYPE CODE.
(5) 010564 000007
(3) 010566 012201 83\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
(2) 010570 020001 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
(3) 010572 001405 BEQ 85\$;BRANCH OVER ERROR CALL IF GOOD DATA.
(4) 010574 004767 007576 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
(5) 010600 004767 011044 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
(5) 010604 000007 .WORD 7 ;ERROR TYPE CODE.
7446 010566 012201 84\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
(2) 010570 020001 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
(3) 010572 001405 BEQ 85\$;BRANCH OVER ERROR CALL IF GOOD DATA.
(4) 010574 004767 007576 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
(5) 010600 004767 011044 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
(5) 010604 000007 .WORD 7 ;ERROR TYPE CODE.
7447 010606 005100 85\$: COM R0 ;COMPLEMENT CHECK WORD
7448 010610 005142 COM -(R2) ;COMPLEMENT TEST DATA
7449 010612 012201 MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
(2) 010614 020001 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
(3) 010616 001405 BEQ 87\$;BRANCH OVER ERROR CALL IF GOOD DATA.
(4) 010620 004767 007552 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
(5) 010624 004767 011020 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
(5) 010630 000007 .WORD 7 ;ERROR TYPE CODE.
(3) 010632 005100 86\$: COM R0 ;COMPLEMENT CHECK WORD
7450 010632 005100 COM -(R2) ;RESTORE DATA
7451 010634 005142 MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
7452 010636 012201 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
(2) 010640 020001 BEQ 89\$;BRANCH OVER ERROR CALL IF GOOD DATA.
(3) 010642 001405 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
(4) 010644 004767 007526 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
(5) 010650 004767 010774 .WORD 7 ;ERROR TYPE CODE.
(5) 010654 000007
(3) 010656 012201 87\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
(2) 010660 020001 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
(3) 010662 001405 BEQ 89\$;BRANCH OVER ERROR CALL IF GOOD DATA.
(4) 010664 004767 007506 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
(5) 010670 004767 010754 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
(5) 010674 000007 .WORD 7 ;ERROR TYPE CODE.
(3) 010676 005100 89\$: COM R0 ;COMPLEMENT CHECK WORD
7453 010656 012201 COM -(R2) ;COMPLEMENT TEST DATA
7454 010676 005100 MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
7455 010700 005142 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
7456 010702 012201 BEQ 91\$;BRANCH OVER ERROR CALL IF GOOD DATA.
(2) 010704 020001 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
(3) 010706 001405 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
(4) 010710 004767 007462 .WORD 7 ;ERROR TYPE CODE.
(5) 010714 004767 010730 90\$: COM R0 ;COMPLEMENT CHECK WORD
7457 010722 005100 COM -(R2) ;RESTORE DATA
7458 010724 005142 MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
7459 010726 012201 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
(2) 010730 020001

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER
CZOMCG.P11 12-MAR-80 13:07

J 5
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-44
MODIFIED 3 XOR 9 PATTERN FOR PARITY MEMORY

SEQ 006

(3) 010732 001405
(4) 010734 004767 007436
(5) 010740 004767 010704
(5) 010744 000007
(3) 010746
7460 010746 010046
(1) 010750 010300
(1) 010752 012603
7461 010754 005304
7462 010756 001213
7463 010760 010046
(1) 010762 010300
(1) 010764 012603
7464 010766 030502
(1) 010770 001204
(1) 010772 004767 004216

94\$: BEQ 95\$ JSR PC, SPRNT2 ;BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC, SERROR ;SET UP VALUES FOR ERROR PRINTING.
.WORD 7 ;*** ERROR *** (GO TYPE A MESSAGE)
;ERROR TYPE CODE.

95\$: MOV R0, -(SP) ;SAVE R0
MOV R3, R0 ;PUT R3 INTO R0
MOV (SP)+, R3 ;PUT SAVED R0 INTO R3
DEC R4 ;DECREMENT 256. WORD COUNTER
BNE 22\$;BRANCH IF MORE.
MOV R0, -(SP) ;SAVE R0
MOV R3, R0 ;PUT R3 INTO R0
MOV (SP)+, R3 ;PUT SAVED R0 INTO R3
BIT R5, R2 ;CHECK FOR END OF A BLOCK.
BNE 21\$;BRANCH IF MORE IN CURRENT BLOCK.
JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 21\$.

7465
7466 ;*****
(3) ;*TES: 16 COMPLEMENT PARITY 3 XOR 9 TEST PATTERN.
(3) ;*****
(2) 010776
(3) 010776 004567 007636
(3) 011002 000777
(3) 011004 000167 000610

TST16: JSR R5, \$SCOPE ;GO TO SCOPE ROUTINE.
.WORD 77\$;MINIMUM BLOCK SIZE OF 256. WORDS
;REQUIRED FOR THIS TEST.
JMP TST17 ;SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
;AVAILABLE FOR TEST.

7467 011010 012700 177777
7468 011014 012703 000401
7469 011020 004467 003412
7470 011024 004767 005236
7471 011030 030502
(1) 011032 001374
(1) 011034 004767 004154

1\$: MOV #-1, R0 ;SET UP ALL ONES PATTERN
MOV #401, R3 ;SET UP PARITY "ALL ZEROS" PATTERN
JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
JSR PC, W3X9 ;WRITE 256. WORD BLOCK WITH 3 XOR 9 PAT.
BIT R5, R2 ;CHECK FOR END OF A BLOCK.
BNE 1\$;BRANCH IF MORE IN CURRENT BLOCK.
JSR PC, MMUP ;FIND NEXT BLOCK AND JOP TO 1\$.

7472
7473
7474 ;* CHECK COMPLEMENT PARITY 3 XOR 9 PATTERN WRITTEN ABOVE.
7475 ;*****
7476 011040 012700 177777
7477 011044 012703 000401
7478 011050 004467 003362
7479 011054 012704 000100
7480 011060
(1) 011060 012201
(2) 011062 020001
(3) 011064 001405
(4) 011066 004767 007304
(5) 011072 004767 010552
(5) 011076 000007
(3) 011100
7481 011100 012201
(2) 011102 020001
(3) 011104 001405
(4) 011106 004767 007264
(5) 011112 004767 010532
(5) 011116 000007
(3) 011120

11\$: MOV #-1, R0 ;SET UP ALL ONES PATTERN
MOV #401, R3 ;SET UP PARITY "ALL ZEROS" PATTERN
JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
MOV #64.., R4 ;SET 256. WORD COUNTER

12\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 65\$;BRANCH OVER ERROR CALL IF GOOD DATA.

64\$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, SERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.

65\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 67\$;BRANCH OVER ERROR CALL IF GOOD DATA.

66\$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, SERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.

67\$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, SERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.

7482 011120 012201
 (2) 011122 020001
 (3) 011124 001405
 (4) 011126 004767 007244
 (5) 011132 004767 010512
 (5) 011136 000007
 (3) 011140
 7483 011140 012201
 (2) 011142 020001
 (3) 011144 001405
 (4) 011146 004767 007224
 (5) 011152 004767 010472
 (5) 011156 000007
 (3) 011160
 7484 011160 010046
 (1) 011162 010300
 (1) 011164 012603
 7485 011166 005304
 7486 011170 001333
 7487 011172 010046
 (1) 011174 010300
 (1) 011176 012603
 7488 011200 030502
 (1) 011202 001324
 (1) 011204 004767 004004

68\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 69\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 ;ERROR TYPE CODE.

69\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 71\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 ;ERROR TYPE CODE.

70\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 71\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 ;ERROR TYPE CODE.

71\$: MOV R0, -(SP) ;SAVE R0
 MOV R3, R0 ;PUT R3 INTO R0
 MOV (SP)+, R3 ;PUT SAVED R0 INTO R3
 DEC R4 ;COUNT 256. WORDS
 BNE 12\$;BRANCH IF MORE
 MOV R0, -(SP) ;SAVE R0
 MOV R3, R0 ;PUT R3 INTO R0
 MOV (SP)+, R3 ;PUT SAVED R0 INTO R3
 BIT R5, R2 ;CHECK FOR END OF A BLOCK.
 BNE 11\$;BRANCH IF MORE IN CURRENT BLOCK.
 JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 11\$.

7489

7490 :*****
 7491 :* CHECK, COM, CHECK, COM, CHECK COMPLEMENTED PARITY 3 XOR 9 PATTERN.
 7492 :*****

7493 011210 012700 177777
 7494 011214 012703 000401
 7495 011220 004467 003212
 7496 011224 012704 000100
 7497 011230
 (1) 011230 012201
 (2) 011232 020001
 (3) 011234 001405
 (4) 011236 004767 007134
 (5) 011242 004767 010402
 (5) 011246 000007
 (3) 011250
 7498 011250 005100
 7499 011252 005142
 7500 011254 012201
 (2) 011256 020001
 (3) 011260 001405
 (4) 011262 004767 007110
 (5) 011266 004767 010356
 (5) 011272 000007
 (3) 011274
 7501 011274 005100
 7502 011276 005142
 7503 011300 012201
 (2) 011302 020001
 (3) 011304 001405
 (4) 011306 004767 007064

21\$: MOV #1, R0 ;SET UP ALL ONES PATTERN
 MOV #401, R3 ;SET UP PARITY "ALL ZEROS" PATTERN
 JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
 22\$: MOV #64., R4 ;SET 256. WORD COUNTER

72\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 73\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 ;ERROR TYPE CODE.

73\$: COM R0 ;COMPLEMENT CHECK WORD
 COM -(R2) ;COMPLEMENT TEST DATA
 MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 75\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 .WORD 7 ;ERROR TYPE CODE.

74\$: COM R0 ;COMPLEMENT CHECK WORD
 COM -(R2) ;RESTORE DATA
 MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 77\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.

75\$: COM R0 ;COMPLEMENT CHECK WORD
 COM -(R2) ;RESTORE DATA
 MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 77\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.

76\$: COM R0 ;COMPLEMENT CHECK WORD
 COM -(R2) ;RESTORE DATA
 MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 BEQ 77\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.

CZQMCG0 0-124K MEMORY EXERCISER, 16K VER
CZQMCG.P11 12-MAR-80 13:07 T16

L 5
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-46
COMPLEMENT PARITY 3 XOR 9 TEST PATTERN.

SEQ 0065

(5) 011312 004767 010332
(5) 011316 000007
(3) 011320
7504 011320 012201
(2) 011322 020001
(3) 011324 001405
(4) 011326 004767 007044
(5) 011332 004767 010312
(5) 011336 000007
(3) 011340
7505 011340 005100
7506 011342 005142
7507 011344 012201
(2) 011346 020001
(3) 011350 001405
(4) 011352 004767 007020
(5) 011356 004767 010266
(5) 011362 000007
(3) 011364
7508 011364 005100
7509 011366 005142
7510 011370 012201
(2) 011372 020001
(3) 011374 001405
(4) 011376 004767 006774
(5) 011402 004767 010242
(5) 011406 000007
(3) 011410
7511 011410 012201
(2) 011412 020001
(3) 011414 001405
(4) 011416 004767 006754
(5) 011422 004767 010222
(5) 011426 000007
(3) 011430
7512 011430 005100
7513 011432 005142
7514 011434 012201
(2) 011436 020001
(3) 011440 001405
(4) 011442 004767 006730
(5) 011446 004767 010176
(5) 011452 000007
(3) 011454
7515 011454 005100
7516 011456 005142
7517 011460 012201
(2) 011462 020001
(3) 011464 001405
(4) 011466 004767 006704
(5) 011472 004767 010152
(5) 011476 000007
(3) 011500
7518 011500 012201
(2) 011502 020001
(3) 011504 001405

77\$: JSR PC. \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.
MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 79\$;BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC. SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC. \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.
COM R0 ;COMPLEMENT CHECK WORD
COM -(R2) ;COMPLEMENT TEST DATA
MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 81\$;BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC. SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC. \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.
COM R0 ;COMPLEMENT CHECK WORD
COM -(R2) ;RESTORE DATA
MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 83\$;BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC. SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC. \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.
MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 85\$;BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC. SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC. \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.
COM R0 ;COMPLEMENT CHECK WORD
COM -(R2) ;COMPLEMENT TEST DATA
MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 87\$;BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC. SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC. \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.
COM R0 ;COMPLEMENT CHECK WORD
COM -(R2) ;RESTORE DATA
MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 89\$;BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC. SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC. \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.
MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 91\$;BRANCH OVER ERROR CALL IF GOOD DATA.

CZQMCG0 0-124K MEMORY EXERCISER, 16K VER
CZQMCG.P11 12-MAR-80 13:07

M 5
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-47
COMPLEMENT PARITY 3 XOR 9 TEST PATTERN.

SEQ 0064

(4) 011506 004767 006664 T16
(5) 011512 004767 010132
(5) 011516 000007
(3) 011520
7519 011520 005100
7520 011522 005142
7521 011524 012201
(2) 011526 020001
(3) 011530 001405
(4) 011532 004767 006640
(5) 011536 004767 010106
(5) 011542 000007
(3) 011544
7522 011544 005100
7523 011546 005142
7524 011550 012201
(2) 011552 020001
(3) 011554 001405
(4) 011556 004767 006614
(5) 011562 004767 010062
(5) 011566 000007
(3) 011570
7525 011570 010046
(1) 011572 010300
(1) 011574 012603
7526 011576 005304
7527 011600 001213
7528 011602 010046
(1) 011604 010300
(1) 011606 012603
7529 011610 030502
(1) 011612 001204
(1) 011614 004767 003374

90\$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.
91\$: COM R0 ;COMPLEMENT CHECK WORD
COM -(R2) ;COMPLEMENT TEST DATA
MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 93\$;BRANCH OVER ERROR CALL IF GOOD DATA.
92\$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.
93\$: COM R0 ;COMPLEMENT CHECK WORD
COM -(R2) ;RESTORE DATA
MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 95\$;BRANCH OVER ERROR CALL IF GOOD DATA.
94\$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 7 ;ERROR TYPE CODE.
95\$: MOV R0, -(SP) ;SAVE R0
MOV R3, R0 ;PUT R3 INTO R0
MOV (SP)+, R3 ;PUT SAVED R0 INTO R3
DEC R4 ;DECREMENT 256. WORD COUNTER
BNE 22\$;BRANCH IF MORE.
MOV R0, -(SP) ;SAVE R0
MOV R3, R0 ;PUT R3 INTO R0
MOV (SP)+, R3 ;PUT SAVED R0 INTO R3
BIT R5, R2 ;CHECK FOR END OF A BLOCK.
BNE 21\$;BRANCH IF MORE IN CURRENT BLOCK.
JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 21\$.

7538 :*****
 (3) :* TEST 17 WORSE CASE NOISE PARITY BYTE TESTING
 (4) :* CHECK PARITY MEMORY WITH A SERIES OF BYTE PATTERNS
 (4) :* 1) FORCE WRONG PARITY IN EACH BYTE OF PARITY MEMORY
 (4) :* 2) READ IT BACK WITH ACTION ENABLE SET, MAKING SURE THAT A TRAP OCCURS
 (4) :* 3) WRITE GOOD PARITY AND MAKE SURE NO TRAP OCCURS WHEN IT IS READ
 (4) :* 4) MAKE SURE THE ERROR ADDRESS BITS (CSR BITS <11-5>) ARE CORRECT
 (3) :*****
 (2) 011620 TST17:
 (3) 011620 004567 007014 JSR R5, \$SCOPE ;GO TO SCOPE ROUTINE.
 (3) 011624 000000 170444 .WORD 0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
 7539 011626 005767 170444 WWPB0: TST MPRX ;CHECK FOR ANY PARITY MEMORY.
 7540 011632 001404 BEQ 1\$;BR IF NO PARITY MEMORY.
 7541 011634 032777 000100 167276 BIT #SW06, @SWR ;CHECK FORINHIBIT PARITY SWITCH.
 7542 011642 001402 BEQ 2\$;BR IF NOT SET.
 7543 011644 000167 000622 1\$: JMP TST20 ;SKIP THIS TEST IF NO PARITY MEMORY PRESENT.
 7544 011650 005000 2\$: CLR R0 ;ZERO TO BE PUT IN ALL MEMORY.
 7545 011652 004767 004322 JSR PC, SETCON ;ROUTINE TO LOAD ALL MEMORY.
 7546 011656 004467 002554 JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
 7547
 7548 011662 036767 167656 167650 WWPBYT: BIT BITPT, PMEMAP ;CHECK IF CURRENT BANK HAS PARITY MEMORY.
 7549 011670 001010 BNE 2\$;BR IF PARITY MEM.
 7550 011672 036767 167650 167642 BIT BITPT+2,PMEMAP+2 ;...HI 64K.
 7551 011700 001004 BNE 2\$;BR IF PARITY MEM.
 7552 011702 050502 BIS R5, R2 ;POINT TO END OF BLOCK.
 7553 011704 005202 INC R2 ;FIRST ADR OF NEXT BLOCK.
 7554 011706 000167 000540 JMP WWPB5 ;BR TO FIND NEXT BLOCK.
 7555 011712 004767 005674 2\$: JSR PC, SETAE ;SET ACTION ENABLE (EVEN IF BANK0.)
 7556 011716 004767 005724 JSR PC, CKPME ;CHECK FOR ANY NON TRAP PARITY ERRORS.
 7557 011722 020227 000114 WWPB1: CMP R2, #114 ;CHECK IF POINTING TO PARITY ERROR VECTOR.
 7558 011726 001004 BNE 3\$;BR IF NOT AT VECTOR.
 7559 011730 062702 000004 ADD #4, R2 ;SKIP PARITY VECTOR.
 7560 011734 000167 000512 JMP WWPB5 ;CHECK FOR BLOCK END.
 7561 011740 111201 3\$: MOVB (R2), R1 ;CHECK IF BYTE STILL CLEARED.
 7562 011742 001405 BEQ 65\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 (2) 011744 004767 006352 64\$: JSR PC, SPRNT ;SET UP VALUES FOR ERROR PRINTING.
 (3) 011750 004767 007674 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 (3) 011754 000011 .WORD 11 ;ERROR TYPE CODE.
 (1) 011756
 7563 011756 105067 167576 CLR8 OEFGL ;CLEAR ODD/EVEN FLAG.
 7564 011762 112700 000252 MOVB #252, R0 ;SET UP DATA...EVEN, SETS PARITY BIT.
 7565 011766 110012 WWPB2: MOVB R0, (R2) ;MOV DATA INTO TEST LOCATION.
 7566 011770 016703 167634 MOV .MPRX, R3 ;GET PARITY REGISTER TABLE POINTER.
 7567 011774 056773 167612 000000 10\$: BIS WWP, @R3) ;SET WRITE WRONG PARITY.
 7568 012002 052733 000001 BIS #AE, @R3)+
 7569 012006 005713 TST (R3) ;CHECK FOR TABLE TERMINATOR.
 7570 012010 001371 BNE 10\$;BR IF MORE REGS IN TABLE.
 7571 :* SET WRONG PARITY IN LOCATION UNDER TEST.
 7572 012012 110012 MOVB R0, (R2) ;WRITE SAME DATA (EXCEPT PARITY) VIA DATOB.
 7573 012014 016703 167610 MOV .MPRX, R3 ;GET PARITY REG TABLE POINTER.
 7574 012020 046733 167566 11\$: BIC WWP, @R3)+ ;CLEAR WRITE WRONG PARITY.
 7575 012024 005713 TST (R3) ;CHECK FOR TABLE TERMINATOR.
 7576 012026 001374 BNE 11\$;BR IF MORE PARITY REGISTERS.
 7577 012030 016737 167576 000114 MOV .PBTRP, @MPARVEC ;SET UP VECTOR FOR EXPECTED TRAP.
 7578 :* DETECT WRONG PARITY VIA DATIP; DATOB SHOULDN'T EXECUTE.
 7579 012036 105412 NEGB (R2) ;DATIP (DATOB AND COM PARITY BIT.)

7580 :* SHOULD HAVE TRAPPED TO PBTRP.
 7581 012040 016737 167572 000114 :* PESRV, &PARVEC ;RESET VECTOR FOR UNEXPECTED TRAPS.
 7582 012046 004767 006300 64\$: JSR PC, SPRNTO ;SET UP VALUES FOR ERROR PRINTING.
 (2) 012052 004767 007572 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 (2) 012056 000012 .WORD 12 ;ERROR TYPE CODE.
 7583 012060 000562 BR WWPB4 ;SKIP TRAP SERVICE.

7584
 7585 :* EXPECTED PARITY MEMORY TRAPS COME HERE.
 7586 012062 016737 167550 000114 PBTRP: MOV .PESRV, &PARVEC ;RESET PARITY VECTOR FOR UNEXPECTED TRAPS.
 7587 012070 022626 CMP (SP)+, (SP)+ ;RESET THE STACK POINTER AFTER TRAP.
 7588 012072 016703 167530 MOV .MPRO, R3 ;GET PARITY REG AND MAP TABLE POINTER.
 7589 012076 032713 000001 21\$: BIT #BIT0, (R3) ;CHECK IF THIS REGISTER EXISTS.
 7590 012102 001003 BNE 22\$;BR IF IT DOESN'T EXIST.
 7591 012104 017301 000000 MOV @((R3)), R1 ;GET THE CONTENTS.
 7592 012110 100413 BMI 23\$;BR IF ERROR FLAG SET.
 7593 012112 062703 000010 22\$: ADD #10, R3 ;MOVE POINTER TO NEXT REG.
 7594 012116 020367 167506 CMP R3, .MPRX ;CHECK FOR END OF TABLE.
 7595 012122 103765 BLO 21\$;BR IF MORE REGISTERS.
 7596 012124 004767 006222 64\$: JSR PC, SPRNTO ;SET UP VALUES FOR ERROR PRINTING.
 (2) 012130 004767 007514 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 (2) 012134 000013 .WORD 13 ;ERROR TYPE CODE.
 7597 012136 000533 BR WWPB4 ;EXIT AFTER ERROR.
 7598 012140 036763 167400 000002 23\$: BIT BITPT, 2(R3) ;CHECK THE MAP FOR THIS REGISTER.
 7599 012146 001011 BNE 24\$;BR IF THIS REGISTER CONTROLS THIS BANK.
 7600 012150 036763 167372 000004 BIT BITPT+2,4(R3) ;CHECK THE HI 64K.
 7601 012156 001005 BNE 24\$;BR IF THIS REGISTER CONTROLS THIS BANK.
 7602 012160 004767 006162 65\$: JSR PC, SPRNTP ;SET UP VALUES FOR ERROR PRINTING.
 (2) 012164 004767 007460 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 (2) 012170 000014 .WORD 14 ;ERROR TYPE CODE.

7603 012172 (2) 012172 010046 24\$: MOV R0,-(SP) ;PUSH R0 ON STACK
 7604 012174 010200 MOV R2, R0 ;GET THE ADDRESS POINTER.
 7605 012176 042700 003777 BIC #3777, R0 ;CLEAR LOW ADDRESS BITS.
 7606 012202 000300 SWAB R0 ;SHIFT 6 PLACES RIGHT.
 7607 012204 006300 ASL R0
 7608 012206 006300 ASL R0
 7609 012210 005767 166372 TST MMAVA ;CHECK FOR MEM MGMT.
 7610 012214 001404 BEQ 25\$;BR IF NO MEM MGMT.
 7611 012216 042700 177600 BIC #177600, R0 ;CLEAR BANK BITS
 7612 012222 063700 172344 ADD #MKIPAR2, R0 ;ADD MEM MGMT OFFSET.
 7613 012226 052700 100001 25\$: BIS #BIT15+BIT0, R0 ;SET ERROR AND AE BIT IN CHECK WORD.
 7614 012232 016367 000006 167256 MOV 6(R3), RESRVD ;GET APPROPRIATE MASK.
 7615 012240 046700 167252 BIC RESRVD, R0 ;CLEAR PARITY REG BITS RESERVED FOR FUTURE.
 7616 012244 046701 167246 BIC RESRVD, R1 ;CLEAR PARITY REG BITS RESERVED FOR FUTURE.
 7617 ;NOTE: THE ABOVE INSTRUCTION (2 WORDS) CAN BE NOP'ED FOR UNMIXED MEMORY TYPES.
 7618 012250 020001 CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
 (2) 012252 001405 BEQ 67\$;BRANCH OVER ERROR CALL IF GOOD DATA.
 (3) 012254 004767 006066 66\$: JSR PC, SPRNTP ;SET UP VALUES FOR ERROR PRINTING.
 (4) 012260 004767 007364 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 (4) 012264 000015 .WORD 15 ;ERROR TYPE CODE.

7619 012266 005073 000000 67\$: CLR @((R3)) ;CLEAR REG INCLUDING ACTION ENABLE.
 7620 012272 010346 MOV R3,-(SP) ;PUSH R3 ON STACK
 7621 012274 062703 000010 26\$: ADD #10, R3 ;UPDATE POINTER TO NEXT PARITY REG + MAP.
 7622 012300 020367 167324 CMP R3, .MPRX ;CHECK FOR END OF TABLE.
 7623 012304 101014 BHI WWPB3 ;BR IF END OF TABLE REACHED.

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER
CZOMCG.P11 12-MAR-80 13:07 T17

C 6
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-50
WORSE CASE NOISE PARITY BYTE TESTING

SEQ 0067

7624 012306 032713 000001	BIT #BIT0, (R3)	CHECK IF NEXT REG EXISTS.
7625 012312 001370	BNE 26\$:BR IF THIS PARITY REG DOESN'T EXIST.
7626 012314 017301 000000	MOV @ (R3), R1	:SAVE AND CHECK FOR ERROR FLAG.
7627 012320 100365	BPL 26\$:BR IF NO ERROR FLAG.
7628 012322 004767 006020	68\$: JSR PC, SPRNTP	SET UP VALUES FOR ERROR PRINTING.
(2) 012326 004767 007316	JSR PC, \$ERROR	*** ERROR *** (GO TYPE A MESSAGE)
(2) 012332 000016	.WORD 16	ERROR TYPE CODE.
7629 012334 000757	BR 26\$:BR AFTER ERROR.
7630 012336 111204	WWPB3: MOVB (R2), R4	:GET THE DATA FOR CHECKING.
7631	;* READING THE DATA VIA DATI TO	CHECK IT SHOULD CAUSE PARITY ERROR, BUT
7632	;* ACTION ENABLE IS NOT SET IN	CONTROLLING REG, SO NO TRAP SHOULD OCCURE.
7633 012340 111212	MOV B (R2), (R2)	:RESTORE RIGHT PARITY
7634	:NOTE: THE ABOVE INSTRUCTION CAN BE NOP'ED FOR PROCESSORS	
7635	:	WHICH DO ONLY DATOB TO DESTINATION OF MOVB INSTRUCTIONS.
7636 012342 012603	MOV (SP)+, R3	:POP STACK INTO R3
7637 012344 017301 000000	MOV @ (R3), R1	:READ THE PARITY REGISTER TO CHECK IT AGAIN.
7638 012350 046701 167142	BIC RESRVD, R1	:CLEAR PARITY REG BITS RESERVED FOR FUTURE.
7639	:NOTE: THE ABOVE INSTRUCTION (2 WORDS) CAN BE NOP'ED FOR UNMIXED MEMORY TYPES.	
7640 012354 042700 000001	BIC #AE, R0	:CLEAR THE ACTION ENABLE BIT IN TEST DATA.
7641 012360 020001	CMP R0, R1	:COMPARE THE CHECK WORD WITH THE DATA READ.
(2) 012362 001405	BEQ 65\$:BRANCH OVER ERROR CALL IF GOOD DATA.
(3) 012364 004767 005756	64\$: JSR PC, SPRNTP	SET UP VALUES FOR ERROR PRINTING.
(4) 012370 004767 007254	JSR PC, \$ERROR	*** ERROR *** (GO TYPE A MESSAGE)
(4) 012374 000015	.WORD 15	ERROR TYPE CODE.
(2) 012376	65\$: MOVB #1, @ (R3)	:CLEAR ALL BUT ACTION ENABLE.
7642 012376 012773 000001 000000	MOV R4, R1	:GET DATA READ FROM MEMORY FOR TESTING.
7643 012404 010401	MOV (SP)+, R0	:POP STACK INTO R0
7644 012406 012600	CMPB R0, R1	:CHECK THE DATA.
7645 012410 120001	BEQ 67\$:BRANCH OVER ERROR CALL IF GOOD DATA.
7646 012412 001405	66\$: JSR PC, SPRNTO	SET UP VALUES FOR ERROR PRINTING.
(2) 012414 004767 005732	JSR PC, \$ERROR	*** ERROR *** (GO TYPE A MESSAGE)
(3) 012420 004767 007224	.WORD 17	ERROR TYPE CODE.
(3) 012424 000017	67\$: WWPB4: MOVB R0, (R2)	:RESTORE DATA.
7647 012426 110012	TSTB (R2)	:DO A DATI TO BE SURE RIGHT PARITY.
7648 012430 105712	MOV #253, R0	:SET ODD PARITY DATA.
7649 012432 012700 000253	COMB OEFLG	:CHECK IF DONE BOTH ODD AND EVEN PARITY.
7650 012436 105167 167116	BPL 27\$:BR IF DONE BOTH EVEN AND ODD.
7651 012442 100002	JMP WWPB2	:LOOP BACK AND DO ODD(PARITY BIT CLR).
7652 012444 000167 177316	27\$: INC R2	:MOVE POINTER TO NEXT MEMORY BYTE.
7653 012450 005202	WWPB5: BIT R5,	:CHECK FOR END OF BLOCK.
7654 012452 030502	BEQ 30\$:BR IF END OF BLOCK FOUND.
7655 012454 001402	JMP WWPB1	:LOOP BACK TO TEST NEXT BYTE.
7656 012456 000167 177240	30\$: JSR PC, MMUP	:FIND NEXT BLOCK AND LOOP TO WWPBYT
7657 012462 004767 002526	.ISR PC, MAMF	:GO RESET PARITY REGISTERS.
7658 012466 004767 005054		

CZQMCG0 0-124K MEMORY EXERCISER. 16K VER
CZQMCG.P11 12-MAR-80 13:07 T20

D 6
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-5
RANDOM DATA TESTING THRU PROGRAM CODE RELOCATION.

SEQ 0068

(ZOMCG0 0-124K MEMORY EXERCISER. 16K VER
(ZOMCG.P11 12-MAR-80 13:07

E 6
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-52
EXECUTE DATA, DATA THRU MEMORY.

SEQ 0069

(4) :* R2 = ADDRESS OF IUT/DATA.
(4) :* R3 = INSTRUCTION UNDER TEST (IUT).
(4) :* R4 - RTS R5 (CODE 205).
(4) :* R5 = BLOCK BOUNDARY BIT MASK.
(3) :*****
(2) 012606 T21:
(3) 012606 004567 006026 JSR R5, \$SCOPE :GO TO SCOPE ROUTINE.
(3) 012612 000003 .WORD 3 :MINIMUM BLOCK SIZE OF 2 WORDS
(3) REQUIRED FOR THIS TEST.
(3) 012614 000167 000056 JMP TST22 :SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
(3) AVAILABLE FOR TEST.
7707 012620 012703 010412 DIDO: MOV #010412,R3 :GET 'MOV R4,(R2)' INSTRUCTION (IUT).
7708 012624 012704 000205 MOV #205, R4 :GET 'RTS R5'
7709 012630 010400 MOV R4, R0 :SET UP S/B DATA AFTER EXECUTION.
7710 012632 004467 001600 JSR R4, INITMM :INITIALIZE THE MEMORY ADDRESS POINTERS.
7711 012636 010322 1\$: MOV R3, (R2)+ :PUT IUT INTO FIRST LOC OF BLOCK.
7712 012640 010412 2\$: MOV R4, (R2) :PUT 'RTS R5' FOLLOWING IUT.
7713 012642 004542 JSR R5, -(R2) :GO EXECUTE THE IUT.
7714 012644 012201 MOV (R2)+, R1 :GET THE DATA FROM THE MEM ADR UNDER TEST.
7715 012646 020001 CMP R0, R1 :COMPARE THE CHECK WORD WITH THE DATA READ.
(2) 012650 001405 BEQ 65\$:BRANCH OVER ERROR CALL IF GOOD DATA.
(3) 012652 004767 005514 64\$: JSR PC, SPRNT3 :SET UP VALUES FOR ERROR PRINTING.
(4) 012656 004767 006766 JSR PC, \$ERROR :*** ERROR *** (GO TYPE A MESSAGE)
(4) 012662 000021 .WORD 21 :ERROR TYPE CODE.
(2) 012664 65\$: MOV R3, (R2)+ :PUT THE IUT INTO THE NEXT LOCATION.
7716 012664 010322 BIT R5, R2 :CHECK FOR END OF A BLOCK.
7717 012666 030502 BNE 2\$: :BRANCH IF MORE IN CURRENT BLOCK.
(1) 012670 001363 JSR PC, MMUP :FIND NEXT BLOCK AND LOOP TO 1\$.
(1) 012672 004767 002316

CZQMCIGO 0-124K MEMORY EXERCISER, 16K VER
CZQMCIG.P11 12-MAR-80 13-07 T2

MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-53
EXECUTE DAT1, DAT08 (LOW BYTE) THRU MEMORY.

F

SEQ 0070

7743

(3) *TEST 22 EXECUTE DATI, DATOB (LOW BYTE) THRU MEMORY.
 (4) * EXECUTES THE INSTRUCTION 'MOVB R4,(R2)' THROUGHOUT MEMORY.
 (4) * AN 'RTS R5' (CODE 205) IS PLACED AFTER THE 'MOVB' INSTRUCTION TO RETURN
 (4) * CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.
 (4) * THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:
 (4)
 (4) MEMORY INSTRUCTION CONTENTS OF MEMORY LOCATION
 (4) LOCATION PLACED THERE AFTER INSTRUCTION EXECUTION
 (4)
 (4) 1ST PASS / 40000 110412 110605
 (4) THRU TEST / 40002 000205 000205
 (4)
 (4) 2ND PASS / 40002 110412 110605
 (4) THRU TEST / 40004 000205 000205
 (4)
 (4) ETC.. ETC.. ETC.
 (4)
 (4) * R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).
 (4) * R1 = DATA READ FROM MEMORY (WAS).
 (4) * R2 = ADDRESS OF IUT/DATA.
 (4) * R3 = INSTRUCTION UNDER TEST (IUT).
 (4) * R4 = RTS R5 (CODE 205).
 (4) * R5 = BLOCK BOUNDARY BIT MASK.

(2)	012676		
(3)	012676	004567	005736
(3)	012702	000093	
(3)			
(3)	012704	000167	000060
(3)			
7744	012710	012703	110412
7745	012714	012704	000205
7746	012720	012700	110605
7747	012724	004467	001506
7748	012730	010322	
7749	012732	010412	
7750	012734	004542	
7751	012736	012201	
7752	012740	020001	
(2)	012742	001405	
(3)	012744	004767	005422
(4)	012750	004767	006674
(4)	012754	000021	
(2)	012756		
7753	012756	010322	
7754	012760	030502	
(1)	012762	001363	
(1)	012764	004767	002224

7780

(3) *TEST 23 EXECUTE DATI, DATOB (HIGH BYTE) THRU MEMORY.
 (4) * EXECUTES THE INSTRUCTION 'MOVB R3,-(R2)' THROUGHOUT MEMORY.
 (4) * AN 'RTS R5' (CODE 205) IS PLACED AFTER THE 'MOVB' INSTRUCTION TO RETURN
 (4) * CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.
 (4) * THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:
 (4)

	MEMORY LOCATION	INSTRUCTION PLACED THERE	CONTENTS OF MEMORY LOCATION AFTER INSTRUCTION EXECUTION
--	-----------------	--------------------------	---

1ST PASS /	40000	110342	161342
THRU TEST /	40002	000205	000205
2ND PASS /	40002	110342	161342
THRU TEST /	40004	000205	000205
		ETC.. ETC.. ETC.	

(4) * R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).
 (4) * R1 = DATA READ FROM MEMORY (WAS).
 (4) * R2 = ADDRESS OF IUT/DATA.
 (4) * R3 = INSTRUCTION UNDER TEST (IUT).
 (4) * R4 = RTS R5 (CODE 205).
 (4) * R5 = BLOCK BOUNDARY BIT MASK.

TST23:

(2) 012770	004567	005644	JSR .WORD R5. 3 \$SCOPE	: GO TO SCOPE ROUTINE. : MINIMUM BLOCK SIZE OF 2 WORDS : REQUIRED FOR THIS TEST.
(3) 012774	000003		JMP TST24	: SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK : AVAILABLE FOR TEST.
(3) 012776	000167	000064	DIDBH: MOV #110342,R3	: GET 'MOVB R3,-(R2)' INSTRUCTION (IUT).
7781 013002	012703	110342	MOV #205, R4	: GET 'RTS R5'
7782 013006	012704	000205	MOV #161342,R0	: SET UP S/B DATA AFTER EXECUTION.
7783 013012	012700	161342	JSR R4, INITMM	: INITIALIZE THE MEMORY ADDRESS POINTERS.
7784 013016	004467	001414	1\$: MOV R3, (R2)+	: PUT IUT INTO FIRST LOC OF BLOCK.
7785 013022	010322		2\$: MOV R4, (R2)	: PUT 'RTS R5' FOLLOWING IUT.
7786 013024	010412		JSR R5, -2(R2)	: GO EXECUTE THE IUT.
7787 013026	004562	177776	DEC R2	: ADJUST R2 TO POINT TO MAUT.
7788 013032	005302		MOV (R2)+, R1	: GET THE DATA FROM THE MEM ADR UNDER TEST.
7789 013034	012201		CMP R0, R1	: COMPARE THE CHECK WORD WITH THE DATA READ.
7790 013036	020001		BNE 65\$: BRANCH OVER ERROR CALL IF GOOD DATA.
(2) 013040	001405		JSR PC, SPRNT3	: SET UP VALUES FOR ERROR PRINTING.
(3) 013042	004767	005324	JSR PC, \$ERROR	:*** ERROR *** (GO TYPE A MESSAGE)
(4) 013046	004767	006576	.WORD 21	: ERROR TYPE CODE.
(4) 013052	C00021		65\$: MOV R3, (R2)+	: PUT THE IUT INTO THE NEXT LOCATION.
(2) 013054			BIT R5, R2	: CHECK FOR END OF A BLOCK.
7791 013054	010322		BNE 2\$: BRANCH IF MORE IN CURRENT BLOCK.
7792 013056	030502		JSR PC, MMUP	: FIND NEXT BLOCK AND LOOP TO 1\$.
(1) 013060	001361			
(1) 013062	004767	002126		

7820

(3) TEST 24 EXECUTE DATI, DATIP, DATO THRU MEMORY.
(4) EXECUTES THE INSTRUCTION 'NEG (R2)' THROUGHOUT MEMORY.
(4) AN 'RTS R5' (CODE 205) IS PLACED AFTER THE 'NEG' INSTRUCTION TO RETURN
(4) CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.
(4) THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:
(4)

MEMORY LOCATION	INSTRUCTION PLACED THERE	CONTENTS OF MEMORY LOCATION AFTER INSTRUCTION EXECUTION
-----------------	--------------------------	---

1ST PASS / THRU TEST /	40000 40002	005412 000205
------------------------	-------------	---------------

2ND PASS / THRU TEST /	40002 40004	005412 000205
------------------------	-------------	---------------

ETC.. ETC., ETC.

;* R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).
;* R1 = DATA READ FROM MEMORY (WAS).
;* R2 = ADDRESS OF IUT/DATA.

;* R3 = INSTRUCTION UNDER TEST (IUT).
;* R4 = RTS R5 (CODE 205).
;* R5 = BLOCK BOUNDARY BIT MASK.

	JSR .WORD	R5,	\$SCOPE	GO TO SCOPE ROUTINE. MINIMUM BLOCK SIZE OF 2 WORDS REQUIRED FOR THIS TEST.
013066 004567 005546	JMP	TST25		SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK AVAILABLE FOR TEST.
013072 000003	DIPDO:	MOV #005412,R3		GET 'NEG (R2)' INSTRUCTION (IUT).
013074 000167 000060		MOV #205, R4		GET 'RTS R5'
013100 012703 005412		MOV #172366, R0		SET UP S/B DATA AFTER EXECUTION.
013104 012704 000205		JSR R4, INITMM		INITIALIZE THE MEMORY ADDRESS POINTERS.
013110 012700 172366	1\$:	MOV R3, (R2)+		PUT IUT INTO FIRST LOC OF BLOCK.
013114 004467 001316	2\$:	MOV R4, (R2)		PUT 'RTS R5' FOLLOWING IUT.
013120 010322		JSR R5, -(R2)		GO EXECUTE THE IUT.
013122 010412		MOV (R2)+, R1		GET THE DATA FROM THE MEM ADR UNDER TEST.
013124 004542		CMP R0, R1		COMPARE THE CHECK WORD WITH THE DATA READ.
013126 012201		BEQ 65\$		BRANCH OVER ERROR CALL IF GOOD DATA.
013130 020001	64\$:	JSR PC,	SPRNT3	SET UP VALUES FOR ERROR PRINTING.
013132 001405		JSR PC,	\$ERROR	*** ERROR *** (GO TYPE A MESSAGE)
013134 004767 005232		.WORD 21		ERROR TYPE CODE.
013140 004767 006504		MOV R3, (R2)+		PUT THE IUT INTO THE NEXT LOCATION.
013144 000021		BIT R5, R2		CHECK FOR END OF A BLOCK.
013146 013146 010322		BNE 2\$		BRANCH IF MORE IN CURRENT BLOCK.
013150 030502		JSR PC,	MMUP	FIND NEXT BLOCK AND LOOP TO 1\$.
013152 001363				
013154 004767 002034				

CZOMCG0 0-124K MEMORY EXERCISER, 16K VER
CZOMCG.P11 12-MAR-80 13:07 T29

MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-56
EXECUTE DATI, DATI, DATIP, DATOB (LOW BYTE) THRU MEMORY.

SEQ 0072

7857

(3) TEST 25 EXECUTE DATI, DATI, DATIP, DATOB (LOW BYTE) THRU MEMORY.
(4) EXECUTES THE INSTRUCTION BICB (R2)+,-(R2)' THROUGHOUT MEMORY.
(4) AN 'RTS R5' (CODE 205) IS PLACED AFTER THE BICB' INSTRUCTION TO RETURN
(4) CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.
(4) THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:

* MEMORY LOCATION INSTRUCTION PLACED THERE CONTENTS OF MEMORY LOCATION AFTER INSTRUCTION EXECUTION

•	1ST PASS /	40000	142242	142000
•	THRU TEST /	40002	000205	000205
★				
•	2ND PASS /	40002	142242	142000
•	THRU TEST /	40004	000205	000205

ETC., ETC., ETC.

- * R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).
- * R1 = DATA READ FROM MEMORY (WAS).
- * R2 = ADDRESS OF IUT/DATA.
- * R3 = INSTRUCTION UNDER TEST (IUT).
- * R4 = RTS R5 (CODE 205).
- * R5 = BLOCK BOUNDARY BIT MASK.

ST25:

JSR	R5,	\$SCOPE	: GO TO SCOPE ROUTINE.
.WORD	3		: MINIMUM BLOCK SIZE OF 2 WORDS
			: REQUIRED FOR THIS TEST.
JMP	TST26		: SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
			: AVAILABLE FOR TEST.

(2) 013160

(3) 013160 004567 005454

(3) 013164 000003

(3) 013166 000167 000060

(3) 013188 000187 000000

7858 013172 012703 142242

7859 013176 012704 000205
7860 013203 012300 112000

7860 013202 012700 142000
7861 013206 004667 001224

7851 013203 004487 001224
7862 013212 010322

7863 013214 010412

7864 013216 004542
7865 013220 012301

7865 013220 01220
7866 013222 020001

(2) 013224 001405

(3) 013226 004767 005140

(4) 013232 004767 006412
(1) 013232 000031

(4) 013236 0002
(2) 013240

7867 013240 010322

788 013242 030502

013244 001363
013246 001363

013246 004767 001742

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER
CZOMCG.P11 12-MAR-80 13:07

T26

J 6
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-57
EXECUTE DATI, DATI, DATIP, DATOB (HIGH BYTE) THRU MEMORY.

SEQ 0074

7894

* TEST 26 EXECUTE DATI, DATI, DATIP, DATOB (HIGH BYTE) THRU MEMORY.
* EXECUTES THE INSTRUCTION 'BISB (R2)+(R2)' THROUGHOUT MEMORY.
* AN 'RTS R5' (CODE 205) IS PLACED AFTER THE 'BISB' INSTRUCTION TO RETURN
* CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.
* THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:
*

* MEMORY LOCATION INSTRUCTION CONTENTS OF MEMORY LOCATION
* PLACED THERE AFTER INSTRUCTION EXECUTION

1ST PASS / 40000 152212 157212
THRU TEST / 40002 000205 000205

2ND PASS / 40002 152212 157212
THRU TEST / 40004 000205 000205

ETC., ETC., ETC.

RO = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).
R1 = DATA READ FROM MEMORY (WAS).
R2 = ADDRESS OF IUT/DATA.
R3 = INSTRUCTION UNDER TEST (IUT).
R4 = RTS R5 (CODE 205).
R5 = BLOCK BOUNDARY BIT MASK.

TST26:
013252 JSR R5. \$SCOPE : GO TO SCOPE ROUTINE.
013252 004567 005362 .WORD 3 : MINIMUM BLOCK SIZE OF 2 WORDS
013256 000003 : REQUIRED FOR THIS TEST.
013260 000167 000062 JMP TST27 : SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
013264 012703 152212 DPD8H: MOV #152212,R3 : AVAILABLE FOR TEST.
013270 012704 000205 MOV #205, R4 : GET 'BISB (R2)+(R2)' INSTRUCTION (IUT).
013274 012700 157212 MOV #157212,RO : GET 'RTS R5'
013300 004467 001132 JSR R4, INITMM : SET UP S/B DATA AFTER EXECUTION.
013304 010322 1\$: MOV R3, (R2)+ : INITIALIZE THE MEMORY ADDRESS POINTERS.
013306 010412 2\$: MOV R4, (R2) : PUT IUT INTO FIRST LOC OF BLOCK.
013310 004542 JSR R5, -(R2) : PUT 'RTS R5' FOLLOWING IUT.
013312 005302 DEC R2 : GO EXECUTE THE IUT.
013314 012201 MOV (R2)+, R1 : RESET R2 TO POINT TO IUT.
013316 020001 CMP RO, R1 : GET THE DATA FROM THE MEM ADR UNDER TEST.
013320 001405 BEQ 65\$: COMPARE THE CHECK WORD WITH THE DATA READ.
013322 004767 005044 64\$: JSR PC. SPRNT3 : BRANCH OVER ERROR CALL IF GOOD DATA.
013326 004767 006316 JSR PC. \$ERROR : SET UP VALUES FOR ERROR PRINTING.
013332 000021 .WORD 21 : *** ERROR *** (GO TYPE A MESSAGE)
013334 : ERROR TYPE CODE.
013334 010322 65\$: MOV R3, (R2)+ : PUT THE IUT INTO THE NEXT LOCATION.
013336 030502 BIT R5, R2 : CHECK FOR END OF A BLOCK.
013340 001362 BNE 2\$: BRANCH IF MORE IN CURRENT BLOCK.
013342 004767 001646 JSR PC, MMUP : FIND NEXT BLOCK AND LOOP TO 1\$.

7908

.SBTTL SECTION 4:MOS TESTS

7932

;*****
 (3) * TEST 27 MARCHING 1'S AND 0'S.
 (4) * THIS TEST IS DESIGNED TO STRESS MOS MEMORIES.
 (4) * STARTING AT THE BOTTOM ADDRESS AND ADDRESSING UPWARDS A 4K BANK IS
 (4) * WRITTEN WITH 000377. THEN STARTING AT THE TOP ADDRESS OF THE BANK THE
 (4) * 000377 IS READ, THE BYTES ARE SWAPPED TO 177400 AND THE LOCATION
 (4) * REREAD TO CONFIRM THE WRITE. THIS IS REPEATED FOR EVERY LOCATION
 (4) * ADDRESSED DOWNWARD UNTIL THE BOTTOM IS REACHED. STARTING AT THE
 (4) * BOTTOM EACH LOCATION IS READ FOR 177400, THE BYTES ARE SWAPPED TO
 (4) * 000377 AND REREAD TO CONFIRM THE WRITE UNTIL THE TOP ADDRESS OF THE
 (4) * BANK IS REACHED. AGAIN STARTING AT THE BOTTOM EACH LOCATION IS READ
 (4) * FOR 000377, THE BYTES SWAPPED TO 177400 AND THE LOCATION REREAD TO
 (4) * CONFIRM THE WRITE. LASTLY STARTING FROM THE TOP AND ADDRESSING DOWN-
 (4) * WARD EACH LOCATION IS READ, THE BYTES SWAPPED TO 000377 AND THE
 (4) * LOCATION IS REREAD TO CONFIRM THE WRITE. THIS IS REPEATED FOR EVERY
 (4) * 4K BANK UNDER TEST.

(4)

;*****
 (4) * R0=DATA WRITTEN INTO MEMORY(SHOULD BE)
 (4) * R1=DATA READ FROM MEMORY(WAS)
 (4) * R2=VIRTUAL ADDRESS
 (4) * R3=TIMES THROUGH COUNTER
 (4) * R4=NOT USED
 (4) * R5=BLOCK BOUNDARY BIT MASK.

(4)

(3)

(2)

013346 004567 005266

TST27:
 (3) JSR R5, \$SCOPE ;GO TO SCOPE ROUTINE.
 (3) .WORD 0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.

(3)

013352 000000 001056

JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
 MOV R2, TEMP ;SAVE BANK STARTING ADDRESS

(3)

013354 004467 001056

1\$: CLR R3 ;CLEAR PASS COUNTER

(3)

013360 010267 166230

MOV #000377, R0 ;SETUP TO WRITE PATTERN

(3)

013364 005003

2\$: MOV R0, (R2)+ ;WRITE PATTERN

(3)

013366 012700 000377

BIT R5,R2 ;END OF 4K?
 BNE 2\$;CONTINUE WRITING IF NO.

(3)

013374 030502

3\$: MOV -(R2), R1 ;GET DATA WRITEN

(3)

013376 001375

CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.

(3)

013400 014201

BEQ 65\$;BRANCH OVER ERROR CALL IF GOOD DATA.

(2)

013402 020001

64\$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.

(2)

013404 001405

JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)

(3)

013406 004767 004764

.WORD 10 ;ERROR TYPE CODE.

(4)

013412 004767 006232

65\$: SWAB R0 ;SWAP BYTES OF DATA

(4)

013416 000010

4\$: MOV R0, (R2) ;WRITE SWAPPED WORD

(2)

013420 000300

MOV (R2), R1 ;GET DATA WRITEN

(2)

013422 010012

CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.

(2)

013424 011201

BEQ 67\$;BRANCH OVER ERROR CALL IF GOOD DATA.

(2)

013426 020001

66\$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.

(2)

013430 001405

JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)

(3)

013432 004767 004740

.WORD 10 ;ERROR TYPE CODE.

(4)

013436 004767 006206

67\$: SWAB R0 ;PUT DATA BACK TO ORINGINAL

(4)

013442 000010

TST R3 ;IF ON PASS 0 OR PASS 3

(2)

013444 000300

BEQ 5\$;WE ARE ADDRESSING DOWN

(2)

013446 005703

CMP R3, #3 ;IF ON PASS 1 OR 2 GO TO

(2)

013448 001403

BNE 6\$;UPWARD

(2)

013450 020327 000003

(2)

013452 001010

(2)

013456 000003

CZOMCG0 0-124K MEMORY EXERCISER, 16K VER
CZOMCG.P11 12-MAR-80 13:07

L 6
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-59
MARCHING 1'S AND 0'S.

SEQ 0076

7951 013460 030502 5\$: BIT R5,R2 ;DONE A PASS?
7952 013462 001346 BNE 3\$;IF NO CONTINUE
7953 013464 005203 INC R3 ;IF YES INCREMENT PASS COUNTER
7954 013466 022703 000004 CMP #4,R3 ;ARE WE DONE ALL PASSES FOR THIS 4K?
7955 013472 001427 BEQ 9\$;IF YES BRANCH
7956 013474 000300 SWAB R0 ;ELSE SET UP NEW READ WORD
7957 013476 000404 BR 7\$;GO TO START OF ADDRESS UP
7958 013500 062702 000002 6\$: ADD #2,R2 ;UPDATE TO NEXT ADDRESS
7959 013504 030502 BIT R5,R2 ;DONE A PASS
7960 013506 001411 BEQ 8\$;IF YES BRANCH
7961 013510 011201 7\$: MOV (R2),R1 ;GET DATA WRITTEN
7962 013512 020001 CMP R0 R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
(2) 013514 001405 BEQ 69\$;BRANCH OVER ERROR CALL IF GOOD DATA.
(3) 013516 004767 004654 68\$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
(4) 013522 004767 006122 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
(4) 013526 000010 .WORD 10 ;ERROR TYPE CODE.
(2) 013530 69\$: BR 4\$
7963 013530 000733 8\$: INC R3 ;INCREMENT PASS COUNTER
7964 013532 005203 SWAB R0 ;SET UP NEW READ WORD
7965 013534 000300 CMP R3,#2 ;ADDRESSING UP?
7966 013536 020327 000002 BNE 3\$;IF NO GO TO DOWN SEQUENCE
7967 013542 001316 MOV TEMP,R2 ;IF YES RESET ADDRESS TO START
7968 013544 016702 166044 BR 7\$;GO TO UP SEQUENCE
7969 013550 000757 9\$: JSR R4,INITMM ;INITIALIZE MEMORY ADDRESS POINTERS
7970 013552 00467 000660 JSR PC,MMUP ;UPDATE TO NEW BANK IF EXISTS
7971 013556 004767 001432

7985
(3) :***** TEST 30 ***** WRITE CHECKERBOARD STARTING WITH '125252' DATA.
(4) : THESE TESTS WRITE A CHECKERBOARD THROUGHOUT MEMORY, STALL
(4) : FOR 2 SECONDS THEN CHECK PATTERN TO VERIFY DATA DID NOT
(4) : DETERIORATE BETWEEN REFRESH CYCLES.
(4) :
(4) : R0=DATA WRITTEN INTO MEMORY(SHOULD BE)
(4) : R1=DATA READ FROM MEMORY(WAS)
(4) : R2=VIRTUAL ADDRESS
(4) : R3=SMALL LOOP COUNTER FOR STALL
(4) : R4=NUMBER OF TIMES SMALL LOOP DONE
(4) : R5=BLOCK BOUNDARY BIT MASK.
(3) :*****
(2) 013562 TST30:
(3) 013562 004567 005052 JSR R5, \$SCOPE ;GO TO SCOPE ROUTINE.
(3) 013566 000000 .WORD 0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
7986 013570 004467 000642 JSR R4 INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
7987 013574 012700 125252 MOV #125252 ,R0 ;SETUP DATA PATTERN
7988 013600 010022 MOV R0 ,(R2)+ ;WRITE A WORD
7989 013602 005100 COM R0 ;COMPLEMENT DATA
7990 013604 030502 BIT R5, R2 ;CHECK FOR END OF A BLOCK.
(1) 013606 001374 BNE 1\$;BRANCH IF MORE IN CURRENT BLOCK.
(1) 013610 004767 001400 JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1\$.
7991 013614 005003 CLR R3 ;SET UP COUNTER FOR STALL
7992 013616 012704 000046 MOV #46, R4 ;DO LOOP 46 TIMES OR < SEC. TOTAL.
7993 013622 005303 2\$: DEC R3
7994 013624 001376 BNE 2\$
7995 013626 005304 DEC R4
7996 013630 001374 BNE 2\$

CZQMCGO 0-124K MEMORY EXERCISER, 16K VER
CZQMCG.P11 12-MAR-80 13:07 T30

M 6
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-60
WRITE CHECKERBOARD STARTING WITH '125252' DATA.

SEQ 0077

7997 013632 004467 000600
7998 013636 012700 125252
7999 013642 (1) 013642 012201 (2) 013644 020001 (3) 013646 001405 (4) 013650 004767 004522 (5) 013654 004767 005770 (5) 013660 000006 (3) 013662 013662 005100 (1) 013664 030502 (1) 013666 001365 (1) 013670 004767 001320
8000 013662 005100
8001 013664 030502
(1) 013666 001365
(1) 013670 004767 001320
8002 (3) (3) (2) 013674 (3) 013674 004567 004740 (3) 013700 000000
8003 013702 004467 000530
8004 013706 012700 052525
8005 013712 010022
8006 013714 005100
8007 013716 030502 (1) 013720 001374 (1) 013722 004767 001266
8008 013726 005003
8009 013730 012704 000046
8010 013734 005303
8011 013736 001376
8012 013740 005304
8013 013742 001374
8014 013744 004467 000466
8015 013750 012700 052525
8016 013754 (1) 013754 012201 (2) 013756 020001 (3) 013760 001405 (4) 013762 004767 004410 (5) 013766 004767 005656 (5) 013772 000006 (3) 013774 013774 005100
8017 013776 030502 (1) 014000 001365 (1) 014002 004767 001206
JSR R6 INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
MOV #125252, R0 ;INIT DATA FOR CHECKING
3\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0 R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 65\$;BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 6 ;ERROR TYPE CODE.
64\$: COM R0 ;CHECK FOR END OF A BLOCK.
BIT R5, R2 ;BRANCH IF MORE IN CURRENT BLOCK.
BNE 3\$;FIND NEXT BLOCK AND LOOP TO 1\$.
JSR PC, MMUP ;

;TEST 31 WRITE CHECKERBOARD STARTING WITH 052525 DATA

TST31: JSR R5, \$\$COPE ;GO TO SCOPE ROUTINE.
.WORD 0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
JSR R4 INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
MOV #052525, R0 ;SETUP DATA PATTERN
1\$: MOV R0, (R2)+ ;WRITE A WORD
COM R0 ;
BIT R5, R2 ;CHECK FOR END OF A BLOCK.
BNE 1\$;BRANCH IF MORE IN CURRENT BLOCK.
JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1\$.
CLR R3 ;SET COUNTER FOR LOOP
MOV #46, R4 ;DO LOOP 46 TIMES OR 2 SEC. TOTAL
2\$: DEC R3 ;
BNE 2\$;
DEC R4 ;
BNE 2\$;
JSR R4 INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
MOV #052525, R0 ;INIT PATTERN FOR CHECKING
3\$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP R0 R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 65\$;BRANCH OVER ERROR CALL IF GOOD DATA.
JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
.WORD 6 ;ERROR TYPE CODE.
65\$: COM R0 ;CHECK FOR END OF A BLOCK.
BIT R5, R2 ;BRANCH IF MORE IN CURRENT BLOCK.
BNE 3\$;FIND NEXT BLOCK AND LOOP TO 1\$.

CZQMCG0 0-124K MEMORY EXERCISER, 16K VER
CZQMCG.P11 12-MAR-80 13:07

N 6
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-61
DONE: RELOCATE PROGRAM AND REPEAT ALL TESTS.

SEQ 0078

8020 .SBTTL DONE: RELOCATE PROGRAM AND REPEAT ALL TESTS.
8021 014006 DONE:
(1) 014006 004567 004626
(1) 014012 000000
8022 014014 005067 165150 TST32: CLR \$TIMES ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
8023 014020 105067 165056 CLR \$TSTM ;RESET ITERATION COUNTER FOR RESTARTING TEST.
8024 014024 036767 164552 1\$: BIT PRGMAP, SAVTST ;RESET TEST NUMBER.
8025 014032 001004 BNE 2\$;CHECK IF PROGRAM IS IN TEST AREA.
8026 014034 036767 164544 165474 BIT PRGMAP+2,SAVTST+2 ;BR IF IT PROG IN MEM TO BE TESTED.
8027 014042 001435 BEQ \$EOP ;CHECK HI 64K
8028 014044 032777 000200 165066 2\$: BIT #SW07, @SWR ;BR IF PROG NOT IN MEM TO BE TESTED.
8029 014052 001031 BNE \$EOP ;CHECK FOR INHIBIT RELOCATION SWITCH.
8030 014054 022767 000003 164520 CMP #3, PRGMAP ;SKIP RELOCATION IF SWITCH SET.
8031 014062 001013 BNE 4\$;CHECK IF PROGRAM IN FIRST 8K.
8032 014064 023737 000042 000046 CMP @#42,@#46 ;BR IF NOT IN FIRST 8K.
8033 014072 001416 BEQ 6\$;CHECK FOR ACT11
8034 014074 105737 001224 TSTB @SENV ;IF APT11 DO NOT RELOCATE
8035 014100 001013 BNE 6\$;MUST BE XXDP OR STANDALONE
8036
8037 014102 004767 002362 3\$: JSR PC, RELTOP ;RELOCATE PROGRAM TO TOP OF MEMORY.
8038 014106 000167 172002 JMP START1 ;LOOP BACK AND RUN ALL TESTS AGAIN.
8039
8040 014112 004767 002754 4\$: JSR PC, RELO ;RELOCATE PROGRAM BACK TO FIRST 8K.
8041 014116 005737 000042 TST @#42 ;TEST FOR XXDP
8042 014122 001402 BEQ 6\$;IF NOT RUNNING UNDER MON. DONT
8043 014124 004767 003150 5\$: JSR PC, RESLDR ;RESTORE LOADERS.
8044 014130 004567 007366 6\$: JSR RS, \$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 014130 004567 007366 .WORD \$CRLF ;ADDRESS OF MESSAGE TO BE TYPED
(2) 014134 001201

CZQMC0 0-124K MEMORY EXERCISER, 16K VER B 7
CZQMCG.P11 12-MAR-80 13:07 DONE: MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-62

SEQ 0079

8046 :*****
(1)
(1) .SBTTL END OF PASS ROUTINE
(1)
(1) ::INCREMENT THE PASS NUMBER (\$PASS)
(1) ::TYPE 'END PASS #####' (WHERE ##### IS A DECIMAL NUMBER)
(1) ::IF THERE'S A MONITOR GO TO IT
(1) ::IF THERE ISN'T JUMP TO START1
(1)
(1) 014136 SEOP:
(2) 014136 000240 NOP
(1) 014140 005067 165024 CLR \$TIMES ::ZERO THE NUMBER OF ITERATIONS
(1) 014144 005267 165042 INC \$PASS ::INCREMENT THE PASS NUMBER
(1) 014150 042767 100000 165034 BIC #100000,\$PASS ::DON'T ALLOW A NEG. NUMBER
(1) 014156 005327 DEC (PC)+ ::LOOP?
(1) 014160 000001 SEOPCT: .WORD 1
(1) 014162 003040 BGT \$DOAGN ::YES
(1) 014164 012737 MOV (PC)+,a(PC)+ ::RESTORE COUNTER
(1) 014166 000001
(1) 014170 014160
(2) 014172 004567 007324 JSR R5, SPRINT ::GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 014176 014270 .WORD SENDMG ::ADDRESS OF MESSAGE TO BE TYPED
(2) 014200 016746 165006 MOV \$PASS,-(SP) ::SAVE \$PASS FOR TYPEOUT
(4) :: THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE STYPSD ROUTINE
(4) :: WAITOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
(4) 014204 013746 177776 MOV BAPSW, -(SP) ::PUT THE PROCESSOR STATUS ON THE STACK
(4) 014210 004767 010226 JSR PC, STYPSD ::GO TO THE SUBROUTINE
(2) 014214 004567 007302 JSR R5, SPRINT ::GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 014220 014305 .WORD SENULL ::ADDRESS OF MESSAGE TO BE TYPED
(1) 014222 \$GET42:
(1) 014222 016700 163614 MOV 42, R0 ::GET MONITOR ADDRESS
(1) 014226 001416 BEQ \$DOAGN ::BRANCH IF NO MONITOR
(1) 014230 000005 RESET ::CLEAR THE WORLD
(1) 014232 004710 SENDAD: JSR PC,(R0) ::GO TO MONITOR
(1) 014234 000240 NOP ::SAVE ROOM
(1) 014236 000240 NOP ::FOR
(1) 014240 000240 NOP ::ACT11
(1) 014242 023737 000042 000046 CMP #42,#46 ::ARE WE UNDER ACT11 OR XXDP
(1) 014250 001405 BEQ \$DOAGN ::IF ACT11 THEN RESTART
(1) 014252 105737 001224 TSTB #ENV ::CHECK FOR APT11
(1) 014256 001002 BNE \$DOAGN ::IF APT11 THEN RESTART
(1) 014260 004767 003074 JSR PC, SAVLDR ::IF XXDP FIRST SAVE MONITOR
(1) 014264 000167 171624 \$DOAGN: JMP START1 ::RETURN*****
(1) 014270 005015 047105 020104 SENDMG: .ASCIZ <15><12>/END PASS #/
(1) 014276 040520 051523 021440
(1) 014304 000
(1) 014305 377 377 000 SENULL: .BYTE -1,-1,0 ::NULL CHARACTER STRING
8047 .SBTTL SUBROUTINE AND TRAP ROUTINE SECTION.
8048 .SBTTL MEMORY MANAGEMENT AND ADDRESSING SUBROUTINES.
8049 :*****
8050 :: SET UP ALL THE MEM MGMT REGISTERS FOR NORMAL OPERATION.
8051 :: THE PROGRAM IS POINTED TO BY PARS 0 AND 1.
8052 :: THE MEMORY UNDER TEST IS POINTED TO BY PARS 2 AND 3.
8053 :: THE DEVICE ADDRESS AREA IS POINTED TO BY PAR 7.

```

8054 ;* PARS 4, 5, AND 6 ARE UNUSED.
8055 ;*****
8056 014310 MMINIT:
8057 (1) 014310 012737 077406 172300 MOV #200-1*400+UP+RW, @MKIPDR0 ;SET KIPDR0 = RW UP 200 BLOCKS
8058 014316 012737 077406 172302 MOV #200-1*400+UP+RW, @MKIPDR1 ;SET KIPDR1 = RW UP 200 BLOCKS
8059 014324 012737 077406 172304 MOV #200-1*400+UP+RW, @MKIPDR2 ;SET KIPDR2 = RW UP 200 BLOCKS
8060 014332 012737 077406 172306 MOV #200-1*400+UP+RW, @MKIPDR3 ;SET KIPDR3 = RW UP 200 BLOCKS
8061 014340 005037 172310 CLR @MKIPDR4
8062 014344 005037 172312 CLR @MKIPDR5
8063 014354 012737 077406 172316 CLR @MKIPDR6
8064 014362 005037 172340 MOV #200-1*400+UP+RW, @MKIPDR7 ;SET KIPDR7 = RW UP 200 BLOCKS
8065 014366 012737 000200 172342 CLR @MKIPAR0 ;MAP PAR0 INTO BANK0
8066 014374 005037 172344 MOV #200, @MKIPAR1 ;MAP PAR1 INTO BANK1
8067 014400 005037 172346 CLR @MKIPAR2 ;MAP PAR2 INTO BANK0
8068 014404 005037 172350 CLR @MKIPAR3
8069 014410 005037 172352 CLR @MKIPAR4
8070 014414 005037 172354 CLR @MKIPAR5
8071 014420 012737 007600 172356 CLR @MKIPAR6
8072 014426 012737 000001 177572 MOV #7600, @MKIPAR7 ;MAP PAR7 INTO I/O BANK
8073 014434 000207 RTS PC ;RETURN
8074
8075
8076 ;*****
8077 ;* MEMORY ADDRESS POINTER INITIALIZATION ROUTINES.
8078 ;*****
8079 014436 012767 000001 165100 INITMM: MOV #BIT0, BITPT ;SET POINTER TO BANK0
8080 014444 005067 165076 CLR BITPT+2 ;CLEAR HI 64K BANK POINTERS
8081 014450 005002 CLR R2 ;SET ADDRESS POINTER TO 0
8082 014452 016705 165130 MOV BLKMSK, R5 ;RESET R5 TO BLOCK MASK.
8083 014456 005767 164124 TST MMAVA ;CHECK FOR MEM MGMT AVAILABLE
8084 014462 001514 BEQ 10$ ;BRANCH IF NO MEM MGMT
8085 014464 005037 172344 CLR @MKIPAR2 ;SET UP 3RD PAR TO BANK0
8086 014470 012702 040000 MOV #40000, R2 ;RESET VIRTUAL ADR POINTER
8087 014474 036767 165044 165026 1$: BIT BITPT, TSTMAP ;CHECK IF THIS BANK TO BE TESTED
8088 014502 001015 BNE 2$ ;BRANCH IF MATCH
8089 014504 036767 165036 165020 BIT BITPT+2, TSTMAP+2 ;CHECK IN HI MAP
8090 014512 001011 BNE 2$ ;BRANCH IF MATCH
8091 014514 062737 000200 172344 ADD #200, @MKIPAR2 ;UPDATE MEM MGMT, THIRD PAR.
8092 014522 006367 165016 ASL BITPT ;UPDATE LO POINTER TO NEXT BANK.
8093 014526 006167 165014 ROL BITPT+2 ;...HI POINTER.
8094 014532 100360 BPL 1$ ;BR IF MORE.
8095 014534 000000 HALT ;FATAL ERROR!!! NO 4K BANK FOUND?
8096 014536 036767 165002 165036 2$: BIT BITPT, LADMAP ;CHECK IF LAST BANK.
8097 014544 001004 BNE 3$ ;BR IF LAST BANK.
8098 014546 036767 164774 165030 BIT BITPT+2, LADMAP+2 ;CHECK IF LAST BANK.
8099 014554 001405 BEQ 4$ ;BR IF NOT LAST BANK.
8100 014556 016705 165016 3$: MOV LADMSK, R5 ;SET MASK TO FIND LAST ADR.
8101 014562 042767 020000 165006 BIC #20000, TMPLAD ;MAKE SURE VIRTUAL LAST ADR IN BANK 2.
8102 014570 013737 172344 172346 4$: MOV @MKIPAR2, @MKIPAR3 ;COPY CURRENT PAR INTO FORTH PAR.
8103 014576 016767 164742 164744 MOV TMPPPT ;COPY BITPT...LO 64K.
8104 014604 016767 164736 164740 MOV BITPT+2, TMPPPT+2 ;...HI 64K.
8105 014612 032705 020000 BIT #BIT13, R5 ;CHECK FOR A BLOCK SIZE OF 8K.
8106 014616 001505 BEQ 2$ ;BRANCH IF NOT 8K.
8107 014620 062737 000200 172346 5$: ADD #200, @MKIPAR3 ;UP DATE FORTH PAR.
8108 014626 006367 164716 ASL TMPPPT ;UPDATE LO POINTER TO NEXT 4K BANK.

```

D 7

8109	014632	006167	164714		ROL	TMPPT+2	;..HI POINTER.	
8110	014636	100473			BMI	20\$;BR IF NO MORE.	
8111	014640	036767	164704	164662	BIT	TMPPT, TSTMAP	;CHECK IF BANK TO BE TESTED.	
8112	014646	001004			BNE	6\$;BRANCH IF A MATCH.	
8113	014650	036767	164676	164654	BIT	TMPPT+2, TSTMAP+2	;CHECK FOR HI 64K BANKS.	
8114	014656	001760			BEQ	5\$;BRANCH IF NO MEMORY	
8115	014660	036767	164664	164714	6\$:	BIT	TMPPT, LADMAP	;CHECK IF LAST BANK.
8116	014666	001004			BNE	7\$;BRANCH IF A MATCH	
8117	014670	036767	164656	164706	BIT	TMPPT+2, LADMAP+2	;CHECK HI 64K	
8118	014676	001455			BEQ	21\$;BR IF NOT LAST BANK.	
8119	014700	016705	164674		7\$:	MOV	LADMSK, R5	;RESET MASK TO FIND LAST ADR.
8120	014704	052767	020000	164664		BIS	#20000, TMPLAD	;MAKE SURE LAST ADDRESS IS IN BANK 3.
8121	014712	000447			BR	21\$;BR TO FINISH UP.	
8122								
8123	014714	036767	164624	164606	10\$:	BIT	BITPT, TSTMAP	;CHECK IF THIS BANK TO BE TESTED.
8124	014722	001006			BNE	11\$;BR IF MATCH.	
8125	014724	062702	020000		ADD	#20000, R2	;UPDATE PHYSICAL ADR PNTR TO NEXT BANK.	
8126	014730	106367	164610		ASLB	BITPT	;UPDATE BANK POINTER TO NEXT BANK.	
8127	014734	100367			BPL	10\$;BR IF MORE BANKS.	
8128	014736	000000			HALT		:FATAL ERROR!!! NO 4K BANK FOUND?	
8129	014740	016767	164600	164602	11\$:	MOV	BITPT, TMPPT	;COPY BANK POINTER.
8130	014746	036767	164572	164626		BIT	BITPT, LADMAP	;CHECK IF LAST BANK.
8131	014754	001021			BNE	12\$;BR IF LAST BANK.	
8132	014756	032705	020000		BIT	#BIT13, R5	;CHECK FOR 8K BLOCK SIZE.	
8133	014762	001423			BEQ	21\$;BRANCH IF SMALLER BLOCK SIZE.	
8134	014764	106367	164560		ASLB	TMPPT	;POINT TO NEXT BANK.	
8135	014770	100416			BMI	20\$;BRANCH IF OVERFLOW.	
8136	014772	036767	164552	164530	BIT	TMPPT, TSTMAP	;CHECK IF BANK TO BE TESTED.	
8137	015000	001412			BEQ	20\$;BRANCH IF NOT TO BE TESTED.	
8138	015002	112767	000011	164547	MOV	#11, FLAG8K	;SET 8K BLOCK SIZE FLAG.	
8139	015010	036767	164534	164564	BIT	TMPPT, LADMAP	;CHECK FOR LAST BANK.	
8140	015016	001403			BEQ	20\$;BR IF NOT LAST BANK.	
8141	015020	016705	164554		12\$:	MOV	LADMSK, R5	;RESET MASK TO FIND LAST ADR.
8142	015024	000402			BR	21\$;SKIP MASK RESET.	
8143	015026	012705	017777		20\$:	MOV	#MASK4K, R5	;RESET MASK TO 4K BLOCK SIZE.
8144	015032	056767	164506	164510	21\$:	BIS	BITPT, TMPPT	;SET TMPPT FOR FLAGGING LAST BANK.
8145	015040	056767	164502	164504	BIS	BITPT+2, TMPPT+2		
8146	015046	036767	164472	164514	BIT	BITPT, FADMAP	;CHECK IF FIRST ADDRESS NEEDS TO BE SET.	
8147	015054	001004			BNE	22\$;BR IF FIRST BANK.	
8148	015056	036767	164464	164506	BIT	BITPT+2, FADMAP+2	;CHECK HI 64K.	
8149	015064	001450			BEQ	INITEX	;BR IF NOT FIRST BANK.	
8150	015066	016702	164472		22\$:	MOV	TMPFAD, R2	;RESET ADDRESS POINTER TO FIRST ADR.
8151	015072	000445			BR	INITEX		
8152								
8153	015074	016705	164506		INITDN:	MOV	BLKMSK, R5	;RESET R5 TO CURRENT BLOCK MASK.
8154	015100	005002				CLR	R2	;INIT ADDRESS POINTER.
8155	015102	005767	163500			TST	MMAVA	;CHECK FOR MEM MGMT
8156	015106	001411				BEQ	31\$;BRANCH IF NO MEM MGMT
8157	015110	012767	100000	164430		MOV	#BIT15, BITPT+2	;SET POINTER TO TOP BIT
8158	015116	005067	164422			CLR	BITPT	
8159	015122	012737	007600	172344		MOV	#7600, #KIPAR2	;SET PAR TO TOP OF MEM
8160	015130	000403				BR	32\$;BRANCH TO COMMON AREA
8161								
8162	015132	012767	000400	164404	31\$:	MOV	#BIT8, BITPT	;SET UP BANK POINTER
8163	015140	012767	015162	164406	32\$:	MOV	#33\$, MMORE	;SET 'MMDOWN' EXIT ADDRESS.
8164	015146	066767	163426	164400		ADD	RELOCF, MMORE	;ADD OFFSET

```

8165 015154 004767 000524          JSR    PC,      MMODWN :ROUTINE TO SEARCH DOWNWARD FOR 'OP MEM BANK
8166 015160 000000          HALT   :FATAL ERROR!!! NO MEM INDICATED IN MEM MAP ABOVE 8K
8167 015162 036767 164356 164412 33$: BIT    BITPT, LADMAP ;CHECK FOR NON BOUNDARY LAST ADDR.
8168 015170 001004          BNE    34$: 34$    ;BR IF LAST BANK FLAG FOUND.
8169 015172 036767 164350 164404          BIT    BITPT+2,LADMAP+2 ;CHECK FOR NON BOUNDARY LAST ADDR.
8170 015200 001402          BEQ    INITEX ;BR IF NO LAD FLG FOUND.
8171 015202 016702 164366          MOV    LSTADR, R2 ;SET UP R2.
8172 015206 010467 164342          INITEX: MOV    R4,     MMORE ;PUT RETURN PC INTO 'MMORE'
8173 015212 000204          RTS    R4      ;RETURN
8174
8175 :***** COMMON UPWARDS ADDRESSING ROUTINE *****
8176 :* FINDS NEXT EXISTING 4K BANK AND UPDATES POINTERS.
8177 :* GOES TO ADDRESS IN 'MMORE' IF MORE BANKS.
8178 :* DOES STRAIGHT EXIT WHEN ALL MEMORY HAS BEEN DONE.
8179 :***** *****
8180
8181 015214 036767 164330 164360 MMUP: BIT    TMPPT, LADMAP ;CHECK FOR LAST BANK FLAG.
8182 015222 001122          BNE    10$: 10$    ;BR IF LAST BANK.
8183 015224 036767 164322 164352          BIT    TMPPT+2,LADMAP+2 ;CHECK FOR LAST BANK FLAG.
8184 015232 001116          BNE    10$: 10$    ;BR IF LAST BANK.
8185 015234 016705 164346          MOV    BLKMSK, RS ;RESET RS TO BLOCK MASK.
8186 015240 005767 163342          TST    MMAVA ;CHECK FOR MEM MGMT AVAILABLE
8187 015244 001515          BEQ    20$: 20$    ;BRANCH IF NO MEM MGMT
8188 015246 012702 040000          MOV    #40000, R2 ;RESET VIRTUAL ADR POINTER
8189 015252 062737 000200 172344 1$: ADD    #200, 2MKIPAR2 ;UPDATE MEM MGMT, THIRD PAR.
8190 015260 006367 164260          ASL    BITPT ;UPDATE LO POINTER TO NEXT BANK.
8191 015264 006167 164256          ROL    BITPT+2 ;..HI POINTER.
8192 015270 100577          BMI    32$: 32$    ;BR IF ALL DONE.
8193 015272 036767 164246 164230          BIT    BITPT, TSTMAP ;CHECK IF THIS BANK EXISTS
8194 015300 001004          BNE    2$: 2$    ;BRANCH IF MATCH
8195 015302 036767 164240 164222          BIT    BITPT+2,TSTMAP+2 ;CHECK IN HI MAP
8196 015310 001760          BEQ    1$: 1$    ;BRANCH IF NO MATCH
8197 015312 036767 164226 164262 2$: BIT    BITPT, LADMAP ;CHECK FOR LAST BANK FLAG.
8198 015320 001004          BNE    3$: 3$    ;BRANCH IF LAST BANK FLAG.
8199 015322 036767 164220 164254          BIT    BITPT+2,LADMAP+2 ;CHECK IF LAST BANK FLAG.
8200 015330 001405          BEQ    4$: 4$    ;BR IF NOT LAST BANK.
8201 015332 016705 164242          MOV    LADMSK, RS ;RESET MASK.
8202 015336 042767 020000 164232 3$: BIC    #20000, TMPLAD ;MAKE SURE VIRTUAL LAST ADR IN BANK 2
8203 015344 016767 164174 164176 4$: MOV    BITPT, TMPPT ;COPY BITPT...LO 64K.
8204 015352 016767 164170 164172          MOV    BITPT+2,TMPPT+2 ;..HI 64K.
8205 015360 032705 020000          BIT    #BIT13, RS ;CHECK FOR A BLOCK SIZE OF 8K.
8206 015364 001530          BEQ    31$: 31$    ;BRANCH IF NOT.
8207 015366 013737 172344 172346          MOV    2MKIPAR2,2MKIPAR3 ;COPY CURRENT PAR INTO FORTH PAR.
8208 015374 062737 000200 172346 5$: ADD    #200, 2MKIPAR3 ;UP DATE FORTH PAR.
8209 015402 006367 164142          ASL    TMPPT ;UPDATE LO POINTER TO NEXT 4K BANK.
8210 015406 006167 164140          ROL    TMPPT+2 ;..HI POINTER.
8211 015412 100513          BMI    30$: 30$    ;BR IF NO MORE.
8212 015414 036767 164130 164106 6$: BIT    TMPPT, TSTMAP ;CHECK IF BANK TO BE TESTED.
8213 015422 001004          BNE    7$: 7$    ;BRANCH IF A MATCH.
8214 015424 036767 164122 164100          BIT    TMPPT+2,TSTMAP+2 ;CHECK FOR HI 64K BANKS.
8215 015432 001760          BEQ    5$: 5$    ;BRANCH IF NO MEMORY
8216 015434 036767 164110 164140 7$: BIT    TMPPT,LADMAP ;CHECK FOR LAST BANK FLAG.
8217 015442 001004          BNE    8$: 8$    ;BRANCH IF A MATCH
8218 015444 036767 164102 164132          BIT    TMPPT+2,LADMAP+2 ;CHECK HI 64K
8219 015452 001475          BEQ    31$: 31$    ;BR IF NO LAST BANK FLAG.
8220 015454 016705 164120          MOV    LADMSK, RS ;RESET MASK TO FIND LAST ADDRESS.

```

F 7

```

8221 015460 052767 020000 164110      BIS     #20000, TMPLAD ;SET VIRTUAL ADR TO BANK 3.
8222 015466 000467
8223
8224 015470 026702 164102      10$:   CMP     TMPLAD, R2 ;CHECK IF LAST ADR REACHED.
8225 015474 001064      BNE     31$ ;BR IF MORE.
8226 015476 000474      BR      32$ ;BR IF ALL DONE.
8227
8228 015500 106267 164053      20$:   ASRB    FLAG8K ;SHIFT 8K FLAG
8229 015504 001407      BEQ     22$ ;BR IF NOT 8K BLOCK.
8230 015506 103455      BCS     30$ ;BR IF ANOTHER 4K.
8231 015510 105067 164043      CLR8    FLAG8K ;CLEAR OUT ALL FLAGS.
8232 015514 162702 060000      SUB    #40000, R2 ;BACK UP 8K.
8233 015520 062702 020000      21$:   ADD    #20000, R2 ;UPDATE PHYSICAL ADR PNTR TO NEXT BANK.
8234 015524 106367 164014      22$:   ASLB    BITPT ;UPDATE POINTER.
8235 015530 100457      BMI    32$ ;BRANCH WHEN END IS REACHED.
8236 015532 036767 164006 163770      BIT    BITPT, TSTMAP ;CHECK IF THIS BANK EXISTS.
8237 015540 001767      BEQ    21$ ;BRANCH IF NO MATCH.
8238 015542 036767 163776 164032      BIT    BITPT, LADMAP ;CHECK FOR LAST BANK FLAG.
8239 015550 001402      BEQ    23$ ;BR IF NO MATCH.
8240 015552 016705 164022      MOV    LADMSK, R5 ;RESET MASK TO FIND LAST ADR.
8241 015556 016767 163762 163764 23$:   MOV    BITPT, TMPPT ;SET UP TMP POINTER.
8242 015564 032705 020000      BIT    #BIT1$, R5 ;CHECK FOR 8K BLOCK SIZE.
8243 015570 001426      BEQ    31$ ;BRANCH IF SMALLER BLOCK SIZE.
8244 015572 106367 163752      ASLB    TMPPT ;POINT TO NEXT BANK.
8245 015576 100421      BMI    30$ ;BRANCH IF OVERFLOW.
8246 015600 036767 163744 163722      BIT    TMPPT, TSTMAP ;CHECK IF BANK TO BE TESTED.
8247 015606 001415      BEQ    30$ ;BRANCH IF NOT TO BE TESTED.
8248 015610 036767 163730 163764      BIT    BITPT, LADMAP ;CHECK FOR LAST BANK FLAG.
8249 015616 112767 000011 163733      MOVB    #11, FLAG8K ;SET 8K BLOCK FLAG.
8250 015624 036767 163714 163750      BIT    BITPT, LADMAP ;CHECK FOR LAST BANK FLAG.
8251 015632 001403      BEQ    30$ ;BR IF NO FLAG.
8252 015634 016705 163740      MOV    LADMSK, R5 ;RESET MASK TO FIND LAST ADR.
8253 015640 000402      BR     31$ ;RETURN
8254 015642 012705 017777      30$:   MOV    #MASK4K,R5 ;SET MASK TO 4K.
8255 015646 056767 163672 163674 31$:   BIS    BITPT, TMPPT ;SET TMPPT FOR FINDING LAST ADR.
8256 015654 056767 163666 163670      BIS    BITPT+2,TMPPT+2
8257 015662 016716 163666      MOV    MMORE, (SP) ;FUDGE RETURN ADDRESS TO LOOP.
8258 015666 000207      RTS    PC ;RETURN
8259      ;*: BEFORE FINAL EXIT, CHECK FOR ANY NON-TRAP PARITY ERRORS.
8260 015670 005767 164402      32$:   TST    MPRX ;CHECK FOR ANY PARITY REGISTERS PRESENT.
8261 015674 001402      BEQ    33$ ;BR IF NONE.
8262 015676 004767 001744      JSR    PC, CKPMER ;CHECK FOR PARITY MEMORY ERRORS.
8263 015702 000207      33$:   RTS    PC ;STRAIGHT RETURN.
8264
8265      ;*****
8266      ;*: MEMORY DOWNTOWARDS ADDRESSING SUBROUTINE.
8267      ;*: FINDS NEXT LOWER 4K BANK AND UPDATES POINTERS.
8268      ;*: GOES TO ADDRESS IN 'MMORE' IF MORE BANKS.
8269      ;*: DOES STRAIGHT EXIT WHEN ALL MEMORY HAS BEEN DONE.
8270      ;*****
8271 015704 036767 163634 163656  MMODOWN: BIT    BITPT, FADMAP ;CHECK FOR FIRST ADR FLAG.
8272 015712 001004      BNE    1$ ;BR IF FIRST ADR IN THIS BANK.
8273 015714 036767 163626 163650      BIT    BITPT+2,FADMAP+2 ;CHECK FOR FIRST ADR FLAG.
8274 015722 001404      BEQ    2$ ;BR IF NO FLAG
8275 015724 026702 163634      1$:   CMP    TMPFAD, R2 ;CHECK IF FIRST ADDRESS REACHED.
8276 015730 001052      BNE    9$ ;BR IF MORE.

```

CZQMC60 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-67
CZQMEG.P11 12-MAR-80 13:07 MEMORY MANAGEMENT AND ADDRESSING SUBROUTINES.

SEQ 0084

8277	015732	000453				BR	10\$:BR IF ALL DONE.
8278	015734	005767	162646	2\$:	TST	MMAVA		:CHECK IF MEM MGMT IS AVAILABLE
8279	015740	001425			BEQ	6\$:BRANCH IF NOT
8280	015742	162737	000200	172344	3\$:	SUB	#200, _MKIPAR2	:LOWER MEM MGMT PAR BY 4K
8281	015750	006067	163572		ROR	BITPT+2		:MOV POINTER TO NEXT LOWER BANK...HI MAP.
8282	015754	006067	163564		ROR	BITPT		...LO MAP.
8283	015760	103440			BCS	10\$:BR IF NO MORE.
8284	015762	036767	163556	163540	BIT	BITPT, TSTMAP		:CHECK FOR BANK EXISTING
8285	015770	001004			BNE	4\$:BR IF BANK TO BE TESTED.
8286	015772	036767	163550	163532	BIT	BITPT+2, TSTMAP+2		:CHECK FOR BANK IN HI MAP.
8287	016000	001760			BEQ	3\$:BR IF NOT THERE.
8288	016002	012702	060000	4\$:	MOV	#60000, R2		:SET ADR POINTER TO TOP OF BANK
8289	016006	000411			BR	7\$:GO TO COMMON EXIT
8290	016010	162702	020000	5\$:	SUB	#20000, R2		:BACK POINTER DOWN ONE BANK
8291	016014	006267	163524	6\$:	ASR	BITPT		:MOVE POINTER TO NEXT LOWER BANK
8292	016020	103420			BCS	10\$:BRANCH TO EXIT IF NO MORE MEM
8293	016022	036767	163516	163500	BIT	BITPT, TSTMAP		:CHECK IF BANK EXISTS
8294	016030	001767			BEQ	5\$:BRANCH IF BANK DOESN'T EXIST
8295	016032	036767	163506	163530	7\$:	BIT	BITPT, FADMAP	:CHECK IF FIRST BANK FLAG.
8296	016040	001004			BNE	8\$:BR IF FIRST BANK.
8297	016042	036767	163500	163522	BIT	BITPT+2, FADMAP+2		:CHECK IF FIRST BANK FLAG.
8298	016050	001402			BEQ	9\$:BR IF NO FLAG FOUND.
8299	016052	016705	163510	8\$:	MOV	FADMSK, R5		:SET UP R5 TO FIND FIRST ADDRESS.
8300	016056	016716	163472	9\$:	MOV	MMORE, (SP)		:RESET RETURN ADDRESS
8301	016062	000207		10\$:	RTS	PC		:RETURN

H 7

```

8303          .SBTTL SUBROUTINES FOR ADDRESS AND WORSE CASE NOISE TESTS.
8304
8305          ;* SUBROUTINE TO CALCULATE PHYSICAL ADDRESS AND PUT IT IN R0 (BOTTOM 16 BITS).
8306          ;* BITS 16 AND 17 ARE IN $TMPO.
8307
8308 016064 010200          PHYADR: MOV    R2,    R0      ;VITRUAL INTO R0
8309 016066 005067 163066      CLR    $TMPO     ;CLEAR TEMP SAVE OF HIGH BITS
8310 016072 005767 162510      TST    MMAVA     ;CHECK FOR MEM MGMT AVAILABLE
8311 016076 001417      BEQ    1$      ;BRANCH IF NO MEM MGMT
8312 016100 010146      MOV    R1,-(SP)   ;PUSH R1 ON STACK
8313 016102 013701 172344      MOV    @4KIPAR2, R1  ;GET PAR TO BE ADDED TO VIRTUAL
8314 016106 006301      ASL    R1       ;SHIFT IT 6 TIMES
8315 016110 006301      ASL    R1
8316 016112 006301      ASL    R1
8317 016114 006301      ASL    R1
8318 016116 006301      ASL    R1
8319 016120 006167 163034      ROL    $TMPO     ;SAVE EXTRA BITS
8320 016124 006301      ASL    R1
8321 016126 006167 163026      ROL    $TMPO
8322 016132 060100      ADD    R1,    R0      ;ADD SHIFTED PAR TO VIRTUAL
8323 016134 012601      MOV    (SP)+,R1  ;POP STACK INTO R1
8324 016136 000207      1$:    RTS    PC       ;RETURN
8325
8326
8327          ;* SUBROUTINE TO PUT BANK NUMBER INTO R0.
8328
8329 016140 005000          BANKNO: CLR    R0      ;INIT R0
8330 016142 010146      MOV    R1,-(SP)   ;PUSH R1 ON STACK
8331 (2) 016144 010246      MOV    R2,-(SP)   ;PUSH R2 ON STACK
8332 016146 016701 163372      MOV    BITPT, R1    ;GET BANK MAP POINTER...LO 64K.
8333 016152 016702 163370      MOV    BITPT+2,R2  ;...HI 64K.
8334 016156 006202      1$:    ASR    R2       ;SHIFT POINTER...HI
8335 016160 006001      ROR    R1       ;...LO
8336 016162 103403      BCS    2$      ;BR WHEN POINTER FOUND.
8337 016164 105200      INCB   R0      ;COUNT BANKS.
8338 016166 100373      BPL    1$      ;BR IF NOT OVERFLOW.
8339 016170 000000      HALT   R0      ;FATAL ERROR!!! NO POINTER FOUND.
8340 016172 012602      2$:    MOV    (SP)+,R2  ;POP STACK INTO R2
8341 (2) 016174 012601      MOV    (SP)+,R1  ;POP STACK INTO R1
8342 016176 000207      RTS    PC       ;RETURN
8343
8344          ;* SUBROUTINE TO WRITE THE CONSTANT IN R0 INTO ALL OF MEMORY.
8345 016200          SETCON:
8346 (1) 016200 004467 176232      2$:    JSR    R4,    INITMM  ;INITIALIZE THE MEMORY ADDRESS POINTERS.
8347 016204 010022      MOV    R0,    (R2)+  ;MOV CONSTANT INTO MEMORY
8348 016206 030502      BIT    R5,    R2      ;CHECK FOR END OF A BLOCK.
8349 (1) 016210 001375      BNE    2$      ;BRANCH IF MORE IN CURRENT BLOCK.
8350 (1) 016212 004767 176776      JSR    PC,    MMUP    ;FIND NEXT BLOCK AND LOOP TO 1$.
8351 016216 000207      RTS    PC       ;RETURN

```

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 12-MAR-80 13.10 PAGE 59-6
CZOMCG.P11 12-MAR-80 13:07 SUBROUTINES FOR ADDRESS AND WORSE CASE NOISE TESTS.

SEQ 0086

8350 ;*****
8351 ;* ROUTINE TO ROTATE 'C' BIT THROUGH A MEMORY LOCATION.
8352 ;*****
8353 016220 106112 ROTATE: ROLB (R2) ;(R2)=177776 OR 000001
8354 016222 106112 ROLB (R2) ;(R2)=177775 OR 000002
8355 016224 106112 ROLB (R2) ;(R2)=177773 OR 000004
8356 016226 106112 ROLB (R2) ;(R2)=177767 OR 000010
8357 016230 106112 ROLB (R2) ;(R2)=177757 OR 000020
8358 016232 106112 ROLB (R2) ;(R2)=177737 OR 000040
8359 016234 106112 ROLB (R2) ;(R2)=177677 OR 00010C
8360 016236 106112 ROLB (R2) ;(R2)=177777 OR 000000
8361 016240 106122 ROLB (R2)+ ;(R2)=177577 OR 000200
8362 016242 106112 ROLB (R2) ;(R2)=177377 OR 000400
8363 016244 106112 ROLB (R2) ;(R2)=176777 OR 001000
8364 016246 106112 ROLB (R2) ;(R2)=175777 OR 002000
8365 016250 106112 ROLB (R2) ;(R2)=173777 OR 004000
8366 016252 106112 ROLB (R2) ;(R2)=167777 OR 010000
8367 016254 106112 ROLB (R2) ;(R2)=157777 OR 020000
8368 016256 106112 ROLB (R2) ;(R2)=137777 OR 040000
8369 016260 106112 ROLB (R2) ;(R2)=077777 OR 100000
8370 016262 106122 ROLB (R2)+ ;(R2)=177777 OR 000000
8371 016264 000207 RTS PC ;RETURN
8372 ;*****
8373 ;* SUBROUTINE TO WRITE 3 XOR 9 PATTERN INTO 256. WORD BLOCK.
8374 ;*****
8375 ;*****
8376 016266 012704 000020 W3X9: MOV #16.,R4 ;EACH LOOP WRITES 256. WORDS
8377 ;\$:
8378 016272 010022 MOV R0,(R2)+
8379 016274 010022 MOV R0,(R2)+
8380 016276 010022 MOV R0,(R2)+
8381 016300 010022 MOV R0,(R2)+
8382 ;\$:
8383 016302 010322 MOV R3,(R2)+
8384 016304 010322 MOV R3,(R2)+
8385 016306 010322 MOV R3,(R2)+
8386 016310 010322 MOV R3,(R2)+
8387 ;\$:
8388 016312 010022 MOV R0,(R2)+
8389 016314 010022 MOV R0,(R2)+
8390 016316 010022 MOV R0,(R2)+
8391 016320 010022 MOV R0,(R2)+
8392 ;\$:
8393 016322 010322 MOV R3,(R2)+
8394 016324 010322 MOV R3,(R2)+
8395 016326 010322 MOV R3,(R2)+
8396 016330 010322 MOV R3,(R2)+
8397 ;\$:
8398 016332 005304 DEC R4
8399 016334 001356 BNE 2\$
8400 016336 010046 MOV R0, -(SP) ;SAVE R0
 (1) 016340 010300 MOV R3, R0 ;PUT R3 INTO R0
 (1) 016342 012603 MOV (SP)+, R3 ;PUT SAVED R0 INTO R3
8401 016344 000207 RTS PC ;RETURN

8403 .SBTTL RELOCATION SUBROUTINES.
 8404 ;*****
 8405 ;* ROUTINE TO RELOCATE PROGRAM CODE
 8406 ;*****
 8407 016346 RÉLOC:
 (2) 016346 010246 MOV R2,-(SP) ;PUSH R2 ON STACK
 (2) 016350 010346 MOV R3,-(SP) ;PUSH R3 ON STACK
 (2) 016352 010446 MOV R4,-(SP) ;PUSH R4 ON STACK
 8408 016354 012502 4\$: MOV (R5)+, R2 ;GET FIRST LOCATION.
 8409 016356 012503 MOV (R5)+, R3 ;GET FIRST LOCATION OF DESTINATION.
 8410 016360 012704 020000 1\$: MOV #20000, R4 ;SET UP 8K COUNTER.
 8411 016364 012223 MOV (R2)+, (R3)+ ;MOV THE DATA.
 8412 016366 005304 DEC R4 ;COUNT THE WORDS.
 8413 016370 001375 BNE 1\$;BR IF MORE.
 8414 016372 012704 020000 MOV #20000, R4 ;RESET THE COUNTER.
 8415 016376 024243 2\$: CMP -(R2), -(R3) ;CHECK THE DATA JUST MOVED.
 8416 016400 001417 BEQ 3\$;BR IF DATA OK.
 8417 016402 011267 162516 MOV (R2), \$GDDAT ;GET SOURCE DATA.
 8418 016406 011367 162514 MOV (R3), \$BDDAT ;GET DESTINATION DATA.
 8419 016412 010267 162502 MOV R2, \$GDADR ;GET SOURCE ADDRESS.
 8420 016416 010367 162500 MOV R3, \$BDADR ;GET DESTINATION ADDRESS.
 8421 016422 004767 003222 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 (1) 016426 000023 .WORD 23 ;ERROR TYPE CODE.
 8422 016430 000000 HALT ;FATAL ERROR!!! RELOCATION FAILED.
 8423 016432 162705 000004 SUB #4, R5 ;ADJUST RETURN POINTER.
 8424 016436 000746 BR 4\$;GO BACK AND TRY AGAIN.
 8425 016440 005304 3\$: DEC R4 ;COUNT WORDS.
 8426 016442 001355 BNE 2\$;BR IF MORE.
 8427 016444 004567 005052 JSR R5, \$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
 (2) 016450 026552 .WORD PRÉLOC ;ADDRESS OF MESSAGE TO BE TYPED
 (1) ;PROGRAM RELOCATED TO ''
 8428 016452 010346 MOV R3, -(SP) ;PUT THE DATA ON THE STACK.
 (1) 016454 004767 006502 JSR PC, \$TYPAD ;DETERMINE THE PHYSICAL ADDRESS AND TYPE IT.
 8429 016460 012604 MOV (SP)+, R4 ;POP STACK INTO R4
 (2) 016462 012603 MOV (SP)+, R3 ;POP STACK INTO R3
 (2) 016464 012602 MOV (SP)+, R2 ;POP STACK INTO R2
 8430 016466 000205 RTS R5 ;RETURN
 8431 ;*****
 8432 ;* SUBROUTINE TO MOVE PROGRAM FROM BOTTOM TO TOP OF MEMORY.
 8433 ;*****
 8434 016470 022767 000003 162104 RÉLTOP: CMP #3, PRGMAP ;CHECK THAT THE PROGRAM IS NOW IN BANKS 0 AND 1.
 8435 016476 001401 BEQ 1\$;BR IF OK
 8436 016500 000000 HALT ;FATAL ERROR!!! PROG SHOULD BE IN BANKS 0 AND 1
 8437 016502 1\$: ;*****
 (2) 016502 010046 MOV R0,-(SP) ;PUSH R0 ON STACK
 (2) 016504 010146 MOV R1,-(SP) ;PUSH R1 ON STACK
 8438 016506 005767 162074 TST MMAVA
 8439 016512 001465 BEQ 10\$
 8440 016514 012737 007600 172346 MOV #7600, @KIPAR3 ;SET PAR TO TOP OF MEM
 8441 016522 005000 CLR R0 ;INIT BANK POINTER...LO 64K
 8442 016524 012701 100000 MOV #BIT15, R1 ;...HI 64K.
 8443 016530 162737 000200 172346 2\$: SUB #200, @KIPAR3 ;BACK DOWN ONE BANK.
 8444 016536 006001 ROR R1 ;MOVE POINTER...HI 64K.
 8445 016540 006000 ROR R0 ;...LO 64K.
 8446 016542 103500 BCS 90\$
 8447 016544 030167 162756 BIT R1, MEMMAP+2 ;CHECK FOR BANK EXISTS.

8448 016550 001003 BNE 3\$;BR IF AVAILABLE
 8449 016552 030067 162746 BIT R0, MEMMAP ;CHECK FOR BANK EXISTS.
 8450 016556 001764 BEQ 2\$;BR IF NO BANK FOUND.
 8451 016560 013737 172346 172344 3\$: MOV @MKIPAR3, @MKIPAR2 ;COPY PAR
 8452 016566 010046 MOV R0,-(SP) ;PUSH R0 ON STACK
 (2) 016570 010146 MOV R1,-(SP) ;PUSH R1 ON STACK
 8453 016572 162737 000200 172344 4\$: SUB #200, @MKIPAR2 ;BACK DOWN WITH LOW PAR.
 8454 016600 006001 ROR R1 ;SHIFT POINTER.
 8455 016602 006000 ROR R0 ;LO 64K.
 8456 016604 103457 BCS 90\$;BR IF OVERFLOW.
 8457 016606 030167 162714 5\$: BIT R1, MEMMAP+2 ;CHECK IF BANK EXISTS...HI 64K.
 8458 016612 001003 BNE 6\$;BR IF BANK EXISTS.
 8459 016614 030067 162704 BIT R0, MEMMAP ;CHECK IF BANK EXISTS...LO 64K.
 8460 016620 001764 BEQ 4\$;BR IF BANK DOESN'T EXIST.
 8461 016622 052601 BIS (SP)+, R1 ;GET SECOND BANK POINTER.
 8462 016624 052600 BIS (SP)+, R0 ;LO 64K.
 8463 016626 030067 161750 BIT R0, PRGMAP ;CHECK FOR CONFLICT.
 8464 016632 001044 BNE 90\$;ABORT IF DESTINATION OVERLAYS SOURCE.
 8465 016634 004567 177506 JSR R5, RELOC ;GO RELOCATE PROGRAM.
 8466 016640 000000 .WORD 0 ;SOURCE FIRST ADDRESS.
 8467 016642 040000 .WORD 40000 ;DESTINATION FIRST ADDRESS.
 8468 016644 013737 172344 172340 MOV @MKIPAR2, @MKIPAR0 ;RELOCATE LO BANK
 8469 016652 013737 172346 172342 MOV @MKIPAR3, @MKIPAR1 ;RELOCATE HI BANK.
 8470 :* PROGRAM SHOULD NOW BE EXECUTING OUT OF LAST TWO BANKS OF MEMORY.
 8471 016660 010167 161720 MOV R1, PRGMAP+2 ;RESET PROGRAM MAP.
 8472 016664 000473 BR 30\$;BR TO COMMON EXIT.
 8473
 8474 016666 012700 000400 10\$: MOV #BIT8, R0 ;SET BANK POINTER TO TOP OF MEM.
 8475 016672 005001 CLR R1 ;SET ADDRESS POINTER TO TOP.
 8476 016674 162701 020000 11\$: SUB #20000, R1 ;BACK DOWN ONE BANK.
 8477 016700 006200 ASR R0 ;MOVE POINTER DOWN ONE BANK.
 8478 016702 103420 BCS 90\$;BR IF OVERFLOW.
 8479 016704 030067 162614 BIT R0, MEMMAP ;CHECK IF THIS BANK EXISTS.
 8480 016710 001771 BEQ 11\$;BR IF NON-EXISTANT BANK.
 8481 016712 162701 020000 SUB #20000, R1 ;BACK DOWN TO NEXT BANK.
 8482 016716 006200 ASR R0 ;MOV POINTER DOWN ONE BANK.
 8483 016720 103411 BCS 90\$;BR IF OVERFLOW.
 8484 016722 030067 162576 BIT R0, MEMMAP ;CHECK IF THIS BANK EXISTS.
 8485 016726 001762 BEQ 11\$;BR TO START OVER IF NO LOWER BANK.
 8486 016730 010046 MOV R0, -(SP) ;SAVE THE POINTER.
 8487 016732 006300 ASL R0 ;RESET POINTER TO HI BANK.
 8488 016734 052600 BIS (SP)+, R0 ;SET BIT FOR LO BANK.
 8489 016736 030067 161640 BIT R0, PRGMAP ;CHECK FOR A PROGRAM CONFLICT.
 8490 016742 001401 BEQ 12\$;BR IF NO CONFLICT.
 8491 016744 000000 90\$: HALT ;FATAL ERROR!!! NOT ENOUGH MEMORY??
 (1) 016744 000000
 8492 016746 010167 000006 12\$: MOV R1, 13\$;SET DATA FOR RELOCATION SUBROUTINE.
 8493 016752 004567 177370 JSR R5, RELOC ;GO RELOCATE THE PROGRAM TO TOP OF MEM.
 8494 016756 000000 .WORD 0 ;SOURCE STARTING ADDRESS.
 8495 016760 000000 .WORD 0 ;DESTINATION STARTING ADDRESS.
 8496 016762 010167 161612 MOV R1, RELOC ;SET RELOCATION FACTOR IN UNRELOCATED CODE.
 8497 016766 060107 ADD R1, PC ;JUMP TO RELOCATED PROGRAM
 8498 :* PROGRAM NOW EXECUTING OUT OF TOP OF MEMORY.
 8499 016770 060106 ADD R1, SP ;ADJUST THE STACK POINTER TO TOP OF MEMORY.
 8500 016772 010167 161602 MOV R1, RELOC ;SET THE RELOCATION FACTOR.
 8501 016776 060137 000004 ADD R1, @ERRVEC ;ADJUST ERROR VECTOR.

8502	017002	060137	000024		ADD	R1,	AMPWREVC	:ADJUST POWER FAIL VECTOR.
8503	017006	060137	000114		ADD	R1,	AMPARVEC	:ADJUST PARITY ERROR VECTOR.
8504	017012	026727	162122	1775/0	CMP	SWR,	#177570	:CHECK FOR HARDWARE SWITCH REGISTER.
8505	017020	001404			BEQ	14\$:BR IF HARDWARE SWITCH REGISTER.
8506	017022	060167	162112		ADD	R1,	SWR	:ADJUST SOFTWARE SWITCH REGISTER.
8507	017026	060167	162110		ADD	R1,	DISPLAY	:ADJUST SOFTWARE DISPLAY REGISTER.
8508	017032	062701	001622	14\$:	ADD	#RADTAB,R1		:POINT TO THE RELATIVE RELOCATION TABLE.
8509	017036	066721	161536	15\$:	ADD	RELOCF, (R1)+		:ADD RELOCATION FACTOR TO ADDRESSES IN TABLE.
8510	017042	005721		16\$:	TST	(R1)+		:CHECK FOR INTERUM TERMINATOR.
8511	017044	001776			BEQ	16\$:BR SO AS TO NOT MODIFY ZERO.
8512	017046	024127	177777		CMP	-(R1), #-1		:CHECK FOR END OF TABLE.
8513	017052	001371			BNE	15\$:BR IF MORE IN TABLE.
8514	017054	010067	161522	30\$:	MOV	R0,	PRGMAP	:SET NEW PROGRAM MAP...LO 64K.
8515	017060	012601			MOV	(SP)+,R1		:POP STACK INTO R1
(2)	017062	012600			MOV	(SP)+,R0		:POP STACK INTO R0
8516	017064	066716	161510		ADD	RELOCF, (SP)		:ADJUST RETURN ADDRESS.
8517	017070	000207			RTS	PC		:RETURN
8518								
8519								*****
8520								/* SUBROUTINE TO RELOCATE PROGRAM BACK TO BANKS 0 AND 1.
8521								*****
8522	017072	032767	000003	161502	RELO:	BIT	#3,	PRGMAP :CHECK FOR PROGRAM ALREADY IN BANKS 0 OR 1.
8523	017100	001401				BEQ	1\$:BR IF NO CONFLICT.
8524	017102	000000				HALT		:FATAL ERROR!!! PROGRAM ALREADY IN BANKS 0 OR 1
8525	017104	005767	161476		1\$:	TST	MMAVA	:CHECK FOR MEM MGMT.
8526	017110	001417				BEQ	10\$:BR IF NO MEMMGMT.
8527	017112	005037	172344			CLR	AMKIPAR2	:SET PAR 2 TO BANK 0.
8528	017116	012737	000200	172346		MOV	#200, AMKIPAR3	:SET PAR 3 TO BANK 1.
8529	017124	004567	177216			JSR	R5, F_LOC	:GO MOVE 8K INTO BANKS 0 AND 1.
8530	017130	000000				.WORD	0	:SOURCE STARTING ADDRESS.
8531	017132	040000				.WORD	40000	:DESTINATION STARTING ADDRESS.
8532	017134	005037	172340			CLR	AMKIPAR0	:RESTORE PAR 0 TO BANK0.
8533	017140	012737	000200	172342		MOV	#200, AMKIPAR1	:RESTORE PAR 1 TO BANK 1.
8534								:* PROGRAM IS NOW EXECUTING OUT OF BANKS 0 AND 1.
8535	017146	000444				BR	30\$:BR TO COMMON EXIT.
8536								
8537	017150	016746	161424		10\$:	MOV	RELOCF, -(SP)	:PUT RELOCATION FACTOR ONTO THE STACK.
8538	017154	011667	000004			MOV	(SP), 20\$:SET DATA FOR RELOC SUBROUTINE.
8539	017160	004567	177162			JSR	R5, RELOC	:GO MOVE THE PROGRAM BACK TO BANKS 0 AND 1.
8540	017164	000000				.WORD	0	:SOURCE STARTING ADDRESS.
8541	017166	000000				.WORD	0	:DESTINATION STARTING ADDRESS.
8542	017170	161607				SUB	(SP), PC	:JUMP TO RELOCATED PROGRAM.
8543								:* THE PROGRAM IS NOW EXECUTING OUT OF BANKS 0 AND 1.
8544	017172	161606				SUB	(SP), SP	:RESET THE STACK POINTER.
8545	017174	010046				MOV	R0,-(SP)	:PUSH R0 ON STACK
8546	017176	012700	001622			MOV	#RADTAB,R0	:SET UP POINTER TO RELATIVE ADDRESS TABLE.
8547								
8548	017202	166620	000002		21\$:	SUB	2(SP), (R0)+	:RESET ADDRESSES TO UNRELOCATED VALUES.
8549	017206	005720			22\$:	TST	(R0)+	:CHECK FOR TERMINATORS.
8550	017210	001776				BEQ	22\$:BR OVER TERMINATORS.
8551	017212	024027	177777			CMP	-(R0), #-1	:CHECK FOR END OF TABLE INDICATOR.
8552	017216	001371				BNE	21\$:BR IF MORE ADDRESSES IN TABLE.
8553	017220	012600				MOV	(SP)+,R0	:POP STACK INTO R0
8554	017222	161637	000004			SUB	(SP), AMPERRVEC	:ADJUST ERROR VECTOR.
8555	017226	161637	000024			SUB	(SP), AMPWREVC	:ADJUST POWER FAIL VECTOR.
8556	017232	161637	000114			SUB	(SP), AMPARVEC	:ADJUST PARITY ERROR VECTOR.

8557	017236	026727	161676	177570	CMP	SWR,	#177570	:CHECK FOR HARDWARE SWITCH REGISTER.		
8558	017244	001404			BEQ	23\$:BR IF HARDWARE SWITCH REGISTER.		
8559	017246	161667	161666		SUB	(SP),	SWR	:ADJUST SOFTWARE SWITCH REGISTER.		
8560	017252	161667	161664		SUB	(SP),	DISPLAY	:ADJUST SOFTWARE DISPLAY REGISTER.		
8561	017256	162616			SUB	(SP)+,	(SP)	:ADJUST RETURN ADDRESS.		
8562	017260	005067	161314	161310	23\$: CLR	RELOCF		:RESET RELOCATION FACTOR.		
8563	017264	012767	000003		30\$: MOV	#3,	PRGMAP	:SET PROGRAM MAP TO POINT TO BANKS 0 AND 1.		
8564	017272	005067	161306		CLR	PRGMAP+2		:.. HI 64K.		
8565	017276	000207			RTS	PC		:RETURN.		
8566										
8567					*****					
8568					*: THIS SUBROUTINE MOVES THE LOADER AREA BACK TO THE 'TOP' OF MEMORY FROM					
8569					: WHENCE IT CAME. THE LOADER AREA IS SAVED AT THE END OF THE 8K OF					
8570					: PROGRAM CODE WHEN THE PROGRAM IS INITIALLY RUN.					
8571					*****					
8572	017300	016700	162214		RESLDR: MOV	LMAD,	R0	:CHECK IF THE LOADERS WERE SAVED.		
8573	017304	001001			BNE	1\$:BR IF LOADER AREA WAS SAVED.		
8574	017306	000000			HALT			:FATAL ERROR!!! CAN'T RESTORE LOADER AREA IF IT WASN'T SAVED.		
8575	017310	005767	161272		1\$: TST	MMAVA		:CHECK FOR MEM MGMT.		
8576	017314	001402			BEQ	2\$:SKIP IF NO MEM MGMT.		
8577	017316	005037	177572		CLR	2\$SR0		:DISABLE MEM MGMT.		
8578	017322	012701	040000		2\$: MOV	#40000, R1		:GET END OF 8K, ASSUME PROG NOT RELOCATED.		
8579	017326	012702	002734		MOV	#1500.. R2		:GET COUNTER.		
8580	017332	014140			3\$: MOV	-(R1), -(R0)		:MOVE THE LOADER AREA.		
8581	017334	005302			DEC	R2		:COUNT HOW LONG THE AREA IS.		
8582	017336	001375			BNE	3\$:BR IF NOT MORE TO MOVE.		
8583	017340	005067	162154		CLR	LMAD		:CLEAR MONITOR SAVED FLAG		
8584	017344	005767	161236		TST	MMAVA		:CHECK FOR MEM MGMT.		
8585	017350	001402			BEQ	4\$:BR IF NO MEM MGMT.		
8586	017352	005237	177572		INC	2\$SR0		:ENABLE MEM MGMT.		
8587	017356	U00207			4\$: RTS	PC		:RETURN.		
8588										
8589					*: ROUTINE TO SAVE THE LOADERS AT THE END OF 8K.					
8590	017360	005767	162134		SAVLDR: TST	LMAD		:CHECK IF LOADERS HAVE BEEN SAVED ALREADY.		
8591	017364	001024			BNE	4\$:BRANCH IF ALREADY SAVED		
8592	017366	012700	040000		MOV	#40000, R0		:GET END OF 8K		
8593	017372	010001			MOV	R0, R1		:GET END OF 8K		
8594	017374	012737	017406	000004	1\$: MOV	#2\$, 2\$ERRVEC		:SET UP TIMEOUT VECTOR		
8595	017402	011020			(R0), (R0)+			:SEARCH FOR END OF MEMORY		
8596	017404	000776			BR	1\$:KEEP SEARCHING		
8597	017406	022626			2\$: CMP	(SP)+, (SP)+		:RESTORE STACK POINTER		
8598	017410	012737	025124	000004	MOV	#ERRTRP, 2\$ERRVEC		:RESET TIMEOUT VECTOR.		
8599	017416	010046			MOV	R0, -(SP)		:SAVE LAST MEMORY ADDRESS (CONTIGUOUS)		
8600	017420	012702	002734		MOV	#1500.. R2		:SET UP WORD COUNTER		
8601	017424	014041			3\$: MOV	-(R0), -(R1)		:SAVE THE LOADERS		
8602	017426	005302			DEC	R2		:COUNT THE WORDS		
8603	017430	001375			BNE	3\$:BRANCH IF MORE WORDS		
8604	017432	012667	162062		MOV	(SP)+, LMAD		:SAVE LAST MEMORY ADDRESS		
8605	017436	000207			4\$: RTS	PC		:RETURN.		

8607 .SBTTL PARITY MEMORY TRAP SERVICE AND SUBROUTINES.
 8608 :*****
 8609 :* PARITY MEMORY UNEXPECTED ERROR TRAP SERVICE ROUTINE.
 8610 :* FIND OUT WHICH REGISTER DETECTED THE ERROR.
 8611 :* THEN SCAN MEMORY TO SEE IF PARITY ERROR STILL SET AND REPORT LOCATION.
 8612 :*****
 8613 017440 011667 161456 PESRV: MOV (SP), \$BDADR ;GET PC OF INSTRUCTION WHICH CAUSED ERROR.
 8614 017444 004567 004052 JSR R5, \$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
 (2) 017450 026511 .WORD UNEXPT ;ADDRESS OF MESSAGE TO BE TYPED
 (1) ;'UNEXPECTED MEMORY PARITY TRAP.'
 8615 017452 010146 MOV R1,-(SP) ;PUSH R1 ON STACK
 (2) 017454 010346 MOV R3,-(SP) ;PUSH R3 ON STACK
 8616 017456 016703 162146 1\$: MOV ,MPRX, R3 ;GET POINTER TO PARITY REGISTERS.
 8617 017462 005733 TST @R3+ ;CHECK THE PARITY REG FOR AN ERROR FLAG.
 8618 017464 100415 BMI 3\$;BR IF THIS REGISTER SHOWS THE ERROR.
 8619 017466 005713 TST (R3) ;CHECK FOR TABLE TERMINATOR.
 8620 017470 001374 BNE 1\$;BR IF MORE REGISTERS.
 8621 017472 004767 002152 JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 (1) ;***ERROR*** NO REGISTER INDICATED ERROR
 (1) 017476 000024 .WORD 24 ;ERROR TYPE CODE.
 8622 017500 000417 BR 4\$;EXIT
 8623 017502 005713 2\$: TST (R3) ;CHECK FOR TABLE TERMINATOR.
 8624 017504 001415 BEQ 4\$;BR IF NO MORE PARITY REGISTERS.
 8625 017506 005733 TST @R3+ ;CHECK THE PARITY REG FOR AN ERROR FLAG.
 8626 017510 100374 BPL 2\$;BR IF NO ERROR FLAG.
 8627 017512 004567 004004 JSR R5, \$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
 (2) 017516 026602 .WORD MTOE ;ADDRESS OF MESSAGE TO BE TYPED
 (1) ;'MORE THAN ONE ERROR FOUND.'
 8628 017520 004767 000610 3\$: ;SET UP VALUES FOR ERROR PRINTING.
 (1) 017520 004767 002120 64\$: JSR PC, SPRNTQ ;*** ERROR *** (GO TYPE A MESSAGE)
 (2) 017524 004767 002120 .WORD 25 ;ERROR TYPE CODE.
 (2) 017530 000025 JSR PC, PSCAN ;GO SCAN MEMORY FOR BAD PARITY.
 8629 017532 004767 000216 8630 017536 000761 BR 2\$;GO LOOK FOR MORE ERRORS.
 8631 017540 (2) 017540 012603 4\$: MOV (SP)+,R3 ;POP STACK INTO R3
 (2) 017542 012601 MOV (SP)+,R1 ;POP STACK INTO R1
 8632 017544 000002 RTI ;RETURN.
 8633 ;*****
 8634 ;ROUTINE TO ENABLE PARITY ERROR ACTION ON MA/MF PARITY MEMORIES
 8635 ;THIS ROUTINE IS MEANT TO CATCH UNEXPECTEDS
 8636 ;*****
 8637 MAMF: TST MPRX ;CHECK IF ANY PARITY REGISTERS EXIST.
 8638 017546 005767 162524 BEQ MAMF2 ;EXIT IF NO PARITY REGISTERS.
 8639 017552 001434 BIT #SW6, @ASWR ;CHECK FOR INHIBIT PARITY ERROR DETECTION.
 8640 017554 032777 000100 161356 BNE MAMF2 ;EXIT IF NO PARITY ERROR DETECTION.
 8641 017562 001030 TST RELOCF ;CHECK IF PROGRAM RELOCATED OUT OF BANK 0.
 8642 017564 005767 161010 BEQ SETAE ;BR IF PROG IN BANK 0.
 8643 017570 001410 BIT #SW5, @ASWR ;CHECK IF VECTORS PROTECTED.
 8644 017572 032777 000040 161340 BNE SETAE ;BR IF VECTOR AREA PROTECTED.
 8645 017600 001004 CMP FSTADR, #1000 ;CHECK FOR STARTING ADDRESS ABOVE THE VECTORS.
 8646 017602 026727 161754 001000 BLO MAMF2 ;EXIT IF VECTORS EXPOSED TO TESTING.
 8647 017610 103415 SETAE: MOV .PESRV, @PARVEC ;SET PARITY ERROR TRAP VECTOR
 8648 CLR @PARVEC+2 ;PRIORITY LEVEL 0 ON TRAP
 8649 017612 016737 162020 000114
 8650 017620 005037 000116

8651	017624	010346		MOV	R3,-(SP)	;PUSH R3 ON STACK
8652	017626	016703	161776	MOV	.MPRX, R3	;GET PARITY REGISTER TABLE POINTER.
8653	017632	052733	000001	MAMF1:	BIS #AE,(R3)+	;SET ACTION ENABLE BIT IN PARITY REG
8654	017636	005713		TST (R3)		;CHECK FOR END OF TABLE.
8655	017640	001374		BNE MAMF1		;BR IF MORE PARITY REGISTERS.
8656	017642	012603		MOV (SP)+,R3		;POP STACK INTO R3
8657	017644	000207		MAMF2: RTS	PC	;RETURN.
8658						
8659						;*****
8660						;* SUBROUTINE TO CHECK PARITY REGISTERS FOR ERRORS THAT DIDN'T TRAP.
8661						;*****
8662	017646			CHGG2:		
8663	017646	005767	162424	CKPMER: TST	MPRX	;CHECK IF ANY PARITY REGISTERS EXIST.
8664	017652	001437		BEQ 4\$;BR IF NO PARITY REGISTERS.
8665	017654	032777	000100 161256	BIT #SW6, ASWR		;CHECK FOR INHIBIT PARITY ERROR CHECKING.
8666	017662	001033		BNC 4\$;BR IF PARITY ERROR CHECKING INHIBITED.
8667	017664	010346		MOV R3,-(SP)		;PUSH R3 ON STACK
8668	017666	016703	161736	MOV .MPRX, R3		;GET PARITY REG TABLE POINTER.
8669	017672	005733		1S: TST a(R3)+		;CHECK THE PARITY REG FOR AN ERROR FLAG.
8670	017674	100023		BPL 3\$;BN IF NO ERROR
8671	017676	02773	000001 177776	BIT #BIT0, a-2(R3)		;CHECK IF A TRAP SHOULD HAVE OCCURRED.
8672	017704	001410		BEQ 2\$;BR IF NO ACTION ENABLE. CHGG2
8673	017706	004767	000422	64\$: JSR PC,	SPRNTO	;SET UP VALUES FOR ERROR PRINTING.
(2)	017712	004767	001732	JSR PC,	\$ERROR	;*** ERROR *** (GO TYPE A MESSAGE)
(2)	017716	000026		WORD 26		;ERROR TYPE CODE.
8674	017720	000411		BR 3\$		
8675	017722	004767	000026	JSR PC,	PSCAN	;GO SCAN ALL MEMORY FOR PARITY ERRORS.
8676	017726			2\$: JSR PC,		
(1)	017726	004767	000402	SPRNTO		;SET UP VALUES FOR ERROR PRINTING.
(2)	017732	004767	001712	JSR PC,	\$ERROR	;*** ERROR *** (GO TYPE A MESSAGE)
(2)	017736	000027		WORD 27		;ERROR TYPE CODE.
8677	017740	004767	000010	JSR PC,	PSCAN	;GO SCAN ALL MEMORY FOR PARITY ERRORS.
8678	017744	005713		3\$: TST (R3)		;CHECK FOR TABLE TERMINATOR.
8679	017746	001351		BNE 1\$;BR IF MORE.
8680	017750	012603		MOV (SP)+,R3		;POP STACK INTO R3
8681	017752	000207		4\$: RTS	PC	;RETURN.
8682						
8683						;*****
8684						;* THIS SUBROUTINE WILL SCAN ALL OF MEMORY LOOKING FOR BAD PARITY
8685						;* TYPE OUT ALL LOCATIONS FOUND TO BE BAD, AND WRITE BACK INTO THE
8686						;* LOCATIONS IN ORDER TO RESTORE GOOD PARITY.
8687						;*****
8688						
8689	017754			PSCAN:		
(2)	017754	010046		MOV R0,-(SP)		;PUSH R0 ON STACK
(2)	017756	010146		MOV R1,-(SP)		;PUSH R1 ON STACK
(2)	017760	010246		MOV R2,-(SP)		;PUSH R2 ON STACK
(2)	017762	010346		MOV R3,-(SP)		;PUSH R3 ON STACK
(2)	017764	010446		MOV R4,-(SP)		;PUSH R4 ON STACK
(2)	017766	013766	000114	MOV a#114,-(SP)		;PUSH a#114 ON STACK
(2)	017772	013746	000116	MOV a#116,-(SP)		;PUSH a#116 ON STACK
8690	017776	004567	003520	JSR R5, SPRINT		;GO PRINT OUT THE FOLLOWING MESSAGE.
(2)	020002	026646		WORD SCANM		;ADDRESS OF MESSAGE TO BE TYPED
(1)	020004	012700	000001	MOV #BIT0, R0		;SCANNING MEMORY FOR BAD PARITY."
8691	020010	005001		CLR R1		;SET BIT POINTER TO FIRST BANK.
8692						;CLR HI 64K POINTER.

C 8
 8693 020012 005002 CLR R2 ;INIT ADDRESS POINTER.
 8694 020014 005004 CLR R4 ;INIT ERROR DETECTED FLAG.
 8695 020016 004767 000256 JSR PC, CLRPAR ;CLEAR THE PARITY REGISTERS.
 8696 020022 012737 000116 000114 MOV #116, @#114 ;HALT IF ANOTHER PARITY TRAP.
 8697 020030 005037 000116 CLR @#116 ;
 8698 020034 005767 160546 TST MMAVA ;CHECK FOR MEMORY MANAGEMENT.
 8699 020040 001406 BEQ 1\$;BR IF NO MEM MGMT.
 8700 020042 013746 172344 MOV @#KIPAR2,-(SP) ;PUSH @#KIPAR2 ON STACK
 8701 020046 005037 172344 CLR @#KIPAR2 ;INIT MEM MGMT TO POINT TO BANK 0.
 8702 020052 012702 040000 MOV #40000, R2 ;SET ADR POINTER TO PAR2.
 8703 020056 030067 161442 1\$: BIT R0, MEMMAP ;CHECK IF THIS BANK OF MEM EXISTS.
 8704 020062 001003 BNE 2\$;BR IF THIS BANK EXISTS.
 8705 020064 030167 161436 BIT R1, MEMMAP+2 ;CHECK HI 64K MAP.
 8706 020070 001442 BEQ 10\$;BR IF THIS BANK DOESN'T EXIST.
 8707 020072 010146 2\$: MOV R1,-(SP) ;PUSH R1 ON STACK
 8708 020074 111201 3\$: MOVB (R2), R1 ;READ THE LOCATION TO SEE IF IT HAS A PARITY ERROR.
 8709 020076 016703 161526 MOV .MPRX, R3 ;SET UP POINTER TO PARITY REGISTERS.
 8710 020102 005733 4\$: TST @#(R3)+ ;CHECK FOR THE ERROR FLAG.
 8711 020104 100024 BPL 6\$;BR IF NO ERROR FLAG.
 8712 020106 005704 TST R4 ;CHECK IF FIRST ERROR, THIS SCAN.
 8713 020110 001003 BNE 5\$;BR IF MORE THAN ONE ERROR FOUND.
 8714 020112 005367 160774 DEC \$ERTTL ;ADJUST ERROR COUNT.
 8715 020116 005204 INC R4 ;SET FLAG TO INDICATE ERROR FOUND.
 8716 020120 004767 000210 5\$: JSR PC, SPRNTQ ;SET UP VALUES FOR ERROR PRINTING.
 (1) 020120 004767 001520 64\$: JSR PC, \$ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
 (2) 020130 000030 .WORD 30 ;ERROR TYPE CODE.
 8717 020132 111212 MOVB (R2), (R2) ;REWRITE THE LOCATION TO CLEAR BAD PARITY.
 8718 020134 005053 CLR @-(R3) ;CLEAR THE ERROR FLAG.
 8719 020136 105712 TSTB (R2) ;CHECK IF THE PARITY ERROR WAS CLEARED.
 8720 020140 005733 TST @#(R3)+ ;CHECK FOR THE ERROR FLAG.
 8721 020142 100005 BPL 6\$;BR IF IT IS OK.
 8722 020144 004567 003352 JSR R5, \$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
 (2) 020150 026710 .WORD PEWNC ;ADDRESS OF MESSAGE TO BE TYPED.
 (1) ;'PARITY ERROR WILL NOT CLEAR.'
 8723 020152 005073 177776 CLR @-2(R3) ;CLEAR OUT THE PARITY ERROR FLAG.
 8724 020156 005713 TST (R3) ;CHECK FOR THE END OF REG ADR TABLE.
 8725 020160 001350 BNE 4\$;BR IF MORE PARITY REGISTERS.
 8726 020162 005202 INC R2 ;GO TO NEXT MEMORY ADDRESS.
 8727 020164 032702 017777 BIT #MASK4K,R2 ;CHECK FOR END OF 4K BANK.
 8728 020170 001341 BNE 3\$;BR IF MORE MEMORY THIS BANK.
 8729 020172 012601 MOV (SP)+,R1 ;POP STACK INTO R1
 8730 020174 000402 BR 11\$;BR TO CHECK FOR NEXT BANK.
 8731 020176 062702 020000 10\$: ADD #20000, R2 ;SKIP BANKS THAT AREN'T THERE.
 8732 020202 005767 160400 11\$: TST MMAVA ;CHECK FOR MEM MGMT.
 8733 020206 001413 BEQ 12\$;BR IF NO MEM MGMT.
 8734 020210 062737 000200 172344 ADD #200, @#KIPAR2 ;UPDATE MEM MGMT REG TO NEXT 4K.
 8735 020216 012702 040000 MOV #40000, R2 ;RESET ADDRESS POINTER TO BEGINNING OF BANK.
 8736 020222 006300 ASL R0 ;UPDATE BANK POINTER.
 8737 020224 006101 ROL R1 ;...HI 64K.
 8738 020226 100313 BPL 1\$;BR IF MORE BANKS.
 8739 020230 012637 172344 MOV (SP)+, @#KIPAR2 ;POP STACK INTO @#KIPAR2
 8740 020234 000402 BR 20\$;GO CHECK IF ANY ERRORS FOUND.
 8741 020236 106300 ASLB R0 ;UPDATE POINTER TO NEXT BANK.
 8742 020240 100306 BPL 1\$;BR IF MORE BANKS.

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER
CZOMCG.P11 12-MAR-80 13:07

D 8
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-77
PARITY MEMORY TRAP SERVICE AND SUBROUTINES.

SEQ 0094

8743 020242 005704 20\$: TST R4 ;CHECK IF ANY PARITY ERRORS DETECTED.
8744 020244 001003 BNE 21\$;BR IF ERRORS DETECTED.
8745 020246 004567 003250 JSR R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 020252 025716 .WORD NOPE\$;ADDRESS OF MESSAGE TO BE TYPED
8746 020254 012637 000116 21\$: MOV (SP)+, #116 ;POP STACK INTO #116
(2) 020260 012637 000114 MOV (SP)+, #114 ;POP STACK INTO #114
(2) 020264 012604 MOV (SP)+, R4 ;POP STACK INTO R4
(2) 020266 012603 MOV (SP)+, R3 ;POP STACK INTO R3
(2) 020270 012602 MOV (SP)+, R2 ;POP STACK INTO R2
(2) 020272 012601 MOV (SP)+, R1 ;POP STACK INTO R1
(2) 020274 012600 MOV (SP)+, R0 ;POP STACK INTO R0
8747 020276 000207 RTS PC ;RETURN.
8748
8749 :*****
8750 :ROUTINE TO CLEAR ALL PARITY REGISTERS PRESENT
8751 :*****
8752 020300 010346 161322 CLRPAR:
(2) 020300 010346 MOV R3, -(SP) ;PUSH R3 ON STACK
8753 020302 016703 161322 MOV .MPRX, R3 ;GET PARITY REGISTER TABLE POINTER.
8754 020306 005713 161322 1\$: TST (R3) ;CHECK FOR THE TABLE TERMINATOR.
8755 020310 001402 BEQ 2\$;BR IF DONE ALL PARITY REGISTERS.
8756 020312 005033 CLR @R3)+ ;CLEAR THE PARITY REGISTER.
8757 020314 000774 BR 1\$;BR FOR MORE
8758 020316 012603 2\$: MOV (SP)+, R3 ;POP STACK INTO R3
8759 020320 000207 RTS PC ;RETURN.
8760
8761 .SBTTL SUBROUTINES TO SET UP DATA FOR ERROR PRINTOUT ROUTINE.
8762 :*****
8763 :* THESE ROUTINES ARE USED TO TRANSFER DATA TO COMMON TAG AREA (.SCMTAG)
8764 :* FOR ERROR PRINTOUT BY .SERROR & .SERRTYP ROUTINES FROM **SYSMAC**.
8765 :*****
8766 020322 010267 160572 SPRNT: MOV R2, \$GDADR ;SAVE THE ADDRESS UNDER TEST.
8767 020326 005067 160572 CLR \$GDDAT ;SHOULD BE DATA IS '0'.
8768 020332 000430 BR SPRNTB
8769
8770 020334 014367 160620 SPRNTO: MOV -(R3), \$TMPO ;GET THE PARITY REGISTER ADDRESS.
8771 020340 013367 160616 MOV @R3)+, \$TMPI ;GET THE CONTENTS OF THE PARITY REG.
8772 020344 000402 BR SPRNTO
8773
8774 020346 011367 160606 SPRNTP: MOV (R3), \$TMPO ;GET THE PARITY REGISTER ADDRESS.
8775 020352 010267 160542 SPRNTO: MOV R2, \$GDADR ;GET THE MEMORY ADDRESS BEING TESTED
8776 020356 000414 BR SPRNTA ;BR TO COMMON SECTION.
8777
8778 020360 010267 160534 SPRNT1: MOV R2, \$GDADR ;GET THE MEMORY ADDRESS BEING TESTED
8779 020364 005367 160530 DEC \$GDADR ;ADJUST IT FOR PRINTOUT.
8780 020370 000407 BR SPRNTA ;BR TO COMMON SECTION.
8781
8782 020372 010367 160562 SPRNT3: MOV R3, \$TMPO ;GET THE DATA IN R3.
8783 020376 010267 160516 SPRNT2: MOV R2, \$GDADR ;GET THE MEMORY ADDRESS BEING TESTED
8784 020402 162767 000002 160510 SUB #2, \$GDADR ;ADJUST IT FOR PRINTOUT.
8785 020410 010067 160510 SPRNTA: MOV R0, \$GDDAT ;GET WHAT THE DATA SHOULD BE
8786 020414 010167 160506 SPRNTB: MOV R1, \$BDDBAT ;GET WHAT THE DATA WAS
8787 020420 000207 RTS PC ;RETURN TO ENTER ERROR ROUTINES
8788

```

8789
8790
8791
8792
8793 020422 005710
8794 020424 001007
8795 020426 005760 000002
8796 020432 001004
8797 020434 004567 003062
(2) 020440 026276
(1)
8798 020442 000475
8799 020444 010146
(2) 020446 010246
(2) 020450 010346
(2) 020452 010446
8800 020454 012701 000001
8801 020460 005002
8802 020462 012703 177777
8803 020466 010304
8804 020470 030110
8805 020472 001014
8806 020474 030260 000002
8807 020500 001011
8808 020502 105703
8809 020504 001042
8810 020506 162703 000001
8811 020512 005604
8812
8813 020514 004567 003002
(1) 020520 025527
8814 020522 000410
8815 020524 105703
8816 020526 001431
8817
8818 020530 062703 000001
8819 020534 005504
8820 020536 004567 002760
(1) 020542 025517
8821 020544
(2) 020544 010346
(2) 020546 010446
8822 020550 006303
8823 020552 006104
8824 020554 006003
8825 020556 010446
(1)
(3)
(3)
(3) 020560 013746 177776
(3) 020564 004767 004104
(1) 020570 003
(1) 020571 000
8826 020572 010346
(1)

***** SUBROUTINE TO TYPE OUT A MAP OF 4K BANK.
** RO POINTS TO THE MAP UPON ENTERING THIS ROUTINE.

TYPMAP: TST (RO) ;CHECK IF ANY MEMORY IN MAP...LO 64K.
         BNE 1$ ;BR IF MEMORY IN MAP.
         TST 2(R0) ;..HI 64K.
         BNE 1$ ;BR IF MEMORY IN MAP.
         JSR R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
         .WORD NOMEM ;ADDRESS OF MESSAGE, TO BE TYPED
                  ;'NO MEMORY FOUND.''
         BR 6$ ;EXIT

1$: MOV R1,-(SP) ;PUSH R1 ON STACK
     MOV R2,-(SP) ;PUSH R2 ON STACK
     MOV R3,-(SP) ;PUSH R3 ON STACK
     MOV R4,-(SP) ;PUSH R4 ON STACK
     MOV #BIT0, R1 ;SET UP BANK POINTER...LO 64K.
     CLR R2 ;..HI 64K.

2$: MOV #-1, R3 ;SET UP ADDRESS POINTER TO -1.
     MOV R3, R4 ;HI BITS OF ADDRESS AS WILL.
     BIT R1, (RO) ;CHECK THE MAP FOR THIS BANK.
     BNE 3$ ;BR IF THIS BANK PRESENT.
     BIT R2, 2(RO) ;CHECK HI 64K MAP.
     BNE 3$ ;BR IF THIS BANK PRESENT.
     TSTB R3 ;CHECK FOR PREVIOUS PRINTOUT.
     BNE 5$ ;BR IF ALREADY TYPED 'TO'.
     SUB #1, R3 ;BACK UP TO LAST ADR OF PREVIOUS BANK.
     SBC R4 ;...HI ADDRESS BITS.

3$: JSR R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
     .WORD TO ;ADDRESS OF MESSAGE TO BE TYPED
     BR 4$ ;GO TO TYPE THE ADDRESS.
     TSTB R3 ;CHECK FOR PREVIOUS TYPEOUT.
     BEQ 5$ ;BR IF ALREADY TYPE 'FROM'.

4$: ADD #1, R3 ;POINT TO FIRST ADDRESS OF THIS BANK.
     ADC R4 ;..HI BITS OF ADDRESS.
     JSR R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
     .WORD FROM ;ADDRESS OF MESSAGE TO BE TYPED

MOV R3,-(SP) ;PUSH R3 ON STACK
MOV R4,-(SP) ;PUSH R4 ON STACK
ASL R3 ;BIT 15 INTO C-BIT
ROL R4 ;BIT 15 INTO R4.
ROR R3 ;RESTORE BITS 14-0.
MOV R4,-(SP) ;SAVE R4 FOR TYPEOUT
                  ;TYPE ADDRESS BITS 21-15

***** THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOS ROUTINE
** WIHTOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
MOV #PSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
JSR PC, $TYPOS ;GO TO THE SUBROUTINE
.BYTE 3 ;TYPE 3 DIGIT(S)
.BYTE 0 ;SUPPRESS LEADING ZEROS
MOV R3,-(SP) ;SAVE R3 FOR TYPEOUT
                  ;TYPE ADDRESS BITS 14-0

```

ZQMC60 0-124K MEMORY EXERCISER, 16K VER
ZQMC.G.P11 12-MAR-80 13:07

F 8
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-79
SUBROUTINES TO SET UP DATA FOR ERROR PRINTOUT ROUTINE.

SEQ 0096

(3) :* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE \$TYPoS ROUTINE
(3) :* WIHTOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
(3) 020574 013746 177776 MOV @MPsw, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
(3) 020600 004767 004070 JSR PC, \$TYPoS ;GO TO THE SUBROUTINE
(1) 020604 005 .BYTE 5 ;TYPE 5 DIGIT(S)
(1) 020605 001 .BYTE 1 ;TYPE LEADING ZEROS
8827 020606 012604 MOV (SP)+, R4 ;POP STACK INTO R4
(2) 020610 012603 MOV (SP)+, R3 ;POP STACK INTO R3
8828 C20612 062703 020000 5\$: ADD #20000, R3 ;UPDATE TO NEXT BANK.
8829 020616 005504 ADC R4 ;HI ADDRESS BITS.
8830 020620 006301 ASL R1 ;SHIFT POINTER...LO 64K.
8831 020622 006102 ROL R2 ;.HI 64K.
8832 020624 103321 BCC 2\$;BR IF MORE BANKS.
8833 020626 012604 MOV (SP)+, R4 ;POP STACK INTO R4
(2) 020630 012603 MOV (SP)+, R3 ;POP STACK INTO R3
(2) 020632 012602 MOV (SP)+, R2 ;POP STACK INTO R2
(2) 020634 012601 MOV (SP)+, R1 ;POP STACK INTO R1
8834 020636 000207 RTS PC ;RETURN.
8835
8919 .SBTTL SCOPE HANDLER ROUTINE
(1)
(2)

(1) :* THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
(1) :* AND LOAD THE TEST NUMBER (\$STSTNM) INTO THE DISPLAY REG. (DISPLAY<7:0>)
(1) :* AND LOAD THE ERROR FLAG (\$ERFLG) INTO DISPLAY<15:08>
(1) :* THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
(1) :* SW14=1 LOOP ON TEST
(1) :* SW11=1 INHIBIT ITERATIONS
(1) :* SW09=1 LOOP ON ERROR
(1) :* SW08=1 LOOP ON TEST IN SWR<4:0>
(1) :* CALL
(1) :* SCOPE ;;SCOPE=IOT
(1)
(1) 020640
SSCOPE:
(3) :* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE \$CKSWR ROUTINE
(3) :* WIHTOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
(3) 020640 013746 177776 MOV @MPsw, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
(3) 020644 004767 001524 JSR PC, \$CKSWR ;GO TO THE SUBROUTINE
(3) 020650 012504 MOV (R5)+, R4 ;SAVE MINIMUM BLOCK MASK NEXT TEST.
(3) 020652 010516 MOV R5, (SP) ;PUT RETURN PC ONTO STACK, SIMULATE JSR PC.
(1) 020654 032777 040000 160256 1\$: BIT #BIT14,@SWR ;LOOP ON PRESENT TEST?
(1) 020662 001117 BNE \$OVER ;YES IF SW14=1
(1) :*****START OF CODE FOR THE XOR TESTER*****
(1) 020664 000416 \$XTSTR: BR 6\$;IF RUNNING ON THE 'XOR' TESTER CHANGE
(1) :THIS INSTRUCTION TO A 'NOP' (NOP 240)
(1) 020666 013746 000004 MOV @ERRVEC,-(SP) ;SAVE THE CONTENTS OF THE ERROR VECTOR
(1) 020672 012737 020712 000004 MOV #5\$, @ERRVEC ;SET FOR TIMEOUT
(1) 020700 005737 177060 TST #177060 ;TIME OUT ON XOR?
(1) 020704 012637 000004 MOV (SP)+, @ERRVEC ;RESTORE THE ERROR VECTOR
(1) 020710 000466 BR \$SVLAD ;GO TO THE NEXT TEST
(1) 020712 022626 5\$: CMP (SP)+, (SP)+ ;CLEAR THE STACK AFTER A TIME OUT
(1) 020714 012637 000004 MOV (SP)+, @ERRVEC ;RESTORE THE ERROR VECTOR
(1) 020720 000426 BR 7\$;LOOP ON THE PRESENT TEST
(1) 020722 032777 000400 160210 6\$: ;*****END OF CODE FOR THE XOR TESTER*****
(1) 020722 032777 000400 160210 BIT #BIT08,@SWR ;LOOP ON SPEC. TEST?
(1) 020730 001407 BEQ 2\$;BR IF NO

CZOMLG0 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) G 8
 CZOMCG.P11 12-MAR-80 13:07 SCOPE HANDLER ROUTINE 12-MAR-80 13:10 PAGE 59-80

SEQ 0097

(1) 020732 017746 160202	MOV @SWR,-(SP)	;SET DESIRED TEST NUM. FROM SWR
(1) 020736 042716 000340	BIC #SSWRMK,(SP)	;STRIP AWAY UNDESIRED BITS
(1) 020742 122667 160134	CMPB (SP)+,\$STSTNM	;ON THE RIGHT TEST?
(1) 020746 001465	BEQ \$OVER	;BR IF YES
(1) 020750 105767 160127	2\$: TSTB SERFLG	;HAS AN ERROR OCCURRED?
(1) 020754 001421	BEQ 3\$;BR IF NO
(1) 020756 126767 160133 160117	CMPB SERMAX,SERFLG	;MAX. ERRORS FOR THIS TEST OCCURRED?
(1) 020764 101015	BHI 3\$;BR IF NO
(1) 020766 032777 001000 160144	BIT #BIT09,@SWR	;LOOP ON ERROR?
(1) 020774 001404	BEQ 4\$;BR IF NO
(1) 020776 016767 160106 160102	7\$: MOV \$LPERR,\$LPADR	;SET LOOP ADDRESS TO LAST SCOPE
(1) 021004 000446	BR \$OVER	
(1) 021006 105067 160071	4\$: CLR B SERFLG	;ZERO THE ERROR FLAG
(1) 021012 005067 160152	CLR STIMES	;CLEAR THE NUMBER OF ITERATIONS TO MAKE
(1) 021016 000415	BR 1\$;ESCAPE TO THE NEXT TEST
(1) 021020 032777 004000 160112	3\$: BIT #BIT11,@SWR	;INHIBIT ITERATIONS?
(1) 021026 001011	BNE 1\$;BR IF YES
(1) 021030 005767 160156	TST SPASS	;IF FIRST PASS OF PROGRAM
(1) 021034 001406	BEQ 1\$;INHIBIT ITERATIONS
(1) 021036 005267 160042	INC SICNT	;INCREMENT ITERATION COUNT
(1) 021042 026767 160122 160034	CMP STIMES,\$ICNT	;CHECK THE NUMBER OF ITERATIONS MADE
(1) 021050 002024	BGE \$OVER	;BR IF MORE ITERATION REQUIRED
(1) 021052 012767 000001 160024	1\$: MOV #1,\$ICNT	;REINITIALIZE THE ITERATION COUNTER
(1) 021060 016767 000552 160102	MOV SMX(CNT,STIMES	;SET NUMBER OF ITERATIONS TO DO
(1) 021066 105267 160010	SSVLAD: INC B STSTNM	;COUNT TEST NUMBERS
(1) 021072 116767 160004 160110	MOV B STSTNM,\$TESTN	;SET TEST NUMBER IN APT MAILBOX
(1) 021100 011667 160002	MOV (SP),\$LPADR	;SAVE SCOPE LOOP ADDRESS
(1) 021104 011667 160000	MOV (SP),\$LPERR	;SAVE ERROR LOOP ADDRESS
(1) 021110 005067 160056	CLR SESCAPE	;CLEAR THE ESCAPE FROM ERROR ADDRESS
(1) 021114 112767 000001 157773	MOV B #1, SERMAX	;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
(1) 021122 016777 157754 160012	\$OVER: MOV STSTNM, #DISPLAY	;DISPLAY TEST NUMBER
(1) 021130 016716 157752	MOV \$LPADR,(SP)	;FUDGE RETURN ADDRESS
(3) 021134 020516	INSERT: CMP R5, (SP)	;CHECK FOR LOOP ON TEST.
(3) 021136 001402	BEQ 1\$;BR IF START NEXT TEST.
(3) 021140 000167 000470	JMP ENDINS	;JMP IF LOOP ON LAST TEST.
(3) 021144 012767 037777 160434	1\$: MOV #37777, BLKMSK	;SET 8K BOUNDARY MASK.
(3) 021152 005767 160034	TST SPASS	;CHECK FOR PASS 0.
(3) 021156 001404	BEQ 2\$;BR IF PASS 0
(3) 021160 126727 157716 000021	CMPB STSTNM, #21	;CHECK IF IN SECTION 3.
(3) 021166 103002	BHIS 3\$;BR IF IN SECTION 3.
(3) 021170 006267 160412	2\$: ASR BLKMSK	;RESET BOUNDARY TO 4K.
(3) 021174 016767 160362 160362	3\$: MOV FSTADR, TMPFAD	;GET FIRST ADDRESS.
(3) 021202 005767 157372	TST RELOCF	;CHECK IF PRG RELOCATED.
(3) 021206 001430	BEQ 4\$;BR IF NOT RELOCATED.
(3) 021210 032777 000040 157722	BIT #SW05, @SWR	;CHECK IF LOC 0-776 TO BE PROTECTED.
(3) 021216 001424	BEQ 4\$;BR IF SW NOT SET.
(3) 021220 026727 160340 001000	CMP TMPFAD, #1000	;CHECK IF NOT BEING TESTED.
(3) 021226 103020	BHIS 4\$;BR IF ALREADY PROTECTED.
(3) 021230 012767 001000 160326	MOV #1000, TMPFAD	;RESET FIRST ADDRESS.
(3) 021236 052767 000001 160324	BIS #BIT0, FADMAP	;SET FLAG IN FIRST BANK.
(3) 021244 026727 160324 001000	CMP LSTADR, #1000	;CHECK IF GONE PAST LAST ADR.
(3) 021252 101006	BHI 4\$;BR IF ENOUGH MEMORY.
(5) 021254 004567 002242	JSR R5, \$PRINT	;GO PRINT OUT THE FOLLOWING MESSAGE.
(5) 021260 026747	.WORD NOMTST	;ADDRESS OF MESSAGE TO BE TYPED
(4) 021262 016716 160356	MOV .TST32, (SP)	;'NO MEMORY TESTED'.
		;ADJUST RETURN ADR FOR ABORT.

```

(3) 021266 000207      RTS   PC      :ABORT.
(3) 021270 016767 160300 160300 4$:  MOV   LSTADR, TMPLAD :GET LAST ADDRESS.
(3) 021276 016767 160232 160224  MOV   SAVTST, TSTMAP :GET TEST MAP, LO 64K.
(3) 021304 016767 160226 160220  MOV   SAVTST+2, TSTMAP+2 :.. HI 64K.
(3) 021312 046767 157264 160210  BIC   PRGMAP, TSTMAP :DON'T TEST OVER THE PROGRAM.
(3) 021320 046767 157260 160204  BIC   PRGMAP+2, TSTMAP+2
(3) 021326 005767 157660          TST   $PASS      :CHECK FOR FIRST PASS
(3) 021332 001011          BNE   10$      :BR IF NOT FIRST PASS.
(3) 021334 032767 000003 160166  BIT   #3, TSTMAP :CHECK IF FIRST TWO BANKS AVAILABLE.
(3) 021342 001405          BEQ   10$      :NOT TESTING FIRST 2 BANKS.
(3) 021344 042767 177774 160156  BIC   #177774, TSTMAP :CLR ALL BUT FIRST 2 BANKS.
(3) 021352 005067 160154          CLR   TSTMAP+2
(3) 021356 005704          10$:  TST   R4       :CHECK FOR A MINIMUM BLOCK SIZE.
(3) 021360 001503          BEQ   20$      :BR IF NO MIN BLOCK SIZE.
(3) 021362 030467 160176          BIT   R4, TMPFAD :CHECK IF FIRST ADR ON BLOCK BOUNDARY.
(3) 021366 001416          BEQ   11$      :BR IF FIRST ADR ON BLOCK BOUNDARY.
(3) 021370 050467 160170          BIS   R4, TMPFAD :ADJUST FIRST ADR TO END OF BLOCK.
(3) 021374 005267 160164          INC   TMPFAD   :FIRST ADR TO FIRST ADR OF NEXT BLOCK.
(3) 021400 032767 017777 160156  BIT   #MASK4K, TMPFAD :CHECK IF FIRST ADR REACHED 4K BOUNDARY.
(3) 021406 001006          BNE   11$      :BR IF NOT ON 4K BOUNDARY.
(3) 021410 046767 160154 160112  BIC   FADMAP, TSTMAP :DON'T TEST FIRST BANK.
(3) 021416 046767 160150 160106  BIC   FADMAP+2, TSTMAP+2
(3) 021424 030467 160146          11$:  BIT   R4, TMPLAD :CHECK IF LAST ADR ON BLOCK BOUNDARY.
(3) 021430 001414          BEQ   12$      :BR IF ON BLOCK BOUNDARY.
(3) 021432 040467 160140          BIC   R4, TMPLAD :ADJUST LAST ADR DOWN TO NEXT BLOCK BOUNDARY.
(3) 021436 032767 017777 160132  BIT   #MASK4K, TMPLAD :CHECK IF ADJUSTED TO 4K BOUNDARY.
(3) 021444 001006          BNE   12$      :BR IF NOT ON 4K BOUNDARY.
(3) 021446 046767 160130 160054  BIC   LADMAP, TSTMAP :SKIP TESTING LAST BANK.
(3) 021454 046767 160124 160050  BIC   LADMAP+2, TSTMAP+2
(3) 021462 036767 160102 160112 12$:  BIT   FADMAP, LADMAP :CHECK IF FIRST AND LAST IN SAME BANK.
(3) 021470 001004          BNE   13$      :BR IF IN SAME BANK.
(3) 021472 036767 160074 160104  BIT   FADMAP+2, LADMAP+2 :... UPPER 64K.
(3) 021500 001404          BEQ   14$      :BR IF FIRST AND LAST NOT SAME BANK.
(3) 021502 026767 160070 160054 13$:  CMP   TMPLAD, TMPFAD :CHECK IF ANY MEMORY LEFT.
(3) 021510 101406          BLO$   15$      :BR IF NO MEMORY TO TEST.
(3) 021512 005767 160012          TST   TSTMAP   :CHECK IF ANY BANKS LEFT TO TEST!!
(3) 021516 001017          BNE   16$      :BR IF TEST MAP NOT EMPTY.
(3) 021520 005767 160006          TST   TSTMAP+2 :CHECK FOR ANY BANKS.
(3) 021524 001014          BNE   16$      :BR IF TEST MAP NOT EMPTY.
(3) 021526          15$:  JSR   R5, SPRINT :GO PRINT OUT THE FOLLOWING MESSAGE.
(5) 021526 004567 001770          .WORD SKPMES :ADDRESS OF MESSAGE TO BE TYPED
(5) 021532 026773          :     :SKIPPING TEST #
(4) 021534 005046          CLR   -(SP)   :CLEAR THE WORD ON THE STACK.
(4) 021536 116716 157340          MOVB  STSTMN, (SP) :PUT THE DATA ON THE STACK.
(6)          :*: THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE STYPOS ROUTINE
(6)          :*: WITHOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
(6) 021542 013746 177776          MOV   @MPSW, -(SP) :PUT THE PROCESSOR STATUS ON THE STACK
(6) 021546 004767 003122          JSR   PC, STYPOS :GO TO THE SUBROUTINE
(4) 021552 003           .BYTE 3   :TYPE 3 DIGITS.
(4) 021553 001           .BYTE 1   :TYPE LEADING ZEROS.
(3) 021554 000427          BR    ENDINS :RETURN TO SKIP TEST.
(3) 021556 062716 000004          ADD   #4, (SP)   :SKIP THE SKIP ON RETURN.
(3) 021562 062767 000004 157316  ADD   #4, $LPADR :ADJUST THE LOOP ADR PAST THE SKIP.
(3) 021570 012767 017777 157770 20$:  MOV   #MASK4K, FADMSK :GET 4K MASK.
(3) 021576 016705 157762          MOV   TMPFAD, R5  :GET FIRST ADR.

```

CZOMCG0 0-124K MEMORY EXERCISER, 16K VER 18
 CZOMCG.P11 12-MAR-80 13:07 SCOPE MACY11 30A(1052) 12-MAR-80 13 10 PAGE 59-82

(3)	021602	040567	157760	21\$: BIC R5, FADMSK ;CLR MASK ABOVE LOWEST BIT OF FIRST ADR.
(3)	021606	006305		ASL R5 ;MOVE LOWEST BIT UP ONE.
(3)	021610	001374		BNE 21\$;LOOP UNTIL OVERFLOW.
(3)	021612	012767	017777 157760	MOV #MASK4K,LADMSK ;SET MASK BITS
(3)	021620	016705	157752	MOV TMPLAD, R5 ;GET LAST ADR.
(3)	021624	040567	157750	22\$: BIC R5, LADMSK ;CLR ALL MASK BITS ABOVE LOWEST BIT IN LAST ADR.
(3)	021630	006305		ASL R5 ;MOVE LOWEST BIT OF LAST ADR UP ONE.
(3)	021632	001374		BNE 22\$;LOOP UNTIL OVERFLOW.
(3)	021634	000207		ENDINS: RTS PC ;EXIT SCOPE ROUTINE BACK TO TEST.
(1)	021636	000004		\$MXCNT: 6 ;MAX. NUMBER OF ITERATIONS
8920				* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE \$CKSWR ROUTINE
(2)	021640	013746	177776	* WIHTOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
(2)	021644	004767	000524	MOV #PSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
				JSR PC, \$CKSWR ;GO TO THE SUBROUTINE
8921				.SBTTL ERROR HANDLER ROUTINE
(1)				*****
(2)				* THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
(1)				* SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
(1)				* AND GO TO \$ERRTYP ON ERROR
(1)				* THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
(1)				* SW15=1 HALT ON ERROR
(1)				* SW13=1 INHIBIT ERROR TYPEOUTS
(1)				* SW10=1 BELL ON ERROR
(1)				* SW09=1 LOOP ON ERROR
(1)				* CALL
(1)				* ERROR N ;ERROR=EMT AND N ERROR ITEM NUMBER
(1)	021650			SERROR:
(3)				* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE \$CKSWR ROUTINE
(3)				* WIHTOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
(3)	021650	013746	177776	MOV #PSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
(3)	021654	004767	000514	JSR PC, \$CKSWR ;GO TO THE SUBROUTINE
(2)	021660	062716	000002	ADD #2, (SP) ;ADJUST POINTER PAST CODE WORD.
(1)	021664	105267	157213	7\$: INC8 SERFLG ;SET THE ERROR FLAG
(1)	021670	001775		BEO 7\$;DON'T LET THE FLAG GO TO ZERO
(1)	021672	016777	157204 157242	MOV STSTNM,ADISPLAY ;DISPLAY TEST NUMBER AND ERROR FLAG
(1)	021700	032777	002000 157232	BIT #BIT10,ASWR ;BELL ON ERROR?
(1)	021706	001403		BEO 1\$;NO - SKIP
(2)	021710	004567	001606	JSR R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
(2)	021714	001174		WORD SBELL ;ADDRESS OF MESSAGE TO BE TYPED
(1)	021716	005267	157170	1\$: INC SERTTL ;COUNT THE NUMBER OF ERRORS
(1)	021722	011667	157170	MOV (SP),\$ERRPC ;GET ADDRESS OF ERROR INSTRUCTION
(1)	021726	162767	000002 157162	SUB #2,\$ERRPC
(1)	021734	117767	157156 157152	MOVB #ERRPC,SITEMB ;STRIP AND SAVE THE ERROR ITEM CODE
(1)	021742	032777	020000 157170	BIT #BIT13,ASWR ;SKIP TYPEOUT IF SET
(1)	021750	001005		BNE 20\$;SKIP TYPEOUTS
(1)	021752	004767	000116	JSR PC,\$ERRTYP ;GO TO USER ERROR ROUTINE
(2)	021756	004567	001540	JSR R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
(2)	021762	001201		WORD SCRLF ;ADDRESS OF MESSAGE TO BE TYPED
(1)	021764	122767	000001 157232	20\$: CMPB #APTENV,SENV ;RUNNING IN APT MODE
(1)	021772	001007		BNE 2\$;NO, SKIP APT ERROR REPORT
(1)	021774	116767	157114 000004	MOVB SITEMB,21\$;SET ITEM NUMBER AS ERROR NUMBER
(1)	022002	004767	002044	JSR PC,SATY4 ;REPORT FATAL ERROR TO APT
(1)	022006	000		BYTE 0

SEQ 0099

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER
CZOMCG.P11 12-MAR-80 13:07

J 8
MACY11 30A(1052) ERROR HANDLER ROUTINE

12-MAR-80 13:10 PAGE 59-83

SEQ 0100

(1) 022007 000 .BYTE 0
(1) 022010 000777 22\$: BR 22\$;;APT ERROR LOOP
(1) 022012 005777 157122 2\$: TST @SWR ;;HALT ON ERROR
(1) 022016 100005 BPL 3\$;;SKIP IF CONTINUE
(1) 022020 000000 HALT ;;HALT ON ERROR!
(3) :* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE \$CKSWR ROUTINE
(3) :* WITHOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
(3) 022022 013746 177776 MOV @PSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
(3) 022026 004767 000342 JSR PC \$CKSWR ;GO TO THE SUBROUTINE
(1) 022032 032777 001000 157100 3\$: BIT #BIT09,@SWR ;LOOP ON ERROR SWITCH SET?
(1) 022040 001402 BEQ 4\$;;BR IF NO
(1) 022042 016716 157042 MOV \$LPERR,(SP) ;FUDGE RETURN FOR LOOPING
(1) 022046 005767 157120 TST \$ESCAPE ;CHECK FOR AN ESCAPE ADDRESS
(1) 022052 001402 BEQ 5\$;;BR IF NONE
(1) 022054 016716 157112 MOV \$ESCAPE,(SP) ;FUDGE RETURN ADDRESS FOR ESCAPE
(1) 022060 HALT ;;YES
(1) 022060 022737 014232 000042 5\$: CMP #SENDAD, #42 ;ACT-11 AUTO-ACCEPT?
(1) 022066 001001 BNE 6\$;;BRANCH IF NO
(1) 022070 000000 RTS PC ;;YES
(2) 022072 000207 ;*****
8922

(1)
(1)
.SBttl ERROR MESSAGE TYPEOUT ROUTINE

(1)
(1)
(1)
;*THIS ROUTINE USES THE "ITEM CONTROL BYTE" (\$ITEMB) TO DETERMINE WHICH
;*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE 'ERROR TABLE' (\$ERRTB),
;*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
(1)

(1) 022074 \$ERRTYP:
(2) 022074 004567 001422 JSR R5, \$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 022100 001201 .WORD \$CRLF ;ADDRESS OF MESSAGE TO BE TYPED
(1) 022102 010046 MOV RO,-(SP) ;SAVE RO
(1) 022104 005000 CLR RO ;PICKUP THE ITEM INDEX
(1) 022106 156700 157002 BISB \$ITEMB,RO
(1) 022112 001007 BNE 1\$;IF ITEM NUMBER IS ZERO, JUST
;TYPE THE PC OF THE ERROR
(2) 022114 016746 156776 MOV \$ERRPC,-(SP) ;SAVE \$ERRPC FOR TYPEOUT
(2) ;;ERROR ADDRESS
(4) :* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE STYPOC ROUTINE
(4) :* WITHOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
(4) 022120 013746 177776 MOV @PSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
(4) 022124 004767 002570 JSR PC \$STYPOC ;GO TO THE SUBROUTINE
(1) 022130 000513 BR 10\$;GET OUT
(1) 022132 016767 156760 157354 1\$: MOV \$ERRPC, \$VERPC ;SET UP VIRTUAL PC FOR TYPEOUT.
(1) 022140 166767 156434 157346 SUB RELOCF, \$VERPC ;MAKE VIRTUAL IF NOT ALREADY.
(1) 022146 005300 DEC RO ;ADJUST THE INDEX SO THAT IT WILL
(1) 022150 006300 ASL RO ;WORK FOR THE ERROR TABLE
(1) 022152 006300 ASL RO
(1) 022154 006300 ASL RO
(1) 022156 066700 157456 ADD .ERRTB, RO ;FORM TABLE POINTER
(1) 022162 012067 000006 MOV (RO)+,\$;PICKUP 'ERROR MESSAGE' POINTER
(1) 022166 001406 BEQ 3\$;SKIP TYPEOUT IF NO POINTER
(2) 022170 004567 001326 JSR R5, \$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.

```

(1) 022174 000000          2$: .WORD 0           ;'ERROR MESSAGE' POINTER GOES HERE
(2) 022176 004567 001320    JSR R5, SPRINT :GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 022202 001201          .WORD $CRLF :ADDRESS OF MESSAGE TO BE TYPED
(1) 022204 012067 000006    MOV (R0)+,4$ :PICKUP 'DATA HEADER' POINTER
(1) 022210 001406          BEQ 5$ :SKIP TYPEOUT IF 0
(2) 022212 004567 001304    JSR R5, SPRINT :GO PRINT OUT THE FOLLOWING MESSAGE.
(1) 022216 000000          .WORD 0           :'DATA HEADER' POINTER GOES HERE
(2) 022220 004567 001276    JSR R5, SPRINT :GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 022224 001201          .WORD $CRLF :ADDRESS OF MESSAGE TO BE TYPED
(1) 022226 010146          MOV R1,-(SP) :SAVE R1
(1) 022230 012001          MOV (R0)+,R1 :PICKUP 'DATA TABLE' POINTER
(1) 022232 001451          BEQ 9$ :BR IF NO DATA TO BE TYPED
(1) 022234 066701 156340    ADD RELOCF, R1 :ADJUST POINTER
(1) 022240 012000          MOV (R0)+,R0 :PICKUP 'DATA FORMAT' POINTER
(1) 022242 066700 156332    ADD RELOCF, R0 :ADJUST POINTER
(1) 022246 105720          TSTB (R0)+ :CHECK THE FORMAT
(1) 022250 001006          BNE 7$ :BR IF NOT 16-BIT OCTAL
(2) 022252 013146          MOV @R1)+,-(SP) ;SAVE @R1)+ FOR TYPEOUT
(4)                                     ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE STYPOC ROUTINE
(4)                                     ;* WIHTOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
(4) 022254 013746 177776    MOV @PSW, -(SP) :PUT THE PROCESSOR STATUS ON THE STACK
(4) 022260 004767 002434    JSR PC, STYPOC :GO TO THE SUBROUTINE
(1) 022264 000426          BR 8$ :.
(1) 022266 100406          BMI 17$ :BRANCH IF NOT DECIMAL
(2) 022270 013146          MOV @R1)+,-(SP) ;SAVE @R1)+ FOR TYPEOUT
(4)                                     ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE STYPODS ROUTINE
(4)                                     ;* WIHTOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
(4) 022272 013746 177776    MOV @PSW, -(SP) :PUT THE PROCESSOR STATUS ON THE STACK
(4) 022276 004767 002140    JSR PC, STYPODS :GO TO THE SUBROUTINE
(1) 022302 000417          BR 8$ :SKIP
(1) 022304 122760 177777 177777 17$: CMPB #1, -1(R0) :CHECK FOR 18-BIT ADDRESS FORMAT.
(1) 022312 001004          BNE 18$ :BR IF NOT 18-BIT ADDRESS FORMAT.
(2) 022314 013146          MOV @R1)+,-(SP) :PUT THE DATA ON THE STACK.
(2) 022316 004767 002640    JSR PC, STYPAD :DETERMINE THE PHYSICAL ADDRESS AND TYPE IT.
(1) 022322 000407          BR 8$ :SKIP
(1) 022324 005046          18$: CLR -(SP) :CLEAR THE WORD ON THE STACK.
(2) 022326 113116          MOVB @R1)+,-(SP) :PUT THE DATA ON THE STACK.
(4)                                     ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE STYPOS ROUTINE
(4)                                     ;* WIHTOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
(4) 022330 013746 177776    MOV @PSW, -(SP) :PUT THE PROCESSOR STATUS ON THE STACK
(4) 022334 004767 002334    JSR PC, STYPOS :GO TO THE SUBROUTINE
(2) 022340 003              .BYTE 3 :TYPE 3 DIGITS.
(2) 022341 001              .BYTE 1 :TYPE LEADING ZEROS.
(1) 022342 005711          8$: TST (R1) :IS THERE ANOTHER NUMBER?
(1) 022344 001404          BEQ 9$ :BR IF NO
(2) 022346 004567 001150    JSR R5, SPRINT :GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 022352 022372          .WORD 11$ :ADDRESS OF MESSAGE TO BE TYPED
(1) 022354 000734          BR 6$ :LOOP
(1)
(1) 022356 012601          9$: MOV (SP)+,R1 :RESTORE R1
(1) 022360 012600          MOV (SP)+,R0 :RESTORE R0
(2) 022362 004567 001134    JSR R5, SPRINT :GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 022366 001201          .WORD $CRLF :ADDRESS OF MESSAGE TO BE TYPED
(1) 022370 000207          RTS PC :RETURN
(1) 022372 000011          .ASCIZ / / :TAB CHARACTER.

```

```

(1) EVEN
8923 .SB TTL TTY INPUT ROUTINE
(1)
(2) *****
(1) .ENABL LSB
(1)
(2) *****
(1) *SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
(1) *ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
(1) *SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
(1) *WHEN OPERATING IN TTY FLAG MODE.
(1) 022374 022767 000176 156536 $CKSWR: CMP #SWREG,SWR ;:IS THE SOFT-SWR SELECTED?
(1) 022402 001104 BNE 15$ ;:BRANCH IF NO
(1) 022404 105777 156534 TSTB @STKS ;:CHAR THERE?
(1) 022410 100101 BPL 15$ ;:IF NO, DON'T WAIT AROUND
(1) 022412 117746 156530 MOVB @STKB,-(SP) ;:SAVE THE CHAR
(1) 022416 042716 177600 BIC #^C177,(SP) ;:STRIP-OFF THE ASCII
(1) 022422 022726 000007 CMP #7,(SP)+ ;:IS IT A CONTROL G?
(1) 022426 001072 BNE 15$ ;:NO, RETURN TO USER
(1) 022430 126727 156500 000001 CMPB $AUTOB,#1 ;:ARE WE RUNNING IN AUTO-MODE?
(1) 022436 001466 BEQ 15$ ;:BRANCH IF YES
(1)
(2) 022440 004567 001056 JSR R5, SPRINT ;:GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 022444 023321 .WORD $CNTLG ;:ADDRESS OF MESSAGE TO BE TYPED
(1) 022446 SGTWR: JSR R5, SPRINT ;:GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 022446 004567 001050 .WORD $MSWR ;:ADDRESS OF MESSAGE TO BE TYPED
(2) 022452 023326 MOV SWREG,-(SP) ;:SAVE SWREG FOR TYPEOUT
(2) 022454 016746 155516
(4) * THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE STYPOC ROUTINE
(4) * WITHOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
(4) 022460 013746 177776 MOV @MPSW, -(SP) ;:PUT THE PROCESSOR STATUS ON THE STACK
(4) 022464 004767 002230 JSR PC, STYPOC ;:GO TO THE SUBROUTINE
(2) 022470 004567 001026 JSR R5, SPRINT ;:GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 022474 023337 .WORD $MNEW ;:ADDRESS OF MESSAGE TO BE TYPED
(1) 022476 005046 19$: CLR -(SP) ;:CLEAR COUNTER
(1) 022500 005046 CLR -(SP) ;:THE NEW SWR
(1) 022502 105777 156436 7$: TSTB @STKS ;:CHAR THERE?
(1) 022506 100375 BPL 7$ ;:IF NOT TRY AGAIN
(1)
(1) 022510 117746 156432 MOV B 15$ ;:PICK UP CHAR
(1) 022514 042716 177600 BIC #^C177,(SP) ;:MAKE IT 7-BIT ASCII
(1)
(1)
(1) 022520 021627 000025 9$: CMP (SP),#25 ;:IS IT A CONTROL-U?
(1) 022524 001006 BNE 10$ ;:BRANCH IF NOT
(2) 022526 004567 000770 JSR R5, SPRINT ;:GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 022532 023314 .WORD $CNTLU ;:ADDRESS OF MESSAGE TO BE TYPED
(1) 022534 062706 000006 ADD #6,SP ;:IGNORE PREVIOUS INPUT
(1) 022540 000756 BR 19$ ;:LET'S TRY IT AGAIN
(1)
(1)
(1) 022542 021627 000015 10$: CMP (SP),#15 ;:IS IT A <CR>?
(1) 022546 001023 BNE 16$ ;:BRANCH IF NO
(1) 022550 005766 000004 TST 4(SP) ;:YES, IS IT THE FIRST CHAR?
(1) 022554 001403 BEQ 11$ ;:BRANCH IF YES

```

CZQMCGO 0-124K MEMORY EXERCISER, 16K VER M 8
 CZQMCG.P11 12-MAR-80 13:07 TTY INPUT ROUTINE MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-86

SEQ 0103

(1) 022556 016677 000002 156354		MOV 2(SP),@SWR	;;SAVE NEW SWR	
(1) 022564 062706 000006	11\$: ADD #6,SP		;;CLEAR UP STACK	
(1) 022570	14\$: JSR .WORD	R5, SPRINT	;GO PRINT OUT THE FOLLOWING MESSAGE.	
(2) 022570 004567 000726	CMPB	\$CRLF	;ADDRESS OF MESSAGE TO BE TYPED	
(2) 022574 001201	BNE 15\$	\$INTAG,#1	;RE-ENABLE TTY KBD INTERRUPTS?	
(1) 022576 126727 156333 000001	MOV #100,@STKS		;BRANCH IF NOT	
(1) 022604 001003	RTI		;RE-ENABLE TTY KBD INTERRUPTS	
(1) 022606 012777 000100 156330	JSR PC,\$TYPEC		;RETURN	
(1) 022614 000002	CMP (SP),#60		;ECHO CHAR	
(1) 022616 004767 001142	BLT 18\$;CHAR < 0?	
(1) 022622 021627 000060	CMP (SP),#67		;BRANCH IF YES	
(1) 022626 002420	BGT 18\$;CHAR > ??	
(1) 022630 021627 000067	BIC #60,(SP)+		;BRANCH IF YES	
(1) 022634 003015	TST 2(SP)		;STRIP-OFF ASCII	
(1) 022636 042726 000060	BEQ 17\$;IS THIS THE FIRST CHAR	
(1) 022642 005766 000002	ASL (SP)		;BRANCH IF YES	
(1) 022646 001403	ASL (SP)		;NO, SHIFT PRESENT	
(1) 022650 006316	ASL (SP)		;CHAR OVER TO MAKE	
(1) 022652 006316	ASL (SP)		;ROOM FOR NEW ONE.	
(1) 022654 006316	INC 2(SP)		;KEEP COUNT OF CHAR	
(1) 022656 005266 000002	BIS -2(SP),(SP)		;SET IN NEW CHAR	
(1) 022662 056616 177776	BR 7\$;GET THE NEXT ONE	
(1) 022666 000705	JSR R5, SPRINT		;GO PRINT OUT THE FOLLOWING MESSAGE.	
(2) 022670 004567 000626	.WORD \$QUES		;ADDRESS OF MESSAGE TO BE TYPED	
(1) 022674 001200	BR 20\$;SIMULATE CONTROL-U	
(1) 022676 000716	DSABL LSB			
(1)				
(1)				
(2)				
(1)			*****	
(1)			;THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY	
(1)			;CALL:	
(1)			;RDCHR	;;INPUT A SINGLE CHARACTER FROM THE TTY
(1)			;RETURN HERE	;CHARACTER IS ON THE STACK
(1)			;	;WITH PARITY BIT STRIPPED OFF
(1)			;	
(1) 022700 011646	\$RDCHR: MOV (SP),-(SP)		;PUSH DOWN THE PC	
(1) 022702 016666 000004	MOV 4(SP),2(SP)		;SAVE THE PS	
(1) 022710 105777 156230 000002	TSTB @STKS		;WAIT FOR	
(1) 022714 100375	BPL 1\$;A CHARACTER	
(1) 022716 117766 156224 000004	MOV B @STKB,4(SP)		;READ THE TTY	
(1) 022724 042766 177600 000004	BIC #^C<17>,4(SP)		;GET RID OF JUNK IF ANY	
(1) 022732 026627 000004 000023	CMP 4(SP),#23		;IS IT A CONTROL-S?	
(1) 022740 001013	BNE 3\$;BRANCH IF NO	
(1) 022742 105777 156176	TSTB @STKS		;WAIT FOR A CHARACTER	
(1) 022746 100375	BPL 2\$;LOOP UNTIL ITS THERE	
(1) 022750 117746 156172	MOV B @STKB,-(SP)		;GET CHARACTER	
(1) 022754 042716 177600	BIC #^C17\$,-(SP)		;MAKE IT 7-BIT ASCII	
(1) 022760 022627 000021	CMP (SP)+,#21		;IS IT A CONTROL-Q?	
(1) 022764 001366	BNE 2\$;IF NOT DISCARD IT	
(1) 022766 000750	BR 1\$;YES, RESUME	
(1) 022770 026627 000004 000140	CMP 4(SP),#140		;IS IT UPPER CASE?	
(1) 022776 002407	BLT 4\$;BRANCH IF YES	
(1) 023000 026627 000004 000175	CMP 4(SP),#175		;IS IT A SPECIAL CHAR?	

```

(1) 023006 003003      BGT   4$      ;:BRANCH IF YES
(1) 023010 042766 000040 000004      BIC   #40,4(SP)    ;:MAKE IT UPPERCASE
(1) 023016 000002      4$: RTI      ;:GO BACK TO USER
(2)
(1) :*****THIS ROUTINE WILL INPUT A STRING FROM THE TTY*****
(1) :*CALL:
(1) :* RDLIN               ;:INPUT A STRING FROM THE TTY
(1) :* RETURN HERE          ;:ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
(1) :*                   ;:TERMINATOR WILL BE A BYTE OF ALL 0'S
(1)
(1) 023020 010346      SRDLIN: MOV   R3,-(SP)  ;:SAVE R3
(1) 023022 005046      CLR   -(SP)    ;:CLEAR THE RUBOUT KEY
(1) 023024 012703 023304      1$: MOV   #$TTYIN,R3  ;:GET ADDRESS
(1) 023030 022703 023314      2$: CMP   #$TTYIN+8.,R3 ;:BUFFER FULL?
(1) 023034 101467      BLOS  4$      ;:BR IF YES
(3) :* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $RDCHR ROUTINE
(3) :* WITHOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.
(3) 023036 013746 177776      MOV   @MPSW, -(SP) ;:PUT THE PROCESSOR STATUS ON THE STACK
(3) 023042 004767 177632      JSR   PC, $RDCHR ;:GO TO THE SUBROUTINE
(1) 023046 112613      MOVB  (SP)+,(R3) ;:GET CHARACTER
(1) 023050 122713 000177      10$: CMPB #177,(R3) ;:IS IT A RUBOUT
(1) 023054 001024      BNE   5$      ;:BR IF NO
(1) 023056 005716      TST   (SP)    ;:IS THIS THE FIRST RUBOUT?
(1) 023060 001010      BNE   6$      ;:BR IF NO
(1) 023062 112767 000134 000212      MOVB  #'\.9$    ;:TYPE A BACK SLASH
(2) 023070 004567 000426      JSR   R5, $PRINT ;:GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 023074 023302      .WORD  9$      ;:ADDRESS OF MESSAGE TO BE TYPED
(1) 023076 012716 177777      MOV   #-1,(SP) ;:SET THE RUBOUT KEY
(1) 023102 005303      DEC   R3      ;:BACKUP BY ONE
(1) 023104 020327 023304      CMP   R3,#$TTYIN ;:STACK EMPTY?
(1) 023110 103441      BLO   4$      ;:BR IF YES
(1) 023112 111367 000164      MOVB  (R3),9$  ;:SETUP TO TYPEOUT THE DELETED CHAR.
(2) 023116 004567 000400      JSR   R5, $PRINT ;:GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 023122 023302      .WORD  9$      ;:ADDRESS OF MESSAGE TO BE TYPED
(1) 023124 000741      BR    2$      ;:GO READ ANOTHER CHAR.
(1) 023126 005716      5$: TST   (SP)    ;:RUBOUT KEY SET?
(1) C23130 001407      BEQ   7$      ;:BR IF NO
(1) 023132 112767 000134 000142      MOVB  #'\.9$    ;:TYPE A BACK SLASH
(2) 023140 004567 000356      JSR   R5, $PRINT ;:GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 023144 023302      .WORD  9$      ;:ADDRESS OF MESSAGE TO BE TYPED
(1) 023146 005016      CLR   (SP)    ;:CLEAR THE RUBOUT KEY
(1) 023150 122713 000025      CMPB #25,(R3) ;:IS CHARACTER A CTRL U?
(1) 023154 001004      BNE   8$      ;:BR IF NO
(2) 023156 004567 000340      JSR   R5, $PRINT ;:GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 023162 023314      .WORD  SCNTLU ;:ADDRESS OF MESSAGE TO BE TYPED
(1) 023164 000717      BR    1$      ;:GO START OVER
(1) 023166 122713 000022      CMPB #22,(R3) ;:IS CHARACTER A '^R'?
(1) 023172 001014      BNE   3$      ;:BRANCH IF NO
(1) 023174 105013      CLRB  (R3)    ;:CLEAR THE CHARACTER
(2) 023176 004567 000320      JSR   R5, $PRINT ;:GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 023202 001201      .WORD  SCRLF ;:ADDRESS OF MESSAGE TO BE TYPED
(2) 023204 004567 000312      JSR   R5, $PRINT ;:GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 023210 023304      .WORD  $TTYIN ;:ADDRESS OF MESSAGE TO BE TYPED
(1) 023212 000706      BR    2$      ;:GO PICKUP ANOTHER CHARACTER
(1) 023214 004567 000302      4$: JSR   R5, $PRINT ;:GO PRINT OUT THE FOLLOWING MESSAGE.

```

(2) 023220 001200	.WORD	SQUES	ADDRESS OF MESSAGE TO BE TYPED
(1) 023222 000700	BR	1\$;CLEAR THE BUFFER AND LOOP
(1) 023224 111367 000052	MOV _B	(R3),9\$;ECHO THE CHARACTER
(2) 023230 004567 000266	JSR	R5, SPRINT	;GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 023234 023302	.WORD	9\$	ADDRESS OF MESSAGE TO BE TYPED
(1) 023236 122723 000015	CMPB	#15,(R3)+	;CHECK FOR RETURN
(1) 023242 001272	BNE	2\$;LOOP IF NOT RETURN
(1) 023244 105063 177777	CLR _B	-1(R3)	;CLEAR RETURN (THE 15)
(2) 023250 004567 000246	JSR	R5, SPRINT	;GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 023254 001202	.WORD	\$LF	ADDRESS OF MESSAGE TO BE TYPED
(1) 023256 005726	TST	(SP)+	;CLEAN RUBOUT KEY FROM THE STACK
(1) 023260 012603	MOV	(SP)+,R3	;RESTORE R3
(1) 023262 011646	MOV	(SP),-(SP)	;ADJUST THE STACK AND PUT ADDRESS OF THE
(1) 023264 016666 000004	MOV	4(SP),2(SP)	FIRST ASCII CHARACTER ON IT
(1) 023272 012766 023304 000004	MOV	#\$TTYIN,4(SP)	
(1) 023300 000002	RTI		;RETURN
(1) 023302 000	.BYTF	0	;STORAGE FOR ASCII CHAR. TO TYPE
(1) 023303 000	.BYTE	0	;TERMINATOR
(1) 023304 000010	\$TTYIN:	.BLKB 8.	;RESERVE 8 BYTES FOR TTY INPUT
(1) 023314 052536 005015 000	SCNTLU:	.ASCIZ /*U/<15><12>	;CONTROL 'U'
(1) 023321 136 006507 000012	SCNTLG:	.ASCIZ /*G/<15><12>	;CONTROL 'G'
(1) 023326 005015 053523 020122	\$MSWR:	.ASCIZ <15><12>/SWR = /	
(1) 023334 020075 000	SMNEW:	.ASCIZ / NEW = /	
(1) 023344 036440 000040	.SBTTL	READ AN OCTAL NUMBER FROM THE TTY	

8924

***** *THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND *CHANGE IT TO BINARY. *THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL *OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A '?' WILL BE TYPED *FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST *THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN. *CALL: * RDOCT * RETURN HERE			
;:READ AN OCTAL NUMBER ;:LOW ORDER BITS ARE ON TOP OF THE STACK ;:HIGH ORDER BITS ARE IN SHIOCT			
(1) 023350 011646	.SRDOCT:	MOV (SP),-(SP)	;PROVIDE SPACE FOR THE
(1) 023352 016666 000004 000002		MOV 4(SP),2(SP)	;INPUT NUMBER
(3) 023360 010046		MOV R0,-(SP)	;PUSH R0 ON STACK
(3) 023362 010146		MOV R1,-(SP)	;PUSH R1 ON STACK
(3) 023364 010246		MOV R2,-(SP)	;PUSH R2 ON STACK
(1) 023366	1\$:		
(3) 023366 013746 177776		THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE SRDLIN ROUTINE	
(3) 023372 004767 177422		WIHTOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**	
(3) 023376 012600		MOV #MPSW, -(SP)	;PUT THE PROCESSOR STATUS ON THE STACK
(1) 023400 010067 000102		JSR PC, SRDLIN	;GO TO THE SUBROUTINE
(1) 023404 005001		MOV (SP)+,R0	;GET ADDRESS OF 1ST CHARACTER
(1) 023406 005002		MOV R0,5\$;AND SAVE IT
(1) 023410 112046		CLR R1	
(1) 023412 001420		CLR R2	
(1) 023414 122716 000060	2\$:	MOV _B (R0)+,-(SP)	;PICKUP THIS CHARACTER
		BEO 3\$;IF ZERO GET OUT
		CMPB #'0,(SP)	;MAKE SURE THIS CHARACTER

```

(1) 023420 003026          BGT   4$           ::IS AN OCTAL DIGIT
(1) 023422 122716 000067    CMPB  #'7,(SP)
(1) 023426 002423          BLT   4$           :
(1) 023430 006301          ASL   R1           ::*2
(1) 023432 006102          ROL   R2           :
(1) 023434 006301          ASL   R1           ::*4
(1) 023436 006102          ROL   R2           :
(1) 023440 006301          ASL   R1           ::*8
(1) 023442 006102          ROL   R2           :
(1) 023444 042716 177770    BIC   #'C7,(SP)  ::STRIP THE ASCII JUNK
(1) 023450 062601          ADD   (SP)+,R1   ::ADD IN THIS DIGIT
(1) 023452 000756          BR    2$           ::LOOP
(1) 023454 005726          3$:   TST   (SP)+   ::CLEAN TERMINATOR FROM STACK
(1) 023456 010166 000012    MOV   R1,12(SP)  ::SAVE THE RESULT
(1) 023462 010267 000032    MOV   R2,$HIOCT
(3) 023466 012602          MOV   (SP)+,R2   ::POP STACK INTO R2
(3) 023470 012601          MOV   (SP)+,R1   ::POP STACK INTO R1
(3) 023472 012600          MOV   (SP)+,R0   ::POP STACK INTO R0
(1) 023474 000002          RTI   :             ::RETURN
(1) 023476 005726          4$:   TST   (SP)+   ::CLEAN PARTIAL FROM STACK
(1) 023500 105010          CLR8  (R0)        ::SET A TERMINATOR
(2) 023502 004567 000014    JSR   R5, SPRINT  :GO PRINT OUT THE FOLLOWING MESSAGE.
(1) 023506 000000          .WORD 0           :
(2) 023510 004567 000006    JSR   R5, SPRINT  :GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 023514 001200          .WORD $QUES      :ADDRESS OF MESSAGE TO BE TYPED
(1) 023516 000723          BR    1$           ::TRY AGAIN
(1) 023520 000000          $HIOCT: .WORD 0   ::HIGH ORDER BITS GO HERE

```

8925

8926

8927

;*****
 ;* SUBROUTINE TO PASS RELOCATED MESSAGE ADDRESSES TO THE \$TYPE ROUTINE.
 ;* CALL: JSR R5, SPRINT
 ;* <MESSAGE VIRTUAL ADDRESS>

8928

8929

8930

8931

\$PRINT: MOV (R5)+, 1\$;GET THE MESSAGE VIRTUAL ADDRESS.

8932

ADD RELOCF, 1\$;MAKE IT PHYSICAL.

8933

;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE \$TYPE ROUTINE
 ;* WITHOUT USING A 'TRAP' INSTRUCTION AS CALLED FOR BY **SYSMAC**.

(1)

MOV @MPSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK

(1)

JSR PC, \$TYPE ;GO TO THE SUBROUTINE

8934

1\$: .WORD 0 ;CONTAINS THE PHYSICAL MESSAGE ADDRESS.

8935

RTS R5 ;RETURN.

8936

.SBTTL TYPE ROUTINE

(1)

(2)

(1)

;*****
 ;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
 ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.

(1)

;*NOTE1: \$NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.

(1)

;*NOTE2: \$FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.

(1)

;*NOTE3: \$FILLC CONTAINS THE CHARACTER TO FILL AFTER.

(1)

;*

(1)

;*CALL:

(1)

;*1) USING A TRAP INSTRUCTION

(1)

TYPE ,MESADR ;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING

(1)

(1)

;*OR

(1)

;* TYPE

(1)

SEQ 0107

* MESADR *

(1) 023550	105767	155403	\$TYPE:	TSTB	\$TPFLG	:: IS THERE A TERMINAL?	
(1) 023554	100002			BPL	1\$:: BR IF YES	
(1) 023556	000000			HALT		:: HALT HERE IF NO TERMINAL	
(1) 023560	000430			BR	3\$:: LEAVE	
(1) 023562	010046		1\$:	MOV	R0,-(SP)	:: SAVE RO	
(1) 023564	017600	000002		MOV	#PTENV,SENV	:: GET ADDRESS OF ASCIZ STRING	
(1) 023570	122767	000001	155426	CMPB		:: RUNNING IN APT MODE	
(1) 023576	001011			BNE	62\$:: NO, GO CHECK FOR APT CONSOLE	
(1) 023600	132767	000100	155417	BITB	#APTSPOOL,SENVM	:: SPOOL MESSAGE TO APT	
(1) 023606	001405			BEQ	62\$:: NO, GO CHECK FOR CONSOLE	
(1) 023610	010067	000004		MOV	R0,61\$:: SETUP MESSAGE ADDRESS FOR APT	
(1) 023614	004767	000222		JSR	PC,SATY3	:: SPOOL MESSAGE TO APT	
(1) 023620	000000			.WORD	0	:: MESSAGE ADDRESS	
(1) 023622	132767	000040	155375	62\$:	BITB	#APTC(SUP,SENVM	:: APT CONSOLE SUPPRESSED
(1) 023630	001003			BNE	60\$:: YES, SKIP TYPE OUT	
(1) 023632	112046			MOV	(R0)+,-(SP)	:: PUSH CHARACTER TO BE TYPED ONTO STACK	
(1) 023634	001005			BNE	4\$:: BR IF IT ISN'T THE TERMINATOR	
(1) 023636	005726			TST	(SP)+	:: IF TERMINATOR POP IT OFF THE STACK	
(1) 023640	012600			MOV	(SP)+,R0	:: RESTORE RO	
(1) 023642	062716	000002		ADD	#2,(SP)	:: ADJUST RETURN PC	
(1) 023646	000002			RTI		:: RETURN	
(1) 023650	122716	000011		CMPB	#HT,(SP)	:: BRANCH IF <HT>	
(1) 023654	001431			BEQ	8\$		
(1) 023656	122716	000200		CMPB	#CRLF,(SP)	:: BRANCH IF NOT <CRLF>	
(1) 023662	001007			BNE	5\$		
(1) 023664	005726			TST	(SP)+	:: POP <CR><LF> EQUIV	
(2) 023666	004567	177630		JSR	R5, SPRINT	:: GO PRINT OUT THE FOLLOWING MESSAGE.	
(1) 023672	001201			\$CRLF			
(1) 023674	105067	000130		CLRB	\$CHARCNT	:: CLEAR CHARACTER COUNT	
(1) 023700	000754			BR	2\$:: GET NEXT CHARACTER	
(1) 023702	004767	000056		JSR	PC,\$TYPEC	:: GO TYPE THIS CHARACTER	
(1) 023706	126726	155244		CMPB	\$FILLC,(SP)+	:: IS IT TIME FOR FILLER CHARS.?	
(1) 023712	001347			BNE	2\$:: IF NO GO GET NEXT CHAR.	
(1) 023714	016746	155234		MOV	\$NULL,-(SP)	:: GET # OF FILLER CHARS. NEEDED	
(1)						:: AND THE NULL CHAR.	
(1) 023720	105366	000001		DEC B	1(SP)	:: DOES A NULL NEED TO BE TYPED?	
(1) 023724	002770			BLT	6\$:: BR IF NO--GO POP THE NULL OFF OF STACK	
(1) 023726	004767	000032		JSR	PC,\$TYPEC	:: GO TYPE A NULL	
(1) 023732	105367	000072		DEC B	\$CHARCNT	:: DO NOT COUNT AS A COUNT	
(1) 023736	000770			BR	7\$:: LOOP	
(1)							
;HORIZONTAL TAB PROCESSOR							
(1) 023740	112716	000040		8\$:	MOV B	#' ,(SP)	:: REPLACE TAB WITH SPACE
(1) 023744	004767	000014		9\$:	JSR	PC,\$TYPEC	:: TYPE A SPACE
(1) 023750	132767	000007	000052	BITB	#7,\$CHARCNT	:: BRANCH IF NOT AT	
(1) 023756	001372			BNE	9\$:: TAB STOP	
(1) 023760	005726			TST	(SP)+	:: POP SPACE OFF STACK	
(1) 023762	000723			BR	2\$:: GET NEXT CHARACTER	
(1) 023764	105777	155160		\$TYPEC:	TSTB	@TPS	:: WAIT UNTIL PRINTER IS READY
(1) 023770	100375			BPL	\$TYPEC		
(1) 023772	116677	000002	155152	MOV B	2(SP),@TPB	:: LOAD CHAR TO BE TYPED INTO DATA REG.	
(1) 024000	122766	000015	000002	CMPB	#CR,2(SP)	:: IS CHARACTER A CARRIAGE RETURN?	

```

(1) 024006 001003      BNE    1$      ;:BRANCH IF NO
(1) 024010 105067 000014      CLR8   $CHARCNT  ;:YES--CLEAR CHARACTER COUNT
(1) 024014 000406      BR     $TYPEx  ;:EXIT
(1) 024016 122766 000012 000002 '$:      CMPB   #LF,2(SP)  ;:IS CHARACTER A LINE FEED?
(1) 024024 001402      BEQ   $TYPEx  ;:BRANCH IF YES
(1) 024026 105227      INCB   (PC)+  ;:COUNT THE CHARACTER
(1) 024030 000000      $CHARCNT:WORD 0  ;:CHARACTER COUNT STORAGE
(1) 024032 000207      $TYPEx: RTS  PC

8938          .SBTTL APT COMMUNICATIONS ROUTINE
(1)
(2)
(1) 024034 112767 000001 000376 $ATY1: MOVB  #1,$FFLG  ;:TO REPORT FATAL ERROR
(1) 024042 112767 000001 000366 $ATY3: MOVB  #1,$MFLG  ;:TO TYPE A MESSAGE
(1) 024050 000403      BR     $ATYC  ;:TO ONLY REPORT FATAL ERROR
(1) 024052 112767 000001 000360 $ATY4: MOVB  #1,$FFLG
(1) 024060      $ATYC:      MOV    R0,-(SP)  ;:PUSH R0 ON STACK
(3) 024060 010046      MOV    R1,-(SP)  ;:PUSH R1 ON STACK
(3) 024062 010146      TSTB   $MFLG  ;:SHOULD TYPE A MESSAGE?
(1) 024064 105767 000346      BEQ   $S  ;:IF NOT: BR
(1) 024070 001450      CMPB   #APTEENV,$ENV  ;:OPERATING UNDER APT?
(1) 024072 122767 000001 155124      BNE   3$  ;:IF NOT: BR
(1) 024100 001031      BITB   #APTSPOOL,$ENV  ;:SHOULD SPOOL MESSAGES?
(1) 024102 132767 000100 155115      BEQ   3$  ;:IF NOT: BR
(1) 024110 001425      MOV    #4(SP),R0  ;:GET MESSAGE ADDR.
(1) 024112 017600 000004      ADD   #2,4(SP)  ;:BUMP RETURN ADDR.
(1) 024116 062766 000002 000004      1$:      TST   $MSGTYPE  ;:SEE IF DONE W/ LAST XMISSION?
(1) 024124 005176 155054      BNE   1$  ;:IF NOT: WAIT
(1) 024130 001375      MOV    R0,$MSGAD  ;:PUT ADDR IN MAILBOX
(1) 024132 010067 155062      TSTB   (R0)+  ;:FIND END OF MESSAGE
(1) 024136 105720      2$:      BNE   2$  ;:SUB START OF MESSAGE
(1) 024140 001376      SUB   $MSGAD,R0  ;:GET MESSAGE LENGTH IN WORDS
(1) 024142 166700 155052      ASR   R0  ;:PUT LENGTH IN MAILBOX
(1) 024146 006200      MOV    R0,$MSGLGT  ;:TELL APT TO TAKE MSG.
(1) 024150 010067 155046      3$:      MOV    #4,$MSGTYPE  ;:PUT MSG ADDR IN JSR LINKAGE
(1) 024154 012767 000004 155022      BEQ   3$  ;:BUMP RETURN ADDRESS
(1) 024162 000413      MOV    #4(SP),4$  ;:PUSH 17776 ON STACK
(1) 024164 017667 000004 000016      ADD   #2,4(SP)  ;:CALL TYPE MACRO
(1) 024172 062766 000002 000004      3$:      MOV    17776,-(SP)  ;:POINT TO TABLE START
(3) 024200 016746 153572      JSR   PC,$TYPEx  ;:END OF TABLE?
(1) 024204 004767 177340      4$:      WORD  0  ;:IF SO: BR
(1) 024210 000000      5$:      .WORD 0  ;:PROPER ENTRY?
(1) 024212 105767 000221      TSTB   $LFLG  ;:IF SO: BR
(1) 024216 001422      BEQ   10$  ;:MOVE PAST COUNTER WORD
(1) 024220 017600 000004      MOV    #4(SP),R0  ;:KEEP LOOKING
(1) 024224 062766 000002 000004      ADD   #2,4(SP)  ;:TABLE FULL?
(1) 024232 012701 001344      MOV    #$ASSTAT,R1  ;:IF SO: BR -- NO MORE ROOM
(1) 024236 005711      6$:      TST   (R1)  ;:
(1) 024240 100404      BMI   8$  ;:
(1) 024242 020021      CMP   R0,(R1)+  ;:
(1) 024244 001406      BEQ   9$  ;:
(1) 024246 005721      TST   (R1)+  ;:
(1) 024250 000772      BR    6$  ;:
(1) 024252 026701 155234      8$:      CMP   $APTR,R1  ;:
(1) 024256 001402      BEQ   10$  ;:

```


CZOMCGO 0-124K MEMORY EXERCISER, 16K VER
CZOMCG.P11 12-MAR-80 13:07 CONVERT MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-93

G 9
SEQ 0110

```

(1)          ;*    MOV    NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
(1)          ;*    TYPDS
(1)
(1) 024442
(3) 024442 010046
(3) 024444 010146
(3) 024446 010246
(3) 024450 010346
(3) 024452 010546
(1) 024454 012746 020200
(1) 024460 016605 000020
(1) 024464 100004
(1) 024466 005405
(1) 024470 112766 000055 000001
(1) 024476 016700 154076
(1) 024502 012703 024664
(1) 024506 060003
(1) 024510 112723 000040
(1) 024514 005002
(1) 024516 016001 024654
(1) 024522 160105
(1) 024524 002402
(1) 024526 005202
(1) 024530 000774
(1) 024532 060105
(1) 024534 005702
(1) 024536 001002
(1) 024540 105716
(1) 024542 100407
(1) 024544 106316
(1) 024546 103003
(1) 024550 116663 000001 177777
(1) 024556 052702 000060
(1) 024562 052702 000040
(1) 024566 110223
(1) 024570 005720
(1) 024572 020067 155044
(1) 024576 103746
(1) 024600 101002
(1) 024602 010502
(1) 024604 000764
(1) 024606 105726
(1) 024610 100003
(1) 024612 116663 177777 177776
(1) 024620 105013
(3) 024622 012605
(3) 024624 012603
(3) 024626 012602
(3) 024630 012601
(3) 024632 012600
(2) 024634 004567 176662
(2) 024640 024664
(1) 024642 016666 000002 000004
(1) 024650 012616
(1) 024652 000002
(1) 024654 023420

          STYPDS:          ;*    MOV    R0,-(SP)      ;;PUSH R0 ON STACK
                           MOV    R1,-(SP)      ;;PUSH R1 ON STACK
                           MOV    R2,-(SP)      ;;PUSH R2 ON STACK
                           MOV    R3,-(SP)      ;;PUSH R3 ON STACK
                           MOV    R5,-(SP)      ;;PUSH R5 ON STACK
                           MOV    #20200,-(SP)   ;;SET BLANK SWITCH AND SIGN
                           MOV    20(SP),R5      ;;GET THE INPUT NUMBER
                           BPL   1$              ;;BR IF INPUT IS POS.
                           NEG   R5              ;;MAKE THE BINARY NUMBER POS.
                           MOVB  #'-,1(SP)       ;;MAKE THE ASCII NUMBER NEG.
                           MOV   RELOCF, R0        ;;GET RELOCATION FACTOR.
                           MOV   #SDBLK,R3        ;;SETUP THE OUTPUT POINTER
                           ADD   R0, R3            ;;ADD IN RELOCATION FACTOR.
                           MOVB  #'',(R3)+        ;;SET THE FIRST CHARACTER TO A BLANK
                           CLR   R2              ;;CLEAR THE BCD NUMBER
                           MOV   $DTBL(R0),R1       ;;GET THE CONSTANT
                           SUB   R1,R5            ;;FORM THIS BCD DIGIT
                           BLT   4$              ;;BR IF DONE
                           INC   R2              ;;INCREASE THE BCD DIGIT BY 1
                           BR    3$              ;;ADD BACK THE CONSTANT
                           ADD   R1,R5            ;;CHECK IF BCD DIGIT=0
                           TST   R2              ;;FALL THROUGH IF 0
                           BNE   5$              ;;STILL DOING LEADING 0'S?
                           TSTB  (SP)            ;;BR IF YES
                           BMI   7$              ;;MSD?
                           ASLB  (SP)            ;;BR IF NO
                           BCC   6$              ;;YES--SET THE SIGN
                           MOVB  1(SP),-1(R3)     ;;MAKE THE BCD DIGIT ASCII
                           BIS   #'0,R2            ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
                           BIS   #' ',R2           ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
                           MOVB  R2,(R3)+          ;;JUST INCREMENTING
                           TST   (R0)+            ;;CHECK THE TABLE INDEX
                           CMP   R0,.EIGHT         ;;GO DO THE NEXT DIGIT
                           BLO   2$              ;;GO TO EXIT
                           BHJ   8$              ;;GET THE LSD
                           MOV   R5,R2            ;;GO CHANGE TO ASCII
                           BR    6$              ;;WAS THE LSD THE FIRST NON-ZERO?
                           TSTB  (SP)+            ;;BR IF NO
                           BPL   9$              ;;YES--SET THE SIGN FOR TYPING
                           CLR8  (R3)            ;;SET THE TERMINATOR
                           MOVB  (SP)+,R5          ;;POP STACK INTO R5
                           MOVB  (SP)+,R3          ;;POP STACK INTO R3
                           MOVB  (SP)+,R2          ;;POP STACK INTO R2
                           MOVB  (SP)+,R1          ;;POP STACK INTO R1
                           MOVB  (SP)+,R0          ;;POP STACK INTO R0
                           JSR   R5, SPRINT        ;;GO PRINT OUT THE FOLLOWING MESSAGE.
                           .WORD $DBLK             ;;ADDRESS OF MESSAGE TO BE TYPED
                           MOV   2(SP),4(SP)        ;;ADJUST THE STACK
                           MOV   (SP)+,(SP)          ;;RETURN TO USER
                           RTI   $DTBL: 10000.
```

(ZQMCGO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) H 9
(ZQMCG.P11 12-MAR-80 13:07 CONVERT BINARY TO DECIMAL AND TYPE ROUTINE 12-MAR-80 13:10 PAGE 59-94

SEQ 0111

(1) 024656 001750 1000.
(1) 024660 000144 100.
(1) 024662 000012 10.
(1) 024664 000004 \$DBLK: .BLKW 4
894C .SBTTL BINARY TO OCTAL (ASCII) AND TYPE
(1)
(2):*****
(1):*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
(1):*OCTAL (ASCII) NUMBER AND TYPE IT.
(1):*\$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
(1):*CALL:
(1):* MOV NUM,-(SP) ;:NUMBER TO BE TYPED
(1):* TYPOS ;:CALL FOR TYPEOUT
(1):* .BYTE N ;:N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
(1):* .BYTE M ;:M=1 OR 0
(:*: ;:1=TYPE LEADING ZEROS
(1):* ;:0=SUPPRESS LEADING ZEROS
(1):*
(1):*:\$TYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
(1):*:\$TYPOS OR \$TYPOC
(1):*CALL:
(1):* MOV NUM,-(SP) ;:NUMBER TO BE TYPED
(1):* TYPON ;:CALL FOR TYPEOUT
(1):*
(1):*:\$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
(1):*CALL:
(1):* MOV NUM,-(SP) ;:NUMBER TO BE TYPED
(1):* TYPOC ;:CALL FOR TYPEOUT
(1) 024674 017646 000000 000213 \$TYPOS: MOV a(SP),-(SP) ;:PICKUP THE MODE
(1) 024700 116667 000001 000173 MOVB 1(SP),\$OFILL ;:LOAD ZERO FILL SWITCH
(1) 024706 112667 000211 MOVB (SP)+,\$OMODE+1 ;:NUMBER OF DIGITS TO TYPE
(1) 024712 062716 000002 ADD #2,(SP) ;:ADJUST RETURN ADDRESS
(1) 024716 000406 BR \$TYPON
(1) 024720 112767 000001 000173 \$TYPOC: MOVB #1,\$OFILL ;:SET THE ZERO FILL SWITCH
(1) 024726 112767 000006 000167 MOVB #6,\$OMODE+1 ;:SET FOR SIX(6) DIGITS
(1) 024734 112767 000005 000156 STYFUN: MOVB #5,\$OCNT ;:SET THE ITERATION COUNT
(1) 024742 010346 MOV R3,-(SP) ;:SAVE R3
(1) 024744 010446 MOV R4,-(SP) ;:SAVE R4
(1) 024746 010546 MOV R5,-(SP) ;:SAVE R5
(1) 024750 116704 000147 MOVB \$OMODE+1,R4 ;:GET THE NUMBER OF DIGITS TO TYPE
(1) 024754 005404 NEG R4
(1) 024756 062704 000006 ADD #6,R4 ;:SUBTRACT IT FOR MAX. ALLOWED
(1) 024762 110467 000134 MOVB R4,\$OMODE ;:SAVE IT FOR USE
(1) 024766 116704 000127 MOVB \$OFILL,R4 ;:GET THE ZERO FILL SWITCH
(1) 024772 016605 000012 MOV 12(SP),R5 ;:PICKUP THE INPUT NUMBER
(1) 024776 005003 CLR R3 ;:CLEAR THE OUTPUT WORD
(1) 025000 006105 1\$: ROL R5 ;:ROTATE MSB INTO 'C'
(1) 025002 000404 BR 3\$;:GO DO MSB
(1) 025004 006105 2\$: ROL R5 ;:FORM THIS DIGIT
(1) 025006 006105
(1) 025010 006105
(1) 025012 010503
(1) 025014 006103 3\$: ROL R3 ;:GET LSB OF THIS DIGIT
(1) 025016 105367 000100 DECB \$OMODE ;:TYPE THIS DIGIT?
(1) 025022 100017 BPL 7\$;:BR IF NO

ZOM(U) 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) I 9
 CZQMCG.P11 12-MAR-80 13:07 BINARY TO OCTAL (ASCII) AND TYPE

SEQ 0112

```

(1) 025024 042703 177770      BIC #177770,R3   ;:GET RID OF JUNK
(1) 025030 001002      BNE 4$      ;:TEST FOR 0
(1) 025032 005704      TST R4     ;:SUPPRESS THIS 0?
(1) 025034 001403      BEQ 5$     ;:BR IF YES
(1) 025036 005204      4$: INC R4     ;:DON'T SUPPRESS ANYMORE 0'S
(1) 025040 052703 000060      BIS #'0,R3   ;:MAKE THIS DIGIT ASCII
(1) 025044 052703 000040      5$: BIS #' ,R3   ;:MAKE ASCII IF NOT ALREADY
(1) 025050 110367 000042      MOVB R3,8$   ;:SAVE FOR TYPING
(2) 025054 004567 176442      JSR R5, $PRINT  ;:GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 025060 025116      .WORD 8$      ;:ADDRESS OF MESSAGE TO BE TYPED
(1) 025062 105367 000032      7$: DECB $OCNT  ;:COUNT BY 1
(1) 025066 003346      BGT 2$     ;:BR IF MORE TO DO
(1) 025070 002402      BLT 6$     ;:BR IF DONE
(1) 025072 005204      INC R4     ;:INSURE LAST DIGIT ISN'T A BLANK
(1) 025074 000743      BR 2$     ;:GO DO THE LAST DIGIT
(1) 025076 012605      MOV (SP)+,R5  ;:RESTORE R5
(1) 025100 012604      MOV (SP)+,R4  ;:RESTORE R4
(1) 025102 012603      MOV (SP)+,R3  ;:RESTORE R3
(1) 025104 016666 000002 000004      MOV 2(SP),4(SP) ;:SET THE STACK FOR RETURNING
(1) 025112 012616      MOV (SP)+,(SP)
(1) 025114 000002      RTI      ;:RETURN
(1) 025116 000      8$: .BYTE 0   ;:STORAGE FOR ASCII DIGIT
(1) 025117 000      .BYTE 0   ;:TERMINATOR FOR TYPE ROUTINE
(1) 025120 000      $OCNT: .BYTE 0   ;:OCTAL DIGIT COUNTER
(1) 025121 000      $OFILL: .BYTE 0   ;:ZERO FILL SWITCH
(1) 025122 000000      $OMODE: .WORD 0   ;:NUMBER OF DIGITS TO TYPE
8941      :ERROR TRAP SERVICE ROUTINE
8942 025124 005727      ERRTRP: TST (PC)+ ;:CHECK IF PREV TRAP TO 4 REPORTED
8943 025126 000000      1$: .WORD 0   ;:CONTAINS ERROR REPORTED FLAG
8944 025130 001010      BNE 2$     ;:BRANCH IF NOT REPORTED
8945 025132 005267 177770      INC 1$     ;:SET DOUBLE TRAP FLAG.
8946 025136 011667 154024      MOV (SP), $TMP3 ;:SAVE THE BAD PC FOR TYPOUT.
8947 025142 004767 174502      JSR PC, $ERROR ;:*** ERROR *** (GO TYPE A MESSAGE)
(1) 025146 000031      .WORD 31   ;:ERROR TYPE CODE.
8948 025150 000401      BR 3$     ;:SKIP HALT
8949 025152 000000      2$: HALT   ;:ERROR! SECOND TRAP TO 4 OCCURRED
8950      ;:BEFORE FIRST WAS PRINTED
8951 025154 005067 177746      3$: CLR 1$   ;:RETURN TO PROGRAM AND TRY TO RECOVER
8952 025160 000002      RTI      ;:RETURN TO PROGRAM AND TRY TO RECOVER
8953      :SBTTL PHYSICAL ADDRESS TYPE ROUTINE
8954      :* ROUTINE TO TYPE A PHYSICAL ADDRESS (18 BITS).
8955      $TYPAD: MOV R0,-(SP) ;:PUSH R0 ON STACK
(2) 025162 010046      MOV R1,-(SP) ;:PUSH R1 ON STACK
(2) 025164 010146      MOV R2,-(SP) ;:PUSH R2 ON STACK
(2) 025166 010240      MOV R3,-(SP) ;:PUSH R3 ON STACK
8957 025172 016602 000012      MOV 12(SP), R2 ;:GET BASE ADDRESS
8958 025176 005003      CLR R3     ;:WORKING & INDEX REGISTER
8959 025200 005767 153402      TST MMAVA ;:CHECK FOR MEM MGMT AVAILABLE
8960 025204 001430      BEQ 1$     ;:BRANCH IF NO MEM MGMT
8961 025206 032737 000001 177572      BIT #1, @SR0 ;:CHECK IF MEM MGMT ENABLED
8962 025214 001424      BEQ 1$     ;:BRANCH IF MEM MGMT NOT ENABLED
8963 025216 010201      MOV R2, R1   ;:COPY VIRTUAL ADR
8964 025220 006101      ROL R1     ;:SHUFFLE BITS 13,14,15 INTO 1,2,3
8965 025222 006101      ROL R1

```

CZQMCGO 0-124K MEMORY EXERCISER, 16K VER
CZQMCG.P11 12-MAR-80 13:07

J 9
MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-96
PHYSICAL ADDRESS TYPE ROUTINE

SEQ 0113

8966 025224 006101 ROL R1
8967 025226 006101 ROL R1
8968 025230 006101 ROL R1
8969 025232 042701 177761 BIC #177761, R1 ;CLR ALL EXCEPT BITS 1,2,3
8970 025236 062701 172340 ADD #KIPARO, R1. ;SET TO APPROPRIATE PAR
8971 025242 011101 MOV (R1), R1 ;GET CONTENTS OF PAR
8972 025244 012700 000006 MOV #6, R0 ;SET UP COUNTER
8973 025250 006301 4\$: ASL R1 ;SHIFT PAR
8974 025252 006103 ROL R3 ;SAVE OVERFLOW BITS
8975 025254 077003 S0B R0, 4\$;COUNT SIX SHIFTS
8976 025256 042702 160000 BIC #160000, R2 ;SAVE BANK BITS
8977 025262 060102 ADD R1, R2 ;COMPUTE PHYSICAL ADDRESS
8978 025264 005503 ADC R3 ;MAKE SURE CARRY ISN'T LOST!
8979 025266 006302 1\$: ASL R2 ;FIRST DIGIT TO R3
8980 025270 006103 ROL R3
8981 025272 012700 000006 MOV #6, R0 ;DIGIT COUNT
8982 025276 000404 BR 3\$;PRINT FIRST DIGIT
8983 025300 006302 2\$: ASL R2
8984 025302 006103 ROL R3
8985 025304 005301 DEC R1
8986 025306 001374 BNE 2\$
8987 025310 012701 000003 3\$: MOV #3, R1 ;DIGIT SHIFT COUNT
8988 025314 062703 000060 ADD #60, R3 ;MAKE IT AN ASCII DIGIT
8989 025320 110367 000036 MOVB R3, 8\$;LOAD DIGIT INTO MESSAGE
8990 025324 004567 176172 JSR R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 025330 025362 .WORD 8\$;ADDRESS OF MESSAGE TO BE TYPED
8991 025332 005003 CLR R3 ;CLEAR INDEX
8992 025334 005300 DEC R0 ;DEC DIGIT COUNT
8993 025336 001360 BNE 2\$
8994 025340 012603 MOV (SP)+, R3 ;POP STACK INTO R3
(2) 025342 012602 MOV (SP)+, R2 ;POP STACK INTO R2
(2) 025344 012601 MOV (SP)+, R1 ;POP STACK INTO R1
(2) 025346 012600 MOV (SP)+, R0 ;POP STACK INTO R0
8995 025350 012616 MOV (SP)+, (SP) ;ADJUST THE STACK TO CLEAR DATA
8996 025352 004567 176144 JSR R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
(2) 025356 027015 .WORD FILL? ;ADDRESS OF MESSAGE TO BE TYPED
8997 025360 000207 RTS PC ;RETURN
8998 025362 000 8\$: .BYTE 0 ;ONE DIGIT MESSAGE BUFFER
8999 025363 000 .BYTE 0 ;MESSAGE TERMINATOR

9000
9001 .SBttl STANDARD PROGRAM MESSAGES
9002
9003 :*****
9004 :VARIOUS MESSAGE PRINTOUTS USED THRUOUT
9005 :THE PROGRAM
9006 :*****

9006 025364 005015 052113 030461 MMAMES: .ASCIZ <15><12>'KT11 (MEMORY MANAGEMENT) AVAILABLE'
025372 024040 042515 047515
025400 054522 046440 047101
025406 043501 046505 047105
025414 024524 040440 040526
025422 046111 041101 042514
025430 000
9007 025431 015 046412 046505 MEMMES: .ASCIZ <15><12>'MEMORY MAP:'
025436 051117 020131 040515
025444 035120 000 BYTMES: .ASCIZ <15><12>'BYTE MEMORY MAP:'
9008 025447 015 041012 052131

CZQMCGO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) K 9
CZQMC.G.P11 12-MAR-80 13:07 STANDARD PROGRAM MESSAGES 12-MAR-80 13:10 PAGE 59-97

SEQ 0114

025454 020105 042515 047515
025462 054522 046440 050101
025470 000072
9009 025472 005015 040520 044522 MTMAP: .ASCIIZ <15><12>'PARITY MEMORY MAP:'
025500 054524 046440 046505
025506 051117 020131 040515
025514 035120 000
9010 025517 015 043012 047522 FROM: .ASCIIZ <15><12>'FROM '
025524 020115 000
9011 025527 040 047524 000040 TO: .ASCIIZ ' TO '
9012 025534 005015 047111 052523 INSUFF: .ASCIIZ <15><12>'INSUFFICIENT MEMORY...FIRST 16K NOT ALL THERE!'
025542 043106 041511 042511
025550 052116 046440 046505
025556 051117 027131 027056
025564 044506 051522 020124
025572 033061 020113 047516
025600 020124 046101 020114
025606 044124 051105 020505
025614 000
9013 025615 015 047012 020117 MTR: .ASCIIZ <15><12>'NO PARITY REGISTERS FOUND'
025622 040520 044522 054524
025630 051040 043505 051511
025636 042524 051522 043040
025644 052517 042116 000
9014 025651 015 051012 051505 PWRMSG: .ASCIIZ <15><12>'RESTARTING AFTER A POWER FAILURE'<15><12>
025656 040524 052122 047111
025664 020107 043101 042524
025672 020122 020101 047520
025700 042527 020122 040506
025706 046111 051125 006505
025714 000012
9015 025716 005015 047516 050040 NOPES: .ASCIIZ <15><12>'NO PARITY ERRORS FOUND ON MEMORY SCAN'<15><12>
025724 051101 052111 020131
025732 051105 047522 051522
025740 043040 052517 042116
025746 047440 020116 042515
025754 047515 054522 051440
025762 040503 006516 000012
9016 025770 005015 051120 043517 PROREL: .ASCIII <15><12>'PROGRAM NOW RESIDES BACK AT 0 TO 8K'
025776 040522 020115 047516
026004 020127 042522 044523
026012 042504 020123 040502
026020 045503 040440 020124
026026 020060 047524 034040
026034 113
9017 026035 015 044012 052111 .ASCIIZ <15><12>'HIT CONTINUE FOR NORMAL RUNNING'<15><12>
026042 041440 047117 044524
026050 052516 020105 047506
026056 020122 047516 046522
026064 046101 051040 047125
026072 044516 043516 005015
026100 000
9018 026101 015 051012 043505 MX1: .ASCIIZ <15><12>'REGISTER AT '
026106 051511 042524 020122
026114 052101 000040
9019 026120 041440 047117 051124 MX2: .ASCIIZ ' CONTROLS '

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-98
CZOMCG.P11 12-MAR-80 13:07 STANDARD PROGRAM MESSAGES

L 9
SEQ 0115

9020	026126	046117	020123	000		
	026133	015	041412	051117	MX3:	.ASCII <15><12>'CORE PARITY '
	026140	020105	040520	044522		
	026146	054524	000040			
9021	02152	005015	047515	020123	MX4:	.ASCII <15><12>'MOS PARITY '
	026160	040520	044522	054524		
	026166	000040				
9022	026170	005015	051515	030461	MX5:	.ASCII <15><12>'MS11-K CSR '
	026176	045455	041440	051123		
	026204	000040				
9023	026206	051515	030461	045455	MX6:	.ASCII 'MS11-K MEMORY PRESENT.' TO COMPLETELY TEST RUN DZMML...'
	026214	046440	046505	051117		
	026222	020131	051120	051505		
	026230	047105	020524	020041		
	026236	047524	041440	046517		
	026244	046120	052105	046105		
	026252	020131	042524	052123		
	026260	051040	047125	042040		
	026266	046532	046115	027056		
	026274	000056				
9024	026276	005015	047516	046440	NOMEM:	.ASCII <15><12>'NO MEMORY FOUND.'
	026304	046505	051117	020131		
	026312	047506	047125	027104		
	026320	000				
9025	026321	015	005012	044412	FADMES:	.ASCII <15><12><12><12>'INPUT ALL PARAMETERS IN OCTAL.'
	026326	050116	052125	040440		
	026334	046114	050040	051101		
	026342	046501	052105	051105		
	026350	020123	047111	047440		
	026356	052103	046101	056		
9026	026363	015	043012	051111		.ASCII <15><12>'FIRST ADDRESS: '
	026370	052123	040440	042104		
	026376	042522	051523	020072		
	026404	000040				
9027	026406	005015	040514	052123	LADMES:	.ASCII <15><12>'LAST ADDRESS: '
	026414	040440	042104	042522		
	026422	051523	020072	020040		
	026430	000				
9028	026431	015	037412	042101	BADADR:	.ASCII <15><12>'ADDRESS IN UNMAPPED BANK?'
	026436	051104	051505	020123		
	026444	047111	052440	046516		
	026452	050101	042520	020104		
	026460	040502	045516	000077		
9029	026466	005015	042523	042514	CONST:	.ASCII <15><12>'SELECT CONSTANT: '
	026474	052103	041440	047117		
	026502	052123	047101	035124		
	026510	000				
9030	026511	015	052412	042516	UNEXPT:	.ASCII <15><12>'UNEXPECTED MEMORY PARITY ERROR'
	026516	050130	041505	042524		
	026524	020104	042515	047515		
	026532	054522	050040	051101		
	026540	052111	020131	051105		
	026546	047522	000122			
9031	026552	005015	051120	043517	PRELOC:	.ASCII <15><12>'PROGRAM RELOCATED TO '
	026560	040522	020115	042522		
	026566	047514	040503	042524		

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER M 9
CZOMCG.P11 12-MAR-80 13:07 MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-99

SEQ 0116

9032	026574	020104	047524	000040		
	026602	005015	047515	042522	MTOE:	.ASCIZ <15><12>'MORE THAN ONE PARITY ERROR FOUND.'
	026610	052040	040510	020116		
	026616	047117	020105	040520		
	026624	044522	054524	042440		
	026632	051122	051117	043040		
	026640	052517	042116	000056		
9033	026646	005015	041523	047101	SCANM:	.ASCIZ <15><12>'SCANNING MEMORY FOR BAD PARITY.'
	026654	044516	043516	046440		
	026662	046505	051117	020131		
	026670	047506	020122	040502		
	026676	020104	040520	044522		
	026704	054524	000056			
9034	026710	005015	040520	044522	PEWNC:	.ASCIZ <15><12>'PARITY ERROR WILL NOT CLEAR.'
	026716	054524	042440	051122		
	026724	051117	053440	046111		
	026732	020114	047516	020124		
	026740	046103	040505	027122		
	026746	000				
9035	026747	015	047012	020117	NOMTST:	.ASCIZ <15><12>'NO MEMORY TESTED.'
	026754	042515	047515	054522		
	026762	052040	051505	042524		
	026770	027104	000			
9036	026773	015	051412	044513	SKPMES:	.ASCIZ <15><12>'SKIPPING TEST #'
	027000	050120	047111	020107		
	027006	042524	052123	021440		
	027014	000				
9037	027015	377	000377		FILL2:	.ASCIZ <377><377>
9038						
9039					.SBTTL	ERROR REPORTING MESSAGES AND TABLES.
9040					*****	*****
9041					*****	MESSAGE BLOCK FOR ERROR TABLE TYPEOUTS
9042					*****	*****
9043	027020	040520	044522	054524	DM1:	.ASCIZ 'PARITY REGISTER DATA ERROR.'
	027026	051040	043505	051511		
	027034	042524	020122	040504		
	027042	040524	042440	051122		
	027050	051117	000056			
9044	027054	042101	051104	051505	DM2:	.ASCIZ 'ADDRESS TEST ERROR(TST1-5).'
	027062	020123	042524	052123		
	027070	042440	051122	051117		
	027076	052050	052123	026461		
	027104	024465	000056			
9045	027110	047503	051516	040524	DM4:	.ASCIZ 'CONSTANT DATA ERROR(TST6-10).'
	027116	052116	042040	052101		
	027124	020101	051105	047522		
	027132	024122	051524	033124		
	027140	030455	024460	000056		
9046	027146	047522	040524	044524	DM5:	.ASCIZ 'ROTATING BIT ERROR(TST11-12).'
	027154	043516	041040	052111		
	027162	042440	051122	051117		
	027170	052050	052123	030461		
	027176	030455	024462	000056		
9047	027204	047515	020123	042522	DM6:	.ASCIZ 'MOS REFRESH TEST ERROR (TST 30-31).'
	027212	051106	051505	020110		
	027220	042524	052123	042440		

9048	027226 051122 051117 024040			
	027234 051524 020124 030063			
	027242 031455 024461 000056			
	027250 020063 047530 020122	DM7:	.ASCIZ	'3 XOR 9 PATTERN ERROR(TST13-16).'
	027256 020071 040520 052124			
	027264 051105 020116 051105			
	027272 047522 024122 051524			
	027300 030524 026463 033061			
	027306 027051 000			
9049	027311 115 051101 044103	DM10:	.ASCIZ	'MARCHING 1'S AND 0'S ERROR(TST 27).'
	027316 047111 020107 023461			
	027324 020123 047101 020104			
	027332 023460 020123 051105			
	027340 047522 024122 051524			
	027346 020124 033462 027051			
	027354 000			
9050	027355 120 051101 052111	DM11:	.ASCIZ	'PARITY MEMORY ADDRESS ERROR(TST17).'
	027362 020131 042515 047515			
	027370 054522 040440 042104			
	027376 042522 051523 042440			
	027404 051122 051117 052050			
	027412 052123 033461 027051			
	027420 000			
9051	027421 104 052101 050111	DM12:	.ASCIZ	'DATIP WITH WRONG PARITY DIDN'T TRAP(TST17).'
	027426 053440 052111 020110			
	027434 051127 047117 020107			
	027442 040520 044522 054524			
	027450 042040 042111 023516			
	027456 020124 051124 050101			
	027464 052050 052123 033461			
	027472 027051 000			
9052	027475 127 047522 043516	DM13:	.ASCIZ	'WRONG PARITY TRAPPED, BUT NO REGISTER SHOWS ERROR FLAG.'
	027502 050040 051101 052111			
	027510 020131 051124 050101			
	027516 042520 026104 041040			
	027524 052125 047040 020117			
	027532 042522 044507 052123			
	027540 051105 051440 047510			
	027546 051527 042440 051122			
	027554 051117 043040 040514			
	027562 027107 000			
9053	027565 120 051101 052111	DM14:	.ASCIZ	'PARITY REGISTER NOT MAPPED AS CONTROLLING THIS ADDRESS(TST17).'
	027572 020131 042522 044507			
	027600 052123 051105 047040			
	027606 052117 046440 050101			
	027614 042520 020104 051501			
	027622 041440 047117 051124			
	027630 046117 044514 043516			
	027636 052040 044510 020123			
	027644 042101 051104 051505			
	027652 024123 051524 030524			
	027660 024467 000056			
9054	027664 047515 042522 052040	DM16:	.ASCIZ	'MORE THAN ONE REGISTER INDICATED PARITY ERROR.'
	027672 040510 020116 047117			
	027700 020105 042522 044507			
	027706 052123 051105 044440			

027714	042116	041511	052101		
027722	042105	050040	051101		
027730	052111	020131	051105		
027736	047522	027122	000		
9055	027743	104	052101	020101	DM17: .ASCIZ 'DATA SHOULDN'T HAVE CHANGED WHEN PARITY ERROR TRAPPED(TST17).' "
	027750	044123	052517	042114	
	027756	023516	020124	040510	
	027764	042526	041440	040510	
	027772	043516	042105	053440	
	030000	042510	020116	040520	
	030006	044522	054524	042440	
	030014	051122	051117	052040	
	030022	040522	050120	042105	
	030030	052050	052123	033461	
	030036	027051	000		
9056	030041	122	047101	047504	DM20: .ASCIZ 'RANDOM DATA ERROR(TST20).' "
	030046	020115	040504	040524	
	030054	042440	051122	051117	
	030062	052050	052123	030062	
	030070	027051	000		
9057	030073	111	051516	051124	DM21: .ASCIZ 'INSTRUCTION EXECUTION ERROR(TST21-26).' "
	030100	041525	044524	047117	
	030106	042440	042530	052503	
	030114	044524	047117	042440	
	030122	051122	051117	052050	
	030130	052123	030462	031055	
	030136	024466	000056		
9058	030142	051120	043517	040522	DM23: .ASCIZ 'PROGRAM CODE CHANGED WHEN RELOCATED.'
	030150	020115	047503	042504	
	030156	041440	040510	043516	
	030164	042105	053460	042510	
	030172	020116	042522	047514	
	030200	040503	042524	027104	
	030206	000			
9059	030207	124	040522	050120	DM24: .ASCIZ 'TRAPPED, BUT NO REGISTER HAD ERROR BIT SET.'
	030214	042105	020054	052502	
	030222	020124	047516	051040	
	030230	043505	051511	042524	
	030236	020122	040510	020104	
	030244	051105	047522	020122	
	030252	044502	020124	042523	
	030260	027124	000		
9060	030263	124	040522	050120	DM25: .ASCIZ 'TRAPPED TO 114.'
	030270	042105	052040	020117	
	030276	030461	027064	000	
9061	030303	106	044501	042514	DM26: .ASCIZ 'FAILED TO TRAP.'
	030310	020104	047524	052040	
	030316	040522	027120	000	
9062	030323	050	041501	044524	DM27: .ASCIZ '"(ACTION ENABLE WASN'T SET)."'
	030330	047117	042440	040516	
	030336	046102	020105	040527	
	030344	047123	052047	051440	
	050352	052105	027051	000	
9063	030357	015	052012	040522	DM31: .ASCIZ <15><12>'TRAPPED TO 4 '
	030364	050120	042105	052040	
	030372	020117	020064	000	

9064
 9065
 9066
 9067
 9068
 9069 030377 120 004503 042522 DH1: .ASCIZ 'PC REG S/B WAS'
 030404 004507 027523 004502
 030412 040527 000123
 9070 030416 027526 041520 050011 DH2: .ASCIZ 'V/PC P/PC MA S/B WAS'
 030424 050057 004503 040515
 030432 051411 041057 053411
 030440 051501 000
 9071 030443 126 050057 004503 DH12: .ASCIZ 'V/PC P/PC MA S/B'
 030450 027520 041520 046411
 030456 004501 027523 000102
 9072 030464 027526 041520 050011 DH14: .ASCIZ 'V/PC P/PC REG MA'
 030472 050057 004503 042522
 030500 004507 040515 000
 9073 030505 126 050057 004503 DH15: .ASCIZ 'V/PC P/PC MAUT REG S/B WAS'
 030512 027520 041520 046411
 030520 052501 004524 042522
 030526 004507 027523 004502
 030534 040527 000123
 9074 030540 027526 041520 050011 DH21: .ASCIZ 'V/PC P/PC IUT MA S/B WAS'
 030546 050057 004503 052511
 030554 004524 040515 051411
 030562 041057 053411 051501
 030570 000
 9075 030571 126 050057 004503 DH23: .ASCIZ 'V/PC P/PC SRC MA DST MA S/B WAS'
 030576 027520 041520 051411
 030604 041522 046440 004501
 030612 051504 020124 040515
 030620 051411 041057 053411
 030626 051501 000
 9076 030631 126 050057 004503 DH24: .ASCIZ 'V/PC P/PC TRP/PC'
 030636 027520 041520 052011
 030644 050122 050057 000103
 9077 030652 027526 041520 050011 DH25: .ASCIZ 'V/PC P/PC TRP/PC REG WAS'
 030660 050057 004503 051124
 030666 027520 041520 051011
 030674 043505 053411 051501
 030702 000
 9078 030703 126 050057 004503 DH26: .ASCIZ 'V/PC P/PC REG WAS'
 030710 027520 041520 051011
 030716 043505 053411 051501
 030724 000
 9079 030725 122 043505 053411 DH30: .ASCIZ 'REG WAS MA WAS'
 030732 051501 046411 004501
 030740 040527 000123
 9080
 9081
 9082
 9083
 9084 030744 000 377 000 DF1: .BYTE 0,-1,0,0
 030747 000
 9085 030750 000 377 377 DF2: .BYTE 0,-1,-1,0,0

;;*****
 ;* DATA FORMAT TABLE FOR ERROR PRINTOUT.
 ;* *****

CZQMCG0 0-124K MEMORY EXERCISER, 16K VER D 10
CZQMCG.P11 12-MAR-80 13:07 MACY11 30A(1052) 12-MAR-80 13:10 PAGE 59-103
ERROR REPORTING MESSAGES AND TABLES.

SEQ 0120

9086 030753 000 000
9086 030755 000 377 377 DF3: .BYTE 0,-1,-1,-2,-2
9087 030760 376 376
9087 030762 000 377 377 DF14: .BYTE 0,-1,-1,-1,0,0
9088 030765 377 000 000
9088 030770 000 377 000 DF21: .BYTE 0,-1,0,-1,0,0
9089 030773 377 000 000
9089 030776 377 000 377 DF30: .BYTE -1,0,-1,-2
9090 031001 376
9091 .EVEN
9092 032110 . 32110 ;THE LOADERS ARE SAVE HERE TO END OF 8K
9093
9094 000001 .END

ABASE = 000000	6485
ACDW1 = 000000	6485
ACDW2 = 000000	6485
ACPUIOP= 000000	6485
ADDW0 = 000000	6485
ADDW1 = 000000	6485
ADDW10= 000000	6485
ADDW11= 000000	6485
ADDW12= 000000	6485
ADDW13= 000000	6485
ADDW14= 000000	6485
ADDW15= 000000	6485
ADDW2 = 000000	6485
ADDW3 = 000000	6485
ADDW4 = 000000	6485
ADDW5 = 000000	6485
ADDW6 = 000000	6485
ADDW7 = 000000	6485
ADDW8 = 000000	6485
ADDW9 - 000000	6485
ADEVCT= 000000	6485
ADEVVM = 000000	6485
AE = 000001	6194# 7568 7640 8653
AENV = 000000	6485
AENVVM = 000000	6485
AFATAL= 000000	6485
AMADR1= 000000	6485
AMADR2= 000000	6485
AMADR3= 000000	6485
AMADR4= 000000	6485
AMAMS1= 000000	6485
AMAMS2= 000000	6485
AMAMS3= 000000	6485
AMAMS4= 000000	6485
AMSGAD= 000000	6485
AMSGLG= 000000	6485
AMSGTY= 000000	6485
AMTYP1= 000000	6485
AMTYP2= 000000	6485
AMTYP3= 000000	6485
AMTYP4= 000000	6485
APASS = 000000	6485
APRIOR= 000000	6485
APTCSU= 000040	8937 8938#
APTENV= 000001	8921 8937 8938#
APTSIZ= 000200	6624 8938#
APTSPO= 000100	8937 8938#
ASWREG= 000000	6485
ATESTN= 000000	6485
AUNIT = 000000	6485
AUSWR = 000000	6485
AVECT1= 000000	6485
AVECT2= 000000	6485
BADADR 026431	7108 9028#
BANKNO 016140	7214 7221 7229 7237 8329#
BITPT 001544	6485# 6837* 6838* 6874 6875 6876 6877 6885* 6886* 6895 6897 6900 6903*

CZQMCGO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) G 10
 CZQMCG.P11 12-MAR-80 13:07 CROSS REFERENCE TABLE -- USER SYMBOLS 12-MAR-80 13:10 PAGE 60-2

SEQ 0123

DH2	030416	6494	6500	6505	6510	6515	6520	6525	6530	6562	6567	9070#
DH21	030540	6572	9074#									
DH23	030571	6582	9075#									
DH24	030631	6587	9076#									
DH25	030652	6592	9077#									
DH26	030703	6597	6602	9078#								
DH30	030725	6607	9079#									
DIDBH	013002	7781#										
DIDBL	012710	7744#										
DIDO	012620	7707#										
DIPDO	013100	7821#										
DISPLA	001142	6485#	6624*	6626*	8507*	8560*	8919*	8921*				
DISPRE	000174	6204#	6624									
DM1	027020	6488	6550	9043#								
DM10	027311	6524	9049#									
DM11	027355	6529	9050#									
DM12	027421	6534	9051#									
DM13	027475	6539	9052#									
DM14	027565	6544	9053#									
DM16	027664	6555	9054#									
DM17	027743	6560	9055#									
DM2	027054	6493	6499	9044#								
DM20	030041	6566	9056#									
DM21	030073	6571	9057#									
DM23	030142	6581	9058#									
DM24	030207	6586	9059#									
DM25	030263	6591	9060#									
DM26	030303	6596	9061#									
DM27	030323	6601	9062#									
DM31	030357	6611	9063#									
DM4	027110	6504	9045#									
DM5	027146	6509	9046#									
DM6	027204	6514	9047#									
DM7	027250	6519	9048#									
DONE	014006	8021#										
DPDBH	013264	7895#										
DPDBL	013172	7858#										
DSWR	= 177570	6186#	6485	6624								
DT1	001646	6485#	6490									
DT12	001674	6485#	6536	6541								
DT14	001706	6485#	6546	6557								
DT15	001720	6485#	6552									
DT2	001660	6485#	6496	6501	6506	6511	6516	6521	6526	6531	6563	6568
DT21	001736	6485#	6573									
DT23	001754	6485#	6583									
DT24	001772	6485#	6588									
DT25	002002	6485#	6593									
DT26	002016	6485#	6598	6603								
DT30	002030	6485#	6608									
DT31	002042	6485#	6613									
EMTVEC=	000030	6186#										
ENDINS	021634	8919#										
ERRTRP	025124	6212	6721	6816	8598	8942#						
ERRVEC=	000004	6186#	6211	6624*	6648*	6657*	6681*	6721*	6741*	6748*	6799*	6816*
FADMAP	001570	8594*	8598*	8919*								
		6485#	7084*	7085*	8146	8148	8271	8273	8295	8297	8919*	

CZQMCG0 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 12-MAR-80 13:10 PAGE 60-3
CZQMCG.P11 12-MAR-80 13:07 CROSS REFERENCE TABLE -- USER SYMBOLS

J 10												
CROSS REFERENCE TABLE -- USER SYMBOLS												
MAC(Y11 30A(1052)) 12-MAR-80 13:10 PAGE 60-5												
PIRQVE= 000240	6186#											
PMEMAP 001540	6485#	6851*	6852*	6876*	6877*	6941*	6942*	6945*	6946*	7548	7550	
PRELOC 026552	8427	9031#										
PRGMAP 000602	6251	6252	6272	6287#	6632*	6633*	8024	8026	8030	8434	8463	8471* 8489
	8514*	8522	8563*	8564*	8919							
PROREL 025770	9016#											
P^0 - 000000	6186#											
PR1 = 000040	6186#											
PR2 = 000100	6186#											
PR3 = 000140	6186#											
PR4 = 000200	6186#											
PR5 = 000240	6186#											
PR6 = 000300	6186#											
PR7 = 000340	6186#											
PS = 177776	6186#											
PSCAN 017754	8629	8675	8677	8689#								
PSW = 177776	6186#	6627	6928	7048	7069	7118	8046	8825	8826	8919	8920	8921 8922
	8923	8924	8933									
PWRMSG 02565*	6290	9014#										
PWRVEC= 000024	6186#	6290*	6624*	8502*	8555*							
RADTAB 001622	6485#	8508	8546									
RANTST 012500	7661#											
RELOC 016346	8407#	8465	8493	8529	8539							
RELOCF 000600	6267	6286#	6634*	7140	8164	8496*	8500*	8509	8516	8537	8562*	8642 8919
	8922	8932	8939									
RELTOP 016470	8037	8434#										
RELO 017072	6274	8040	8522#									
RESCHK 005262	6975	7005#										
RESLDR 017300	6280	8043	8572#									
RESRVD 001516	6485#	6978*	6982	6985	6990	6993	7614*	7615	7616	7638		
RESTAR 000300	6207	6224#	6290	6631								
RESTOR 000304	6208	6226#										
REST1 000306	6225	6227#										
REST2 000324	6229	6231#										
RESVEC= 000010	6186#											
ROTATE 016220	7293	7304	8353#									
RW = 000006	6191#	8056	8057	8058	8059	8063						
SAVLDL 017360	6642	8046	8590#									
SAVTST 001534	6485#	6724*	6725*	7050*	7051*	7086*	7087*	8024	8026	8919		
SCANM 026646	8690	9033#										
SELECT 002656	6205	6623#										
SELFLG 001556	6485#	6621*	6623*	7034								
SETAF 017612	7555	8643	8645	8649#								
SETCON 016200	7290	7301	7545	8345#								
SKPMES 026773	8919	9036#										
SPRNT 020322	6984	6995	7025	7562	8766#							
SPRNTA 020410	8776	8780	8785#									
SPRNTB 020414	8768	8786#										
SPRNTP 020346	7602	7618	7628	7641	8774#							
SPRNTO 020334	8628	8673	8676	8716	8770#							
SPRNTO 020352	6991	7172	7190	7240	7582	7596	7646	8772	8775#			
SPRNT1 020360	7223	8778#										
SPRNT2 020376	7162	7207	7260	7284	7296	7307	7323	7324	7325	7326	7340	7343 7346
	7369	7370	7371	7372	7386	7389	7392	7415	7416	7417	7418	7432 7435
	7438	7439	7442	7445	7446	7449	7452	7453	7456	7459	7480	7481 7482
	7483	7497	7500	7503	7504	7507	7510	7511	7514	7517	7518	7521 7524

CZQMCG0 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) K 10
CZQMCG.P11 12-MAR-80 13:07 CROSS REFERENCE TABLE -- USER SYMBOLS 12-MAR-80 13:10 PAGE 60-6

SEQ 0127.

CZQMCGO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) L 10
CZQMCG.P11 12-MAR-80 13:07 CROSS REFERENCE TABLE -- USER SYMBOLS 12-MAR-80 13:10 PAGE 60-7

SEQ 0128

TST1	006176	7143	7145	7157#					
TST10	007050	7267	7271	7277#					
TST11	007132	7281		7288#					
TST12	007216		7299#						
TST13	007300		7310#						
TST14	007624	7310		7355#					
TST15	010154	7355		7401#					
TST16	010776	7401		7466#					
TST17	011620	7466		7538#					
TST2	006322		7175#						
TST20	012472	7543		7660#					
TST21	012606		7706#						
TST22	012676	7706		7743#					
TST23	012770	7743		7780#					
TST24	013066	7780		7820#					
TST25	013160	7820		7857#					
TST26	013252	7857		7894#					
TST27	013346	7894		7932#					
TST3	006416		7193#						
TST30	013562		7985#						
TST31	013674		8002#						
TST32	014014	6485	7157	8022#					
TST4	006522		7211#						
TST5	006612		7226#						
TST6	006706		7248#	7273					
TST6A	006714		7249#	7274					
TST7	006736		7257#	7273					
TYPMAP	020422	6722	6932	8793#					
UNEXPT	026511	8614	9030#						
UP	= 000000	6190#	8056	8057	8058	8059	8063		
WMP	001612	6485#	6856	6860	6894*	7567	7574		
WMPBYT	011662	7548#							
WMPB0	011626	7539#							
WMPB1	011722	7557#	7656						
WMPB2	011766	7565#	7652						
WMPB3	012336	7623	7630#						
WMPB4	012426	7583	7597	7647#					
WMPB5	012452	7554	7560	7654#					
W3X9	016266	7314	7359	7405	7470	8376#			
SAPTHD	001330	6485#							
SAPTR	001512	6485#	8938						
SASTAT	001344	6485#	8938						
SASTEN	001510	6485#							
SATYC	024060	8938#							
SATY1	024034	8938#							
SATY3	024042	8937		8938#					
SATY4	024052	8921		8938#					
SATY6	024350	8938#							
SATY7	024414	8938#							
SAUTOB	001134	6485#	6627*	8923					
\$BASE	001260	6485#							
\$BDADR	001122	6485#	8420*	8613*					
\$BDDAT	001126	6485#	8418*	8786*					
\$BELL	001174	6485#	8921						
\$CDW1	001264	6485#							
\$FDW2	001266	6485#							

ZOMCGO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 12-MAR-80 13:10 PAGE 60-8
ZOMCG.P11 12-MAR-80 13:07 CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0129

CZQMCG0 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 12-MAR-80 13:10 PAGE 60-9
CZQMCG.P11 12-MAR-80 13:07 CROSS REFERENCE TABLE -- USER SYMBOLS N 10

SEQ 0130

CZQMC60 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 12-MAR-80 13:10 PAGE 60-10
CZQMCG.P11 12-MAR-80 13:07 CROSS REFERENCE TABLE -- USER SYMBOLS B 11

SEQ 0131

CZOMCG0 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 12-MAR-80 13:10 PAGE 60-11
CZOMCG.P11 12-MAR-80 13:07 CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0132

CZQMCGO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) D 11
CZQMCG.P11 12-MAR-80 13:07 CROSS REFERENCE TABLE -- 12-MAR-80 13:10 PAGE 61

SEQ 0133

ABORT	6078#	6258	8095	8128	8166	8338	8422	8436	8491	8524	8574				
CKSWR	6008#	8919	8920	8921											
CKWD	6131#	6991	7162	7172	7207	7223	7240	7260	7284	7296	7307	7323	7324	7325	7326
	7340	7343	7346	7369	7370	7371	7372	7386	7389	7392	7415	7416	7417	7418	7432
	7435	7438	7439	7442	7445	7446	7449	7452	7453	7456	7459	7480	7481	7482	7483
	7497	7500	7503	7504	7507	7510	7511	7514	7517	7518	7521	7524	7618	7641	7675
	7715	7752	7790	7829	7866	7904	7941	7945	7962	7999	8016				
CKWD2	6147#	7162	7207	7260	7284	7323	7324	7325	7326	7340	7343	7346	7369	7370	7371
	7372	7386	7389	7392	7415	7416	7417	7418	7432	7435	7438	7439	7442	7445	7446
	7449	7452	7453	7456	7459	7480	7481	7482	7483	7497	7500	7503	7504	7507	7510
COMMEN	1526#	6176#	6181	6186#	6617	7131									
ENDCOM	1538#	6176#	6183	6186#	6620	7134									
ERROR	6186#														
ESCAPE	1654#	6186#													
GETPRI	1278#	6186#													
GETSWR	1725#	6186#	6627#												
GTSWR	6004#	6627													
LDPDR	6082#	8056	8057	8058	8059	8063									
MORETA	6295#	6485													
MULT	4393#	6186#													
NEWTST	1585#	6174#	6186#	7157	7175	7193	7211	7226	7248	7257	7277	7288	7299	7310	7355
	7401	7466	7538	7660	7706	7743	7780	7820	7857	7894	7932	7985	8002		
POP	2103#	6171#	6186#	6290	7636	7644	8323	8339	8429	8515	8553	8631	8656	8680	8729
	8739	8746	8758	8827	8833	8924	8938	8939	8994						
PRINT	6162#	6652	6680	6723	6730	6745	6756	6763	6782	6819	6912	6918	6922	6926	6927
	6929	7047	7068	7108	7117	8044	8427	8614	8627	8690	8722	8745	8797	8919	8990
	8996														
PUSH	2095#	6171#	6186#	6290	7603	7620	8312	8330	8407	8437	8452	8545	8615	8651	8667
	8689	8700	8707	8752	8799	8821	8924	8938	8939	8956					
RDCHR	6037#	8923													
RDDEC	6049#														
RDLIN	6041#	8924													
RDOCT	6045#	7048	7069	7118											
REPORT	5352#	6175#	6186#												
RESREG	6057#														
SAVREG	6053#														
SCOPE	6186#														
SCOPEX	8840#	8919													
SCOPIN	8836#	8919													
SETPRI	1246#	6186#													
SETUP	1302#	6174#	6186#	6624	7069	7118	8046	8825	8826	8919	8920	8921	8922	8923	8924
SIMTRP	5972#	6627	6928	7048											
	8933														
SKIP	1688#	6186#	7281												
SLASH	1478#	6176#	6186#	6485											
SPACE	6186#														
STARS	1447#	6171#	6176#	6186#	6215	6218	6223	6290	6485	6661	6670	6733	6736	6790	6793
	6825	6834	6845	6849	6906	6909	6963	6967	7000	7003	7040	7042	7157	7175	7193
	7211	7226	7244	7247	7248	7257	7277	7288	7299	7310	7317	7319	7333	7335	7355
	7363	7365	7379	7381	7401	7408	7410	7425	7427	7466	7473	7475	7490	7492	7538
	7660	7706	7743	7780	7820	7857	7894	7932	7985	8002	8046	8049	8055	8076	8078
	8175	8180	8265	8270	8304	8307	8326	8328	8342	8344	8350	8352	8373	8375	8404
	8406	8431	8433	8519	8521	8567	8571	8608	8612	8634	8637	8659	8661	8683	8687
	8749	8751	8762	8765	8789	8792	8919	8921	8922	8923	8924	8926	8930	8937	8938
	8939	8940	9002	9005	9040	9042	9065	9067	9081	9083					

E 11
CZOMCG0 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 12-MAR-80 13:10 PAGE 61-1
CZOMCG.P11 12-MAR-80 13:07 CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0134

F 11

CZOMCGO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 12-MAR-80 13:10 PAGE 61-2
CZOMCG.P11 12-MAR-80 13:07 CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0125

7323	7324	7325	7326	7340	7343	7346	7369	7370	7371	7372	7386	7389	7392	7415
7416	7417	7418	7432	7435	7438	7439	7442	7445	7446	7449	7452	7453	7456	7459
7480	7481	7482	7483	7497	7500	7503	7504	7507	7510	7511	7514	7517	7518	7521
7524	7562	7582	7596	7602	7618	7628	7641	7646	7675	7715	7752	7790	7829	7866
7904	7941	7945	7962	7999	8016	8421	8621	8628	8673	8676	8716	8947		
.HEAD	50#	6173#		6182										
.KT11	319#	6171#		6189										
.MARHO	7909#	7932												
.SCOPE	5980#	7157	7175	7193	7211	7226	7248	7257	7277	7288	7299	7310	7355	7401
	7538	7660	7706	7743	7780	7820	7857	7894	7932	7985	8002	8021		7466
.SETUP	1180#	6174#	6203											
.SWRMI	92#	6173#		6184										
.SWRLO	6173#	6184#		6185										
.TM7	7254#	7257												
.SACT1	4961#	6175#	6215											
.SAPTB	5005#	6175#	6485#											
.SAPTH	5261#	6175#	6485											
.SPTY	5436#	6175#	8938											
.SASTA	5307#	6175#	6485											
.SCATC	905#	6173#	6204											
.SCMTA	1016#	6171#	6485											
.SD82D	4591#													
.SD820	4714#													
.SDIV	4494#													
.SEOP	2162#	5593#	6174#	8046										
.SERRO	2643#	6172#	8921											
.SERRT	2838#	5804#	8922											
.SMULT	4431#													
.SPOWE	4143#	6171#	6290											
.SRAND	4218#													
.SRDDE	3814#													
.SRDOC	3723#	6174#	8924											
.SREAD	3328#	6174#	8923											
.SR2AZ	4858#													
.SSAVE	3889#													
.SSB2D	4675#													
.SSB20	4776#													
.SSCOP	2397#	6171#	8919											
.SSIZE	4271#													
.SSUPR	4814#													
.STRAP	3991#													
.STYPB	3221#													
.STYPD	3144#	5907#	6173#	8939										
.STYPE	2925#	6172#	8937											
.STYPO	3048#	6173#	8940											
.S40CA	944#													
.1170	498#													

. ABS. 032110 000

ERRORS DETECTED: 0

CZOMCG.BIN,CZOMCG.LST/CRF=CZOMCG.SML,CZOMCG.P11
RUN-TIME: 60 80 4 SECONDS

CZOMCG0 0-124K MEMORY EXERCISER, 16K VER G 11
CZOMCG.P11 12-MAR-80 13:07 MACV11 30A(1052) 12-MAR-80 13:10 PAGE 61-3
(CROSS REFERENCE TABLE -- MACRO NAMES)

SEQ 0136

RUN-TIME RATIO: 325/146=2.2
CORE USED: 39K (77 PAGES)